Simple-Pair 用户指南



版本 1.0 版权 © 2016

关于本手册

本文介绍了乐鑫自主研发的 Simple-Pair 技术,说明了使用方式并提供了示例解决方案。 本手册结构如下:

章	标题	内容
第1章	Simple-Pair 技术简介	介绍 Simple-Pair 的技术原理。
第2章	Simple-Pair 使用方式	说明 Simple-Pair 的使用流程。
第3章	解决方案	提供 Simple-Pair 的示例解决方案。
第4章	示例代码	提供 Simple-Pair 的示例代码。

发布说明

日期	版本	发布说明
2016.07	V1.0	首次发布。

目录

1.	Simple-Pair 技术简介	1
	1.1. 概述	
2.	Simple-Pair 使用方式	2
3.	解决方案	3
4.	示例代码	4



Simple-Pair 技术简介

1.1. 概述

Simple-Pair 隶属于 ESP IE 的一部分,用于两个设备间快速协商或交换 Key(或其他信息,一般用于交换 Key)。

Simple-Pair 实现了数个步骤就能完成交换 Key。目前,Simple-Pair 仅提供 Station 与 AP 间交换 Key(限定 16 字节),最终需要交换的 Key 是从 AP 端发往 Station 端。为了保护最终的交换步骤,Simple-Pair 包含了一个被称为 TempKey 的 Key。这个 Key 一般存在 Station 端,用户在 Simple-Pair 之前,需要通过某些手段让 AP 和 Station 双方设备都知晓这个 TempKey。

Simple-Pair 设计初衷是用于快速交换某些功能要使用的 Key,能够使两个从未配对过的设备进行配对操作。在整个配对过程中,建议双方设备都暂时禁止休眠,以免无法正常收包。 Simple-Pair 需要交换的 Key 存放在 AP 端,经过配对端步骤之后,交换的 Key 将会从 AP 端发到 Station 端,此时双方设备已经完成了 Simple-Pair 的步骤。对应用层来说,配对的过程还未结束,必须使用交换完的 Key 进行一次尝试,尝试成功方可认为 Simple-Pair 是正确的。

说明:

可以用智能手机参与控制 Simple-Pair 其中的部分过程。关于如何使用智能手机,请参考第3章。



Simple-Pair 使用方式

在 Simple-Pair 的概念里,设备对应用层只有三个步骤: Set Peer Info, AP ANNOUNCE (STA SCAN) 和 START Negotiate。所有的状态都通过回调函数来实现。

用户需要向 Simple-Pair 来注册一个状态回调函数,在 Simple-Pair 运行的过程中,诸如配对完成、协商请求、超时、错误等等都会通过状态回调函数来指示。如 AP 端的状态回调函数传入状态指示有 Station 发来协商请求,则 AP 端需要决定是否同意请求;如状态回调函数传入错误的状态值,则需要根据状态值的不同做不同的处理(详细请见 Demo 程序)。

在进行配对协商之前,AP 要进入 Simple-Pair Announce 模式,Station 则要进入 Simple-Pair Scan 模式。进入这些模式之后,Station 需要向 AP 发送 IEEE802.11 Probe Request (即进行普通的扫描 AP 的操作),这样 Station 才知道哪些 AP 已经准备好 Simple-Pair 了;AP 才知道哪些 Station 是准备好 Simple-Pair 了。

Station 在扫描到 AP 之后,需要从 BSS_INFO 里选择已经准备好 Simple-Pair 的 AP,设置好 AP 的 MAC 地址以及 TempKey,然后发送 STA Negotiate Start。

AP 收到请求之后,需要(或联合手机)判断是否同意请求。若同意,先设置好 Station 的 MAC 地址、TempKey 和交换的 Key,然后发送 AP Negotiate Start;若不同意,设置好 Station 的 MAC 地址和 TempKey,然后发送 AP Negotiate Refuse。

Station 收到 AP Negotiate Start,则会进行协商步骤;若接收到 Refuse,则通过状态回调函数告知应用层,应用层需要做相应的处理。

在协商完成之后,Station 端就获得了 AP 发送端交换的 Key。此时 Simple-Pair 端步骤已经结束。但是应用层需要做一次验证,以确定交换 Key 是正确的。

1 注意:

在协商开始之前,应用层需要检查 *ESP-NOW* 功能(以后或许会增加新功能)是否有对相同 *MAC* 地址设置 过 *Key*,如设置过,请做相应功能的 *Delete* 操作,否则同一个 *MAC* 地址拥有两个 *Key*,可能会造成 *Simple-Pair* 使用错误的 *Key*。除 *Station / SoftAP* 的连接会设置密钥之外,系统中不允许其他功能对同一个 *MAC* 地址设置两次密钥。



解决方案

以下以 Simple-Pair 交换 ESP-NOW 的 Key 为例说明一种解决方案。

14日・

Simple-Pair 可用于但不限于 ESP-NOW 的 Key 交换, 也可用于其他功能的 Key 交换。




图 3-1. 示例解决方案

Simple-Pair 的步骤完成后,请务必使用交换完成的 Key 做一次验证,验证完成才能认为 Key 的交换是成功的。智能手机可控制其中部分步骤,在成功后,智能手机可控制 ESP-NOW SLAVE 设备是否需要进行下一个 CONTROLLER 的匹配操作。



示例代码

说明:

更多关于 Simple-Pair API 的信息,请参考 ESP8266 Non-OS SDK API 参考。

```
#include "osapi.h"
#include "user_interface.h"
#include "simple pair.h"
 * open AS_STA to compile sta test code
 * open AS AP to compile ap test code
 * don't open both
//#define AS_STA
#define AS_AP
 * FunctionName : user_rf_cal_sector_set
 * Description : SDK just reversed 4 sectors, used for rf init data
and paramters.
                  We add this function to force users to set rf cal
sector, since
                  we don't know which sector is free in user's
application.
                  sector map for last several sectors : ABCCC
                  A : rf cal
                  B : rf init data
```



```
C : sdk parameters
 * Parameters : none
 * Returns
               : rf cal sector
********/
uint32 ICACHE_FLASH_ATTR
user rf cal sector set(void)
    enum flash_size_map size_map = system_get_flash_size_map();
    uint32 rf_cal_sec = 0;
    switch (size_map) {
        case FLASH_SIZE_4M_MAP_256_256:
            rf_cal_sec = 128 - 5;
            break;
        case FLASH SIZE 8M MAP 512 512:
            rf_cal_sec = 256 - 5;
            break:
        case FLASH_SIZE_16M_MAP_512_512:
        case FLASH_SIZE_16M_MAP_1024_1024:
            rf_cal_sec = 512 - 5;
            break;
        case FLASH_SIZE_32M_MAP_512_512:
        case FLASH SIZE 32M MAP 1024 1024:
            rf_cal_sec = 1024 - 5;
            break;
        default:
            rf_cal_sec = 0;
            break;
    }
```



```
return rf_cal_sec;
}
void ICACHE_FLASH_ATTR
user_rf_pre_init(void)
/* STA & AP use the same tmpkey to encrypt Simple Pair communication
static u8 tmpkey[16] = \{0x00, 0x01, 0x02, 0x03, 0x04, 0x05, 0x06, 0x06
0x07,
                                                                    0x08, 0x09, 0x0a, 0x0b, 0x0c, 0x0d, 0x0e, 0x0f};
#ifdef AS_STA
/* since the ex_key transfer from AP to STA, so STA's ex_key don't
care */
static u8 ex_key[16] = \{0x00\};
#endif /* AS STA */
#ifdef AS_AP
/* since the ex key transfer from AP to STA, so AP's ex key must be
static u8 ex key[16] = \{0xff, 0xee, 0xdd, 0xcc, 0xbb, 0xaa, 0x99,
0x88,
                                                                    0 \times 77, 0 \times 66, 0 \times 55, 0 \times 44, 0 \times 33, 0 \times 22, 0 \times 11, 0 \times 00};
#endif /* AS AP */
void ICACHE FLASH ATTR
show_key(u8 *buf, u8 len)
{
                       u8 i;
                       for (i = 0; i < len; i++)
                                             os_printf("\%02x,\%s", buf[i], (i\%16 == 15?"\n":" "));
}
```



```
#ifdef AS_STA
static void ICACHE_FLASH_ATTR
scan done(void *arg, STATUS status)
    int ret;
    if (status == OK) {
        struct bss_info *bss_link = (struct bss_info *)arg;
        while (bss_link != NULL) {
          if (bss_link->simple_pair) {
                os printf("Simple Pair: bssid %02x:%02x:%02x:%02x:
%02x:%02x Ready!\n",
                        bss_link->bssid[0], bss_link->bssid[1],
bss link->bssid[2],
                        bss_link->bssid[3], bss_link->bssid[4],
bss link->bssid[5]);
            simple_pair_set_peer_ref(bss_link->bssid, tmpkey, NULL);
            ret = simple_pair_sta_start_negotiate();
            if (ret)
                  os_printf("Simple Pair: STA start NEG Failed\n");
            else
                  os_printf("Simple Pair: STA start NEG OK\n");
            break;
          }
            bss_link = bss_link->next.stqe_next;
        }
    } else {
        os_printf("err, scan status %d\n", status);
    }
}
#endif
```



```
void ICACHE FLASH ATTR
sp status(u8 *sa, u8 status)
#ifdef AS_STA
      switch (status) {
      case SP_ST_STA_FINISH:
            simple pair get peer ref(NULL, NULL, ex key);
            os_printf("Simple Pair: STA FINISH, Ex_key ");
            show_key(ex_key, 16);
            /* TODO: Try to use the ex-key communicate with AP, for
example use ESP-NOW */
            /* if test ok , deinit simple pair */
            simple_pair_deinit();
            break;
      case SP_ST_STA_AP_REFUSE_NEG:
            /* AP refuse , so try simple pair again or scan other
ap*/
            os printf("Simple Pair: Recv AP Refuse\n");
            simple pair state reset();
            simple_pair_sta_enter_scan_mode();
            wifi station scan(NULL, scan done);
            break;
      case SP_ST_WAIT_TIMEOUT:
            /* In negotiate, timeout , so try simple pair again */
            os_printf("Simple Pair: Neg Timeout\n");
            simple pair state reset();
            simple_pair_sta_enter_scan_mode();
            wifi_station_scan(NULL, scan_done);
            break:
      case SP_ST_SEND_ERROR:
            os printf("Simple Pair: Send Error\n");
```



```
/* maybe the simple_pair_set_peer_ref() haven't called,
it send to a wrong mac address */
            break;
      case SP_ST_KEY_INSTALL_ERR:
            os_printf("Simple Pair: Key Install Error\n");
            /* 1. maybe something argument error.
               2. maybe the key number is full in system*/
            /* TODO: Check other modules which use lots of keys
                         Example: ESPNOW and STA/AP use lots of keys
* /
            break;
      case SP_ST_KEY_OVERLAP_ERR:
            os printf("Simple Pair: Key Overlap Error\n");
            /* 1. maybe something argument error.
               2. maybe the MAC Address is already use in ESP-NOW or
other module
                  the same MAC Address has multi key*/
            /* TODO: Check if the same MAC Address used already,
                         Example: del MAC item of ESPNOW or other
module */
            break;
      case SP_ST_OP_ERROR:
            os_printf("Simple Pair: Operation Order Error\n");
            /* 1. maybe the function call order has something wrong
* /
            /* TODO: Adjust your function call order */
            break;
      default:
            os_printf("Simple Pair: Unknown Error\n");
            break:
      }
```



```
#endif /* AS_STA */
#ifdef AS AP
      switch (status) {
      case SP_ST_AP_FINISH:
            simple_pair_get_peer_ref(NULL, NULL, ex_key);
            os_printf("Simple Pair: AP FINISH\n");
            /* TODO: Wait STA use the ex-key communicate with AP, for
example use ESP-NOW */
            /* if test ok , deinit simple pair */
            simple_pair_deinit();
            break;
      case SP_ST_AP_RECV_NEG:
            /* AP recv a STA's negotiate request */
            os printf("Simple Pair: Recv STA Negotiate Request\n");
            /* set peer must be called, because the simple pair need
to know what peer mac is */
            simple_pair_set_peer_ref(sa, tmpkey, ex_key);
            /* TODO: In this phase, the AP can interaction with Smart
Phone,
                   if the Phone agree, call start_neg or refuse */
            simple_pair_ap_start_negotiate();
            //simple_pair_ap_refuse_negotiate();
            /* TODO:if refuse, maybe call simple_pair_deinit() to
ending the simple pair */
            break;
      case SP ST WAIT TIMEOUT:
            /* In negotiate, timeout , so re-enter in to announce
mode*/
            os_printf("Simple Pair: Neg Timeout\n");
            simple_pair_state_reset();
```



```
simple_pair_ap_enter_announce_mode();
            break;
      case SP ST SEND ERROR:
            os printf("Simple Pair: Send Error\n");
            /* maybe the simple_pair_set_peer_ref() haven't called,
it send to a wrong mac address */
            break;
      case SP ST KEY INSTALL ERR:
            os_printf("Simple Pair: Key Install Error\n");
            /* 1. maybe something argument error.
               2. maybe the key number is full in system*/
            /* TODO: Check other modules which use lots of keys
                         Example: ESPNOW and STA/AP use lots of keys
* /
            break;
      case SP_ST_KEY_OVERLAP_ERR:
            os printf("Simple Pair: Key Overlap Error\n");
            /* 1. maybe something argument error.
               2. maybe the MAC Address is already use in ESP-NOW or
other module
                  the same MAC Address has multi key*/
            /* TODO: Check if the same MAC Address used already,
                         Example: del MAC item of ESPNOW or other
module */
            break;
      case SP ST OP ERROR:
            os_printf("Simple Pair: Operation Order Error\n");
            /* 1. maybe the function call order has something wrong
* /
            /* TODO: Adjust your function call order */
            break;
      default:
```



```
os_printf("Simple Pair: Unknown Error\n");
            break;
      }
#endif /* AS_AP */
}
void ICACHE_FLASH_ATTR
init done(void)
      int ret:
#ifdef AS_STA
      wifi_set_opmode(STATION_MODE);
      /* init simple pair */
      ret = simple pair init();
      if (ret) {
            os_printf("Simple Pair: init error, %d\n", ret);
            return;
      }
      /* register simple pair status callback function */
      ret = register_simple_pair_status_cb(sp_status);
      if (ret) {
            os_printf("Simple Pair: register status cb error, %d\n",
ret);
            return;
      }
      os_printf("Simple Pair: STA Enter Scan Mode ...\n");
      ret = simple_pair_sta_enter_scan_mode();
      if (ret) {
            os_printf("Simple Pair: STA Enter Scan Mode Error, %d\n",
ret);
            return;
```



```
/* scan ap to searh which ap is ready to simple pair */
      os printf("Simple Pair: STA Scan AP ...\n");
        wifi station scan(NULL, scan done);
#endif
#ifdef AS_AP
      wifi set opmode(SOFTAP MODE);
      /* init simple pair */
      ret = simple_pair_init();
      if (ret) {
            os_printf("Simple Pair: init error, %d\n", ret);
            return;
      }
      /* register simple pair status callback function */
      ret = register_simple_pair_status_cb(sp_status);
      if (ret) {
            os_printf("Simple Pair: register status cb error, %d\n",
ret);
            return;
      }
      os_printf("Simple Pair: AP Enter Announce Mode ...\n");
      /* ap must enter announce mode , so the sta can know which ap
is ready to simple pair */
      ret = simple_pair_ap_enter_announce_mode();
      if (ret) {
            os_printf("Simple Pair: AP Enter Announce Mode Error, %d
\n", ret);
            return;
      }
#endif
}
```



```
void ICACHE_FLASH_ATTR
user_init(void)
{
        system_init_done_cb(init_done);
}
```



免责申明和版权公告

本文中的信息,包括供参考的 URL 地址,如有变更,恕不另行通知。

文档"按现状"提供,不负任何担保责任,包括对适销性、适用于特定用途或非侵权性的任何担保,和任何提案、规格或样品在他处提到的任何担保。本文档不负任何责任,包括使用本文档内信息产生的侵犯任何专利权行为的责任。本文档在此未以禁止反言或其他方式授予任何知识产权使用许可,不管是明示许可还是暗示许可。

Wi-Fi 联盟成员标志归 Wi-Fi 联盟所有。蓝牙标志是 Bluetooth SIG 的注册商标。 文中提到的所有商标名称、商标和注册商标均属其各自所有者的财产,特此声明。

版权归© 2016 乐鑫所有。保留所有权利。