

TABLE C.5.1-J3.1. J3.1 to Link 11/11B Message Translation Tree (Sheet 1 of 4)

C-121

TEST NODE DIAGRAM	TEST NODE CONDITION	NOTES
<pre>graph TD 1[1] -- N --> 2[2] 1 -- Y --> A[A] 2 -- N --> 3[3] 2 -- Y --> B[B] 3 -- N --> 4[4] 3 -- Y --> C[C] 4 -- N --> 5[5] 4 -- Y --> D[D] 5 -- N --> 6[6] 5 -- Y --> E[E] 6 -- N --> F[F] 6 -- Y --> G[G] 6 -- N --> Z1[Z]</pre>	1. EXERCISE INDICATOR = 1. 2. SIMULATION INDICATOR = 1. 3. THIS IS INITIAL REPORT FROM THIS DATA SOURCE FOR THIS TN. 4. TN, PREVIOUSLY REPORTED IS OTHER THAN NO STATEMENT. 5. NONZERO IFF/SIF IS REPORTED. 6. HOUR OR MINUTE IS OTHER THAN NO STATEMENT.	1
A B C D E F F G G G G H Z Z Z	REQUIRED ACTION A. DISCARD MESSAGE. B. FWD M.9A(AC=0, SI=1), IF APPROPRIATE. C. FWD M.5 INITIAL SEQUENCE. D. FWD M.9B(AC=6). E. FWD M.11D. F. FWD M.5. G. GO TO NEXT NUMERICAL TEST NODE. H. FWD M.85. Z. END TRANSLATION.	

APPENDIX C

TABLE C.5.1-J3.1. J3.1 to Link 11/11B Message Translation Tree (Sheet 2 of 4)

NOTES

1. The M.9A(AC=0, SI=1) message shall precede appropriate messages. (See paragraph C.4.8.6)

APPENDIX C

TABLE C.5.1-J3.1. J3.1 to Link 11/11B Message Translation Tree (Sheet 3 of 4)

RELATED MESSAGES

RECEIVED LINK 16
MESSAGE

J3.1

ALL POSSIBLE LINK 11/11B MESSAGES
THAT MAY BE REQUIRED

M.5
M.85
M.9A(AC=0)
M.9B(AC = 6)
M.11D

APPENDIX C

TABLE C.5.1-J3.1. J3.1 to Link 11/11B Message Translation Tree (Sheet 4 of 4)

FORWARDING TRANSMIT REQUIREMENTS

1. The forwarded M.5/M.85 messages are transmitted on Link 11/11B each transmit opportunity until the emergency point is dropped.
2. The forwarded M.9B message shall be transmitted in accordance with Link 11/11B redundancy requirements.
3. Upon receipt of the J3.1C1 word with nonzero IFF/SIF data, the M.11D message(s) shall be forwarded.

DATA RETENTION RULES

The FJU shall retain current Emergency Point data on all points being forwarded.