

TABLE C.5.1-M.14. M.14 to Link 16 Message Translation Tree (Sheet 1 of 4)

TEST NODE DIAGRAM		TEST NODE CONDITION	NOTES
<pre>graph TD 1[1] -- Y --> 2[2] 1 -- N --> 3[3] 2 -- Y --> 3 2 -- N --> 4[4] 3 -- Y --> 4 3 -- N --> 5[5] 4 -- Y --> 5 4 -- N --> 6[6] 5 -- Y --> 6 5 -- N --> 6 6 --- A[A]</pre>		1. W/ES = 0, 1, OR 12. 2. W/ES = 2, 5, 6, 8, OR 10 AND WEAPON TYPE = 0-10. 3. W/ES = 3 AND WEAPON TYPE = 0-2, 4, 6-8, OR 10. 4. W/ES = 4 OR 7 AND WEAPON TYPE = 1-10. 5. W/ES =9 AND WEAPON TYPE = 0.	1
		REQUIRED ACTION	
B A Z C C C C Z Z Z Z Z Z Z		A. DISCARD MESSAGE. B. FWD J13.2, J13.3, J13.4, OR J13.5 MESSAGE. C. FWD J10.2 MESSAGE. Z. END TRANSLATION.	

C-351

APPENDIX C

TABLE C.5.1-M.14. M.14 to Link 16 Message Translation Tree (Sheet 2 of 4)

NOTES

1. The Environment/Category of the M.14 TN Friendly Weapon System will determine whether the J13.2 Air, J13.3 Surface (Maritime), J13.4 Subsurface (Maritime), or J13.5 Land (Ground) Platform and System Status message will be forwarded. If the Environment/Category of the M.14 TN Friendly Weapon System cannot be determined, a J13 Series message shall not be forwarded.

APPENDIX C

TABLE C.5.1-M.14. M.14 to Link 16 Message Translation Tree (Sheet 3 of 4)

RELATED MESSAGES

RECEIVED LINK 11/11B
MESSAGE

M.14

ALL POSSIBLE LINK 16 MESSAGES
THAT MAY BE REQUIRED

J10.2

J13.2

J13.3

J13.4

J13.5

APPENDIX C

TABLE C.5.1-M.14. M.14 to Link 16 Message Translation Tree (Sheet 4 of 4)

FORWARDING TRANSMIT REQUIREMENTS

1. Each Engagement Status message will be forwarded in the appropriate J10.2 message or J13 series message when received, unless W/ES = 5, 8, or 9.
2. When W/ES = 5, 8, or 9, the first Engagement Status message received will be forwarded in the appropriate J10.2 message in two consecutive transmit opportunities. The FJU shall discard redundant M.14 W/ES = 5, 8, or 9 messages received.

DATA RETENTION RULES

There are no Data Retention Rules associated with this message translation.