

TABLE C.5.1-M.4D. M.4D/M.84D/M.4B to Link 16 Message Translation Tree (Sheet 1 of 4)

TEST NODE DIAGRAM		TEST NODE CONDITION	NOTES
<pre>graph TD 1[1] -- N --> 3R[3] 1 -- Y --> 2[2] 2 -- N --> 3R 2 -- Y --> 3L[3] 3L -- Y --> 4L[4] 3L -- N --> 4R[4] 4L -- Y --> Bottom[] 4L -- N --> 4R 4R -- Y --> Bottom 4R -- N --> 4L style Bottom fill:none,stroke:none</pre>		1. RECEIVED M.4D IS FOLLOWED BY AN M.84D MESSAGE AND RECEIVED M.4D/M.84D MESSAGE SEQUENCE IS LEGAL. 2. RECEIVED M.4D/M.84D IS FOLLOWED BY AN M.4B MESSAGE. 3. BEARING REPORT TYPE = 1. 4. M.84D(SW=0) BEARING INDICATOR = 1 OR M.84D(SW=1) BEARING INDICATOR = 1, OR NO M.84D(SW=1) RECEIVED.	1 1, 2
		REQUIRED ACTION	
A A A B B Z Z Z Z Z		A. DISCARD MESSAGE. B. FWD J5.4 MESSAGE. Z. END TRANSLATION.	

C-277

APPENDIX C

TABLE C.5.1-M.4D. M.4D/M.84D/M.4B to Link 16 Message Translation Tree
(Sheet 2 of 4)

NOTES

1. Up to five M.4D and/or M.84D messages may be received in a legal M.4D/M.84D message sequence. After an M.4D message is received, the FJU must check the following messages until a message which is not an M.4D or M.84D from the same PU/RU source for the specified track number is received. The data from all messages in a legal M.4D/M.84D message sequence shall be forwarded in a single J5.4 message. The following are the only legal M.4D/M.84D message sequences:

- o M.4D(BSW=0 or 1), M.84D(SW=0).
- o M.4D(BSW=0 or 1), M.84D(SW=0), M.4D(BSW=2), M.84D(SW=1).
- o M.4D(BSW=0 or 1), M.84D(SW=0), M.4D(BSW=2), M.84D(SW=1), M.4D(BSW=3).
- o M.4D(BSW=0 or 1), M.84D(SW=0), M.4D(BSW=2), M.4D(BSW=3).
- o M.4D(BSW=0 or 1), M.84D(SW=0), M.4D(BSW=3).
- o M.4D(BSW=0 or 1), M.84D(SW=0), M.4D(BSW=2).

2. If the received M.4B message does not follow an M.84D message, refer to the M.4B to Link 16 Message Translation Tree.

MIL-STD-6016B

APPENDIX C

TABLE C.5.1-M.4D. M.4D/M.84D/M.4B to Link 16 Message Translation Tree
(Sheet 3 of 4)

RELATED MESSAGES

RECEIVED LINK 11/11B
MESSAGE

M.4D/M.84D
M.4B

ALL POSSIBLE LINK 16 MESSAGES
THAT MAY BE REQUIRED

J5.4

APPENDIX C

TABLE C.5.1-M.4D. M.4D/M.84D/M.4B to Link 16 Message Translation Tree
(Sheet 4 of 4)

FORWARDING TRANSMIT REQUIREMENTS

1. When the initial sequence for an ASW Bearing is received from Link 11, the FJU shall set an indicator to initiate and transmit the appropriate J5.4 message with all data.
2. A J5.4I/J5.4E0 word sequence shall be forwarded for each subsequent Link 11 Acoustic Bearing message received.
3. A J5.4I/J5.4E0/J5.4C1 and/or J5.4C2 word sequence shall be forwarded when any field translatable to the J5.4C1 and/or J5.4C2 is received.

DATA RETENTION RULES

There are no Data Retention Rules associated with this message translation.