

Aim: How to Install Windows 10 on the Raspberry Pi 4.

Hardware:

Raspberry Pi 4 (4GB or 8GB recommended, 2GB is possible but very slow).

Storage device:

- o Option 1: MicroSD card (at least 32GB, Class 10)
- o Option 2 (better): USB 3.0 SSD (faster and more reliable).

HDMI monitor, keyboard, mouse, power supply.

Optional: USB Ethernet adapter

Steps:

Step 1: Download the latest pre-release version of WoR tool

<https://www.worproject.ml/downloads> and extract the files.

Step 2: Prepare Windows 10 ARM64 ISO

1. Go to UUPDump.net.
2. Choose Windows 10 ARM64 build (choose latest stable).
3. Download the script (zip file) and run it on your Windows PC.
 - o It downloads required files directly from Microsoft and builds an ISO.
4. At the end, you'll have a Windows 10 ARM64 ISO file.

Step 3: Install WoR and Prepare the SD/SSD

1. Insert your SD card or SSD into your Windows PC.
2. Open WoR.exe (run as Administrator).
3. Follow the wizard:

Step 1: Select your device (SD/SSD).

o Step 2: Point to your Windows 10 ARM64 ISO.

o Step 3: Select your device type: Raspberry Pi 4.

o Step 4: Provide the UEFI firmware and drivers.

o Step 5: Confirm installation settings.

4. WoR will now flash the Windows image to your device.

o This can take 30–60 minutes depending on storage speed.

Step 4: Booting Raspberry Pi 4

1. Insert the prepared storage into your Raspberry Pi 4.
2. Power it on → it will first load into the UEFI firmware screen.
3. (Optional but recommended):
 - o Go into UEFI settings.
 - o Change Boot Order to make your SD/SSD the first boot option.
- o Save and reboot.
4. Now, Windows 10 setup begins.

- o Select language, region, keyboard layout.
 - o Create or skip Microsoft account.
 - o Configure system preferences.
5. For network access, use a USB to Ethernet or a compatible WiFi dongle.
 6. Install Microsoft Edge by double clicking on the Microsoft Edge desktop icon.