一.Rock_5b使用介绍

1.所需配件

存储

tf卡、emmc、nvme任选其一

系统镜像文件

官方系统下载

包括ubuntu、debian、安卓

账户密码 rock rock

armbian没用自己创建密码, 默认是 root 1234

自行编译armbian

注意boot要改成fat格式

BOOTFS_TYPE="fat"

整合包系统下载@amazingfate

Openwrt

Uos

基于Arch的RebornOs

https://github.com/RebornOS-Developers/lxqt-rock5b-image

RebornOS论坛链接

https://forum.radxa.com/t/arch-based-rebornos-reviewed-on-rock5b/14237/5

Reborn OS安装wiki

spi下载

loader

官方spi-debug版

官方spi-关闭uboot串口输出

<u>armbianspi</u>

<u>zero-擦除spi</u>

SDK

rk驱动

RKDevTool

balenaEtcher

Win32Diskimager

2.win刷写镜像

2.1.tf卡

- 使用 balenaEtcher 烧录
 - 1. 使用读卡器把 TF 卡插入电脑
 - 2. 使用解压软件解压镜像压缩包,解压后的文件中,以".img"结尾的文件就是操作系统的 镜像文件
 - 3. 运行balenaEtcher,选择镜像文件和tf卡




• 使用 Win32Diskimager 烧录



2.2.NVME固态


- 下载loader和对应的spi
- 下载RKDevTool和rk驱动,安装rk驱动,按住mskrom按钮后上电
- 打开RKDevTool, 右键, load config 选择rock-5b-spinor.cfg



- spinor选择你下载的spi, loader选择下载的loader, 点击 run 刷写spi
- 按照刷写镜像到tf卡一样操作刷到nvme,插入5b通电开机

2.3 emmc

- 下载loader和系统镜像
- 下载RKDevTool和rk驱动,安装rk驱动,按住mskrom按钮后上电
- 打开RKDevTool, 右键, load config 选择rock-5b-emmc.cfg



- image选择你下载的系统镜像, loader选择下载的loader, 点击 run 刷写系统镜像
- emmc插入5b通电开机

3.Linux刷写镜像

使用dd命令,没有linux基础的请跳过

二.跑分参考

• 官方ubuntu-不知名品牌tf卡-默频2.5等奖





跑分软件

抽奖工具@happyme531

也可以手动抽奖

dmesg | grep pvtm

三.armbian系统超频

下载unlock.dts

修改13500000为你想要的电压

13500000是1.35v

上传到boot目录

armbian-add-overlay unlock.dts

四.网卡蓝牙修复(ax系列网卡)

MoMo ax210

<u>半世一夕</u> ax200

ax210 005

 $sudo \ mv \ /usr/lib/firmware/iwlwifi-ty-a0-gf-a0.pnvm \ /usr/lib/firmware/iwlwifi-ty-a0-gf-a0.bak \\$

五.驱动

. GPU

添加@amazingfate大佬的ppa源

只适用ubuntu22.04 LTS(jammy)

```
sudo add-apt-repository ppa:liujianfeng1994/panfork-mesa
sudo apt update
```

. 多媒体娱乐

包括 chromium110、ffmpeg4.4、gstreamer、kodi19.4、moonlight、obs28 等

```
sudo add-apt-repository ppa:liujianfeng1994/rockchip-multimedia
sudo apt update
```

六.定制自己的armbian

- 首先克隆@amazingfate的armbian-compile-action, 再克隆armbian-rock5b-images
- 修改armbian-compile-action中的action.yml

```
./compile.sh \
BOARD=${{ inputs.board }} \
BRANCH=${{ inputs.branch }} \
RELEASE=${{ env.release }} \
BUILD_MINIMAL=${{ env.build-minimal }} \
BUILD_DESKTOP=${{ env.build-desktop }} \
KERNEL_ONLY=no \
KERNEL_CONFIGURE=no \
DESKTOP_ENVIRONMENT=${{ env.desktop-environment }} \
DESKTOP_ENVIRONMENT_CONFIG_NAME=${{ env.desktop-environment-config-name }} \
DESKTOP_APPGROUPS_SELECTED=${{ env.desktop_appgroups_selected }} \
EXPERT=${{ env.expert }} \
BOARD_FIRMWARE_INSTALL="-full" \
SHARE_LOG=no \
DEBUG=yes \
COMPRESS_OUTPUTIMAGE=sha,gpg,xz
# 修改相应参数
touch .ignore_changes
        wget https://github.com/amazingfate/armbian-h88k-
images/raw/master/board-dts-add-h88k.patch -O patch/kernel/rockchip-rk3588-
legacy/board-makefile-add-h88k.patch
        mkdir -p arch/arm64/boot/dts/rockchip/
        wget https://github.com/amazingfate/armbian-h88k-
images/raw/master/rk3588-h88k.dts -0 arch/arm64/boot/dts/rockchip/rk3588-
h88k.dts
        git diff --no-index --output=./patch/kernel/rockchip-rk3588-
legacy/board-dts-add-h88k.patch /dev/null arch/arm64/boot/dts/rockchip/rk3588-
h88k.dts || ls -l ./patch/kernel/rockchip-rk3588-legacy/board-dts-add-h88k.patch
        wget https://github.com/amazingfate/armbian-h88k-
images/raw/master/h88k.csc -O config/boards/h88k.csc
        cp -r patch/u-boot/legacy/board_rock-5b patch/u-boot/legacy/board_h88k
        sed -i "s|# CONFIG_SENSORS_PWM_FAN is not
set|CONFIG_SENSORS_PWM_FAN=y|g" config/kernel/linux-rockchip-rk3588-
legacy.config
        sed -i "s|ext4|fat|g" config/boards/rock-5b.wip
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/backport-v6.0.16.patch -0 patch/kernel/archive/rk35xx-
5.10/backport-6.0.16.patch
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/board-add-hinlink-h6xk-makefile.patch -0
patch/kernel/archive/rk35xx-5.10/board-add-hinlink-h6xk-makefile.patch
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/rk3568-hinlink-h6xk.dtsi -0
arch/arm64/boot/dts/rockchip/rk3568-hinlink-h6xk.dtsi
```

```
wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/rk3568-hinlink-h66k.dts -0
arch/arm64/boot/dts/rockchip/rk3568-hinlink-h66k.dts
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/rk3568-hinlink-h68k.dts -0
arch/arm64/boot/dts/rockchip/rk3568-hinlink-h68k.dts
        git diff --no-index --output=./patch/kernel/archive/rk35xx-5.10/rk3568-
dtsi-add-hinlink-h6xk.patch /dev/null arch/arm64/boot/dts/rockchip/rk3568-
hinlink-h6xk.dtsi || ls -l ./patch/kernel/archive/rk35xx-5.10/rk3568-dtsi-add-
hinlink-h6xk.patch
        git diff --no-index --output=./patch/kernel/archive/rk35xx-5.10/board-
dts-add-hinlink-h66k.patch /dev/null arch/arm64/boot/dts/rockchip/rk3568-
hinlink-h66k.dts || ls -l ./patch/kernel/archive/rk35xx-5.10/board-dts-add-
hinlink-h66k.patch
        git diff --no-index --output=./patch/kernel/archive/rk35xx-5.10/board-
dts-add-hinlink-h68k.patch /dev/null arch/arm64/boot/dts/rockchip/rk3568-
hinlink-h68k.dts || ls -l ./patch/kernel/archive/rk35xx-5.10/board-dts-add-
hinlink-h68k.patch
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/linux-rk35xx-legacy.config -0 config/kernel/linux-rk35xx-
legacy.config
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/hinlink-h66k.conf -O config/boards/hinlink-h66k.conf
        wget https://github.com/amazingfate/armbian-h68k-
images/raw/master/hinlink-h68k.conf -O config/boards/hinlink-h68k.conf
        git status
# 需要打自己的补丁和内核config的参考以上指令
```

• 修改armbian-rock5b-images的build.yml

BOARD: [rock-5b]
DISTRO: [armbian]
FLAVOR: [ubuntu]
BRANCH: [legacy]
修改以上四个参数

push触发action构建,开始构建系统然后上传release

七.其他问题与参考资料

Docker不能使用

```
sudo update-alternatives --set iptables /usr/sbin/iptables-legacy
sudo update-alternatives --set ip6tables /usr/sbin/ip6tables-legacy
```

或者参考文档勾选相关选项编译内核替换

内核编译

Firefox主页问题

修改配置文件

/usr/lib/firefox-esr/mozilla.cfg

<u>5b主线内核进度</u>

kevinxiasx的wiki git仓库

ffmpeg**补丁**

USB电流限制



怕电流太大可以拿铅笔涂一涂测一测,电流小就多涂点,电流大就橡皮擦一擦