

Multi-frequency Crystal Core Scale Prevention System

Selection, installation position and flow direction · Подбор, место установки и направление потока

01	Confirm pipe diameter Match the product model to the pipe diameter at the installation point.
02	Choose the installation point Install at the protected equipment inlet or after the shut-off valve at the pump outlet.
03	Check flow direction The arrow on the device body must align with the direction of water flow.
04	Plan circulating-water treatment Install on return-water and make-up-water lines. Treat make-up water before it enters the circuit.
05	Treat before heating The supplied material recommends treating ambient-temperature water before heating. Special water requires customized selection.

Installation checklist

01	Pipe diameter and selected model match.
02	Installation point is before the protected equipment or after the pump outlet shut-off valve.
03	Body arrow and water-flow direction are the same.
04	Return and make-up lines are covered where required.
05	Make-up water is treated before entering the circulating system.
06	Ambient-temperature water is treated before heating.
07	Special water conditions have been reviewed for customized selection.

Operating conditions

Water temperature	Flow velocity	Pressure options
5-85°C	0.5-2.0 m/s	1.0 / 1.6 / 2.5 MPa

This guide reproduces installation requirements from the supplied company materials. Confirm the final arrangement against actual project conditions.