# H3C MSR 系列路由器内网用户通过 NAT 地址 访问地址重叠的外网典型配置举例(V7)



# 目 录

1 简	i介	٠1
2 酝	置前提	٠1
3 酢	置举例	٠1
	3.1 组网需求	. 1
	3.2 配置思路	. 1
	3.3 使用版本	. 2
	3.4 配置步骤	. 2
	3.5 验证配置	. 3
	3.6 配置文件	. 4
4 框	关资料	. 5

## 1 简介

本文档介绍 MSR 系列路由器内网用户通过 NAT 地址访问地址重叠的外网典型配置举例。

## 2 配置前提

本文档适用于使用 Comware V7 软件版本的 MSR 系列路由器,如果使用过程中与产品实际情况有差异,请参考相关产品手册,或以设备实际情况为准。

本文档中的配置均是在实验室环境下进行的配置和验证,配置前设备的所有参数均采用出厂时的缺省配置。如果您已经对设备进行了配置,为了保证配置效果,请确认现有配置和以下举例中的配置不冲突。


本文档假设您已了解 NAT 特性。

### 3 配置举例

#### 3.1 组网需求

如 <u>图 1</u>所示,Router作为某公司内网访问外网的网关,内网网段与外网Web server所在网段地址重叠。该公司拥有 202.38.1.2 和 202.38.1.3 两个公网地址。现要求Host可以通过域名访问外网的Web server。

图1 内网用户通过 NAT 地址访问地址重叠的外网典型配置组网图



### 3.2 配置思路

- 由于外网 DNS 服务器回复给内网主机的 Web 服务器地址与内网主机地址重叠,因此 NAT 设备需要将 Web 服务器地址转换为动态分配的一个 NAT 地址。动态地址分配可以通过入方向动态地址转换实现,地址转换需要通过 DNS ALG 功能实现。
- 由于内网主机的地址与外网 Web 服务器的真实地址重叠,因此也需要为内网主机动态分配一个的 NAT 地址,可以通过出方向动态地址转换实现。

外网 Web 服务器对应的 NAT 地址在 NAT 设备上没有路由, 因此需要手工添加静态路由。

#### 3.3 使用版本

本举例是在 R0106 版本上进行配置和验证的。

#### 3.4 配置步骤

# 配置路由器各接口的 IP 地址。

<Router> system-view

[Router] interface gigabitethernet 1/1

[Router-GigabitEthernet1/1] ip address 192.168.1.1 24

[Router-GigabitEthernet1/1] quit

[Router] interface gigabitethernet 1/2

[Router-GigabitEthernet1/2] ip address 10.0.1.1 24

[Router-GigabitEthernet1/2] quit

# 开启 DNS 协议的 ALG 功能。

[Router] nat alg dns

#配置 ACL 2000, 仅允许对 192.168.1.0/24 网段的用户报文进行地址转换。

[Router] acl number 2000

[Router-acl-basic-2000] rule permit source 192.168.1.0 0.0.0.255

[Router-acl-basic-2000] quit

#创建地址组1。

[Router] nat address-group 1

#添加地址组成员 202.38.1.2。

[Router-nat-address-group-1] address 202.38.1.2 202.38.1.2

[Router-nat-address-group-1] quit

#创建地址组2。

[Router] nat address-group 2

#添加地址组成员 202.38.1.3。

[Router-nat-address-group-2] address 202.38.1.3 202.38.1.3

[Router-nat-address-group-2] quit

#在接口 GigabitEthernet1/2 上配置入方向动态地址转换,允许使用地址组 1 中的地址对 DNS 应答报文载荷中的外网地址进行转换,并在转换过程中不使用端口信息,以及允许反向地址转换。

[Router] interface gigabitethernet 1/2

[Router-GigabitEthernet1/2] nat inbound 2000 address-group 1 no-pat reversible

# 在接口 GigabitEthernet1/2 上配置出方向动态地址转换,允许使用地址组 2 中的地址对内网访问外网的报文进行源地址转换,并在转换过程中使用端口信息。

[Router-GigabitEthernet1/2] nat outbound 2000 address-group 2

[Router-GigabitEthernet1/2] quit

# 配置静态路由,目的地址为外网服务器 NAT 地址 202.38.1.2, 出接口为 GigabitEthernet1/2, 下一跳地址为 10.0.1.1。

[Router] ip route-static 202.38.1.2 32 gigabitethernet 1/2 10.0.1.1

#### 3.5 验证配置

# 以上配置完成后,Host 能够通过域名访问 Web server。在路由器上通过 display nat all 命令显示 NAT 配置信息。

[Router] display nat all

NAT address group information:

There are 2 NAT address groups.

Address group 1:

Address information:

Address group 2:

Address information:

Start address End address 202.38.1.3 202.38.1.3

NAT inbound information:

There are 1 NAT inbound rules. Interface: GigabitEthernet1/2

ACL: 2000 Address group: 1 Add route: N

NO-PAT: Y Reversible: Y

NAT outbound information:

There are 1 NAT outbound rules.

Interface: GigabitEthernet1/2

ACL: 2000 Address group: 2 Port-preserved: N

NO-PAT: N Reversible: N

NAT logging:

Log enable : Disabled Flow-begin : Disabled Flow-end : Disabled Flow-active : Disabled Port-block-assign : Disabled Port-block-withdraw : Disabled Alarm : Disabled

NAT mapping behavior:

Mapping mode: Address and Port-Dependent

ACL : ---

NAT ALG:

DNS : Enabled
FTP : Enabled
H323 : Enabled
ICMP-ERROR : Enabled
ILS : Enabled

```
: Enabled
MGCP
NBT
         : Enabled
PPTP
          : Enabled
RSH
          : Enabled
         : Enabled
RTSP
          : Enabled
SCCP
SIP
          : Enabled
          : Enabled
SOLNET
TFTP
          : Enabled
          : Enabled
XDMCP
```

# 通过 display nat session verbose 命令显示 NAT 会话的详细信息,可以看到 Host 访问 Web server 时生成 NAT 会话信息。

```
[Router] display nat session verbose
Initiator:
              IP/port: 192.168.1.10/1694
  Source
 Destination IP/port: 202.38.1.2/8080
 VPN instance/VLAN ID/VLL ID: -/-/-
  Protocol: TCP(6)
Responder:
  Source
              IP/port: 192.168.1.10/8080
  Destination IP/port: 202.38.1.3/1025
 VPN instance/VLAN ID/VLL ID: -/-/-
  Protocol: TCP(6)
State: TCP_ESTABLISHED
Application: HTTP
Start time: 2013-08-15 14:53:29 TTL: 3597s
Interface(in) : GigabitEthernet1/1
Interface(out): GigabitEthernet1/2
Initiator->Responder:
                                 7 packets
                                                  308 bytes
Responder->Initiator:
                                 5 packets
                                                  312 bytes
Total sessions found: 1
```

#### 3.6 配置文件

```
#
interface GigabitEthernet1/1
port link-mode route
ip address 192.168.1.1 255.255.255.0
#
interface GigabitEthernet1/2
port link-mode route
ip address 10.0.1.1 255.255.255.0
nat inbound 2000 address-group 1 no-pat reversible
nat outbound 2000 address-group 2
#
ip route-static 202.38.1.2 32 GigabitEthernet1/2 10.0.1.1
#
```

```
acl number 2000
  rule 0 permit source 192.168.1.0 0.0.0.255
#
nat address-group 1
  address 202.38.1.2 202.38.1.2
#
nat address-group 2
  address 202.38.1.3 202.38.1.3
#
```

## 4 相关资料

- 《H3C MSR 系列路由器 配置指导(V7)》中的"三层技术-IP 业务配置指导"
- 《H3C MSR 系列路由器 命令参考(V7)》中的"三层技术-IP业务命令参考"