

Before you return the camera, make sure you transfer your data and format the SD card.

## Format SD card - DC-S5M2(X)

Press [ MENU ].

Select [ **SETUP** ].

Select [ Card/File ].

Select [ Card Format ].

Select [ Slot1 or Slot 2 ].

Select [ YES ].