Power Supply











external PLL ground connection (GNDPLL) must NOT be connected to the board's ground.



Clock



Programming



FPGA











Peripherals









FLASH

16Mb FLASH supports 0Bh fast read





pullup on ss means configure as SPI master to read configuration from FLASH at boot

things to check:
clock and reset gbin, will pll be ok?
flash - pullups needed?
check fpga pinout against lattice docs

Sheet: /
File: first-fpga-pcb.sch

Title: Matt-FPGA

Size: A3	Date: 2019-12-30	**Rev: 0.1**
KiCad E.D.A. kicad 5.1.5-52549c584ubuntu18.04.1		Id: 1/1