-DESSAINTES' DISASSEMBLER-

- 1) Initialize RAE: Enter, SEt (as needed) then A) CLear, B) assemble the 1-line prog. "1 .en", C) CLear (again), D) exit to monitor.
- Initialize the disassembler: Enter ".SD 9000, A66A (cr).
- 3) Start disassembly with the following command string: -.n <a>>, b, c, d-

n=1 (1st pass) 2 (2nd pass) 3 (both passes) or 5,6,7 (same as 1,2,3 but with sort if label file not empty).

a=from LOCATION COUNTER (.MC) - optional.

b=from PROGRAM COUNTER (.BA).

c=to PROGRAM COUNTER

d=L(labels only), P(printer), or T(text & labels in RAE).

- 4) When prompted with "." re-enter RAE with ".g". Your disassembled file with labels is now in RAE.
- codes preceeding labels: A
 absolute, B
 branch, J
 jump,
 S
 scient, B
 <a href="mailto:scien

LUX'S NOTES FOR DESSAINTES' DISASSEMBLER:

1) I believe that the following steps are required for INITIALIZATION:

After SEttins, enter CLear <cr>
 Assemble the program 1 .EN to initialize the EOLF pointer CLear <cr>
 to reinitialize the EOTF pointer Do CTRL C to exit to monitor Enter .SD ENTRY, A66A <cr>
 Proceed

- 2) Not all features of this program have been tested, those which have been tested do work correctly.
- 3) All instructions for running this program are given at the beginning of PART1 (FO1) of the Source Code.
- 4) The cassette contains three copies each of three RAE source code files, FO1 (\$0200-\$237E), FO2 (\$0200-\$1693), and FO3 (\$0200-\$2AED), to be assembled with .CT.
- 5) With a 32K system the files may be combined into one, but remember to delete the duplicate set of macros in PART3.

2/22/82 - LUX

```
0010 (NOTES TO ACCOMPANY DESSAINTES' DISASSEMBLER CASSETTE
0020 #22 MARCH 1982 - SYM USERS' GROUP
0030
0040
0050 FNOTE 1: THE FOLLOWING PATCH WILL ELIMINATE
0060 FTHE NEED TO INITIALIZE RAE WITH THE
0070 JASSEMBLY OF A NULL PROGRAM, THE CLEAR,
0080 ;ETC. IT ALSO DOES THE ".SD" BIT FOR
0090 FYOU AS WELL. HOW LAZY CAN ONE BE?
0100
0110 ; NOTE 2: THERE IS A TYPO IN THE SOURCE CODE,
0120 FIN THE EXPLANATION OF V, P, AND T!!!!!!!!
0130 IT MEANS TEXT FILE, AND NOT TAPE. USE T AS
0140 THE FINAL PARAMETER IF YOU WISH TO HAVE
0150 | THE DISASSEMBLER PREPARE A RAE SOURCE FILE
0160 FOR YOU. OTHERWISE YOU WILL NOT GET A FILE.
0170
0180 (NOTE 3: TO USE THE DISASSEMBLER, ENTER RAE
0190 JAND SET YOUR TEXT AND LABEL BOUNDARIES.
0200 FEXIT RAE WITH A CTRL C. FROM SUPERMON
           .G (ADDRESS OF PATCH) <CR>
0210 #
0220 FTHEN FOLLOW DESSAINTE'S INSTRUCTIONS.
0230
0240 ;NOTE 4: FOR THOSE WITH FODS, THE FODS DISK
0250 $LINKAGE IS ALSO INCLUDED.
0260
0270
0280
0290 #PATCH TO "AUTOMATE" DESSAINTES'
0300 #DISASSEMBLER INITIALIZATION
0310
0320 FADDITIONAL SUPERMON/SYSRAM VALUES
0330
0340 ACCESS .DE $8886
0350 URSVEC . DE $A669
0360
0370 FDDS .DE 0
0380
0390
0400 PATCH
0410 ;
                    .BA ANYWHERE
0420
0430 IFN FODS
0440
0450 FNEXT SIX LINES ONLY FOR FODS SYSTEMS
0460
0470 TURNOFF .DE $20
0480 DSKRW .DE $765D
0490 SET2 .DE $7634
0500
0510
     LDA #TURNOFF
0520 JSR DSKRW
0530 JSR SET2
0540
0550 ***
0560
0570 FINITIALIZE THE CURRENT FILE POINTERS
```

```
0580 #TO EQUAL START-OF-FILE (SOF) VALUES
                0590
                0600 FTEXT FILE
0200- AD 00 01
                0610
                     LDA $0100
0203- AE 01 01
                0620
                     LDX $0101
                0630
0206- 85 D3
                0640 STA *$D3
                     STX *$D4
0208- 86 D4
                0650
                0660
                0670 FLABEL FILE
020A- AD 04 01
                0680 LDA $0104
                0690 LDX $0105
020D- AE 05 01
                0700
0210- 85 D5
                0710 STA **D5
0212- 86 D6
                0720 STX *$D6
                0730
                0740 FPLACE EOF MARKERS IN BOTH FILES
                0750 $SET THIRD BYTE IN TO NULL VALUE
                0760
0214- A9 00
                0770 LDA #$00
                0780 LDY #$02
0216- A0 02
                0790
0218- 91 D3
                0800 STA ($D3),Y
021A- 91 D5
                0810
                     STA ($D5),Y
                0820
                0830 #PATCH IN UNRECOGNIZED SYNTAX VECTOR
                0840
021C- 20 86 8B
                0850 JSR ACCESS
                0860
021F- A9 2A
                0870
                      LDA #L,DISASSEMBL
0221- A2 02
                0880 LDX #H,DISASSEMBL
                0890
0223- 8D 6A A6
               0900 STA URSVEC+1
0226- 8E 6B A6
                0910 STX URSVEC+2
                0920
0229- 60
                0930 RTS
                0940
                0950 #CAN USE "BRK" ABOVE INSTEAD OF
                0960 #THE "RTS" IN THE FODS VERSION
                0970
                0980 #CONTINUE WITH DESSAINTES' PROGRAM
                0990
                1000 ;
                                    .BA WHEREVER
                1010
022A- 48
                1020 DISASSEMBL PHA
022B- C9 31
                1030 CMP #'1
                1040 FETCETERA
                1050
                      . EN
```

LABEL FILE: [/ = EXTERNAL]

/ACCESS=8B86 PATCH=0200 //0000,022D,022D /URSVEC=A669 DISASSEMBL=022A /FODS=0000