

- C1 E.F.I. Engine Coolant Temperature Sensor
- C2 Crank Position Sensor
- C3 Intake Mass Air Flow Meter Sub-Assembly
- C4 Throttle Body with Motor Assembly
- C5 Ignition Coil Assembly No. 1
- C6 Ignition Coil Assembly No. 3
- C7 Ignition Coil Assembly No. 5
- C8 Fuel Injector Assembly No. 1
- C9 Fuel Injector Assembly No. 3
- C10 Radio Setting Condenser (Ignition)
- C11 Fuel Injector Assembly No. 5
- C12 Ignition Coil Assembly No. 6
- C13 Ignition Coil Assembly No. 4
- C14 Ignition Coil Assembly No. 2
- C15 Purge VSV
- C16 Fuel Injector Assembly No. 6
- C17 No. 2 Oxygen Sensor (Bank 2 Sensor 2)
- C18 Oxygen Sensor (Bank 1 Sensor 2)
- C19 No. 2 Air Fuel Ratio Sensor (Bank 2 Sensor 1)
- C20 Fuel Injector Assembly No. 2
- C21 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
- C22 VVT Sensor (Bank 2)
- C23 Magnet Clutch Assembly
- C24 VVT Sensor (Bank 1)
- C25 Fuel Injector Assembly No. 4
- C26 Cam Timing Oil Control Valve Assembly LH (Bank 2)
- C27 Cam Timing Oil Control Valve Assembly RH (Bank 1)
- C28 Power Steering Oil Pressure Switch
- C29 Oil Pressure Sender Gage Assembly
- C30 Engine Oil Pressure Switch Assembly
- C31 Fuel Pump
- C32 Back-Up Light Switch Assembly
- C35 Center Differential Lock Indicator Switch (No. 1 Transfer Indicator Switch)
- C36 Transfer L4 Position Switch (No. 1 Transfer Indicator Switch)
- C37 No. 1 Vacuum Switching Valve (ACIS)
- C38 No. 4 Junction Connector
- C39 ECM
- C96 Speedometer Sensor
- C97 Fuel Sender Gage Assembly (Front)
- C104 Purge VSV
- C105 Oil Pressure Sender Gage Assembly



