RHYTHM COMPOSER Model: TR-09

## MIDI Implementation Chart

Date: Aug. 30, 2016 Version 1.00

Function		Transmitted	Recognized	Remarks
Basic	Default	10	10	Memorized
Channel	Changed	1-16, OFF	1-16, OFF	
	Default	Mode 3	Mode 3	
Mode	Messages	x	x	
	Altered	*****	*****	
Note		*1	*2	
Number	: True Voice	*****		
Velocity	: Note On	o 9nH v=80	0	
	: Note Off	o 8nH v=00	0	
After	Key's	x	x	
Touch	Channel's	x	x	
Pitch Bend		x	X	
		x	0	SHUFFLE BD TUNE
	20 21		0	BD ATTACK
	22		0	BD COMP
	23		0	BD DECAY
	24		0	BD LEVEL
	25		0	SD TUNE
	26		0	SD SNAPPY
	27		0	SD COMP
	28		0	SD TONE
	29		0	SD LEVEL
	46	l .	0	LT TUNE
	47 48		0	LT DECAY LT LEVEL
	48		0	MT TUNE
	50		0	MT DECAY
	51		0	MT LEVEL
	52		0	HT TUNE
Combine	53		0	HT DECAY
Control Change	54		0	HT LEVEL
Change	55		0	RS TUNE
	56		0	RS DECAY
	57		0	RS LEVEL
	58 59		0	HC TUNE HC DECAY
	60		0	HC LEVEL
	61		0	CH TUNE
	62		0	CH DECAY
	63		0	CH LEVEL
	71	0	0	TOTAL ACCENT
	80		0	OH TUNE
	81		0	OH DECAY
	82		0	OH LEVEL
	83		0	CC TUNE
	84 85		0	CC DECAY
	86		0	RC TUNE
	87		0	RC DECAY
	88		0	RC LEVEL
Program		x	x	
Change	: True Number	*****	*****	
System Exclusive		x	x	
BYCTUSTAG	: Song Position	0	0	
System	: Song Position : Song Select	0 0-7	0 0-7	
Common	: Tune Request	x	x	
	: Clock	0	0	
System	: Start	0	0	
Real Time	: Continue	0	0	
	: Stop	0	0	
	: All Sound Off	0	0	Transmitted: MIDI OFFLINE
	: Reset All Controllers	0	0	Transmitted: MIDI OFFLINE
	: Local On/Off	x	x	
Aux Messages	: All Notes Off	0	0	Transmitted: MIDI OFFLINE
	: Omni Mode Off	x	0	*3
	: Omni Mode On	x 	0	*3
	: Mono Mode On : Mono Mode Off	x	0	*3 *3
	: Mono Mode OII : Active Sensing	x o	0	· · J
	: Active Sensing : System Reset	x	x	
Notes			I	I
wores.	*3 Same process as All I	Note Uii.		

Mode 1: OMNI ON, POLY Mode 2: OMNI ON, MONO Mode 3: OMNI OFF, POLY Mode 4: OMNI OFF, MONO

O : Yes X : No

=	
Inst.	Note Number
BASS DRUM	36
SNARE DRUM	38
LOW TOM	43
MID TOM	47
HIGH TOM	50
RIM SHOT	37

Inst.	Note Number
HAND CLAP	39
CLOSED HI-HAT	42
OPEN HI-HAT	46
CRASH CYMBAL	49
RIDE CYMBAL	51

\*2

Inst.	Note Number
BASS DRUM	35,36
SNARE DRUM	38,40
LOW TOM	41,43
MID TOM	45,47
HIGH TOM	48,50
RIM SHOT	37

Inst.	Note Number
HAND CLAP	39
CLOSED HI-HAT	42,44
OPEN HI-HAT	46
CRASH CYMBAL	49
RIDE CYMBAL	51