LoRaWAN 商业网关

MQTT Bridge 功能

应用笔记

版本 1.1 | 2019年9月



目录

1 概述	2
2 登录网关	2
3 下载安装 ChirpStack 及其依赖软件 Mosquitto / Redis / PostgreSQL	4
4 LoRa Gateway MQTT Bridge 配置	5
4.1 MQTT&Broker	5
4.2 生成证书	6
4.3 配置 Mosquitto 证书	6
4.4 配置 ChirpStack 证书	7
4.5 使能&配置 MQTT Bridge	8
4.6 Mosquitto_Sub 订阅网关消息	11
4.7 查看 ChirpStack 上订阅的消息	12
5 联系方式	12
6 修订历史	13
7 文档概要	13



1 概述

在产品应用中,MQTT 在物联网领域越来越占主导地位,更多的需求或者已经实现的应用服务器已经支持了 MQTT 协议,LoRaWAN 网关增加该功能也就顺应而生。

RAK 网关标准固件集成了 MQTT Bridge 功能,让用户自行选择使用 UDP(例如 TTN 服务器)或 MQTT(例如 ChirpStack 服务器)协议转发数据到指定的 Netwrork Server 服务器。

本文档适用于我司商业类 LoRaWAN 网关产品如室外型网关 RAK7249,室内型网关 RAK7248,其中主要针对性地讲解了如何使用 MQTT Bridge 中的服务器&客户端双向认证的模式,在自己的服务器(ChirpStack 服务器)上订阅网关的消息。

2 登录网关


通过浏览器直接访问网页,需要通过 IP 地址来直接访问。

1. 网关在上电之后会自动创建 AP 热点,您可以直接电脑搜索链接对应的 AP 热点,AP 热点以产品型号开头,后缀是设备 MAC 地址后四位。AP 热点默认不加密,直接链接之后,通过浏览器访问 http://192.168.230.1/。






2. 您还可以通过网线直接链接路由器 之后登陆路由器可以获取当前的设备的 IP 地址。通过该 IP 地址也可以直接访问内置网页。



通过以上方法打开网页。

注意: 当前页面采用 HTTPS 协议,个别浏览器会提醒不安全,直接继续访问即可。





您的连接不是私密连接

攻击者可能会试图从 **192.168.8.108** 窃取您的信息(例如:密码、通讯内容或信用卡信息)。 <u>了解详情</u>

NET::ERR_CERT_AUTHORITY_INVALID

☑ 您可以选择向 Google 发送一些<u>系统信息和网页内容</u>,以帮助我们改进安全浏览功能。 <u>隐</u> 私权政策

隐藏详情

返回安全连接

此服务器无法证明它是**192.168.8.108**;您计算机的操作系统不信任其安全证书。出现此问题的原因可能是配置有误或您的连接被拦截了。

继续前往192.168.8.108 (不安全)

通过浏览器打开页面之后,需要输入用户名和密码。用户名和密码默认都是 root 。

3 下载安装 ChirpStack 及其依赖软件 Mosquitto / Redis / PostgreSQL


下载地址和安装步骤请参照 https://www.ChirpStack.io/ 的安装介绍。

然后还需要在 ChirpStack 上添加测试用的网关。




4 LoRa Gateway MQTT Bridge 配置

登录网关 WEB 界面后进入 LoRa Gateway-> LoRa Gateway MQTT Bridge 界面,如下图 所示:



4.1 MQTT&Broker

MQTT 是 IBM 开发的一个即时通讯协议。MQTT 是面向 M2M 和物联网的连接协议,采用 轻量级发布和订阅消息传输机制。Mosquitto 是一款实现了 MQTT v3.1 协议的开源消息 代理软件,提供轻量级的,支持发布/订阅的的消息推送模式,使设备对设备之间的短消息 通信简单易用。关于更多 MQTT 请访问:http://mqtt.org/;关于更多 Mosquitto 信息请访问:https://mosquitto.org/。





4.2 生成证书

生成证书,需要以下脚本文件,您可以直接从我司官网下载:

generate_CA.sh:

https://downloads.rakwireless.com.cn/cn/LoRa/Indoor-Gateway-RAK7258/B%E5%9 B%BA%E4%BB%B6/

1. 登录到 ubuntu, 切换到 root 用户,并切换到用户根目录,将 generate_CA.sh 拷贝到 当前目录。

su root

cd ∼

chmod +x generate_CA.sh

2. 生成 CA 证书以及和 Mosquitto Server 证书。

./generate_CA server

3. 生成 ChirpStack 的 TLS 证书和密钥。

./generate_CA client ChirpStack

4. 生成 LoRaGateway 的 TLS 证书和密钥,此处 eui_60c5a8fffe6f74a0 为证书名称,您可 以自行设置,建议以设备 eui 做区分。

./generate_CA client eui_60c5a8fffe6f74a0

5. 导出所有证书备用。

4.3 配置 Mosquitto 证书

1. 将 CA 证书和 server 证书及密钥拷贝到 /etc/mosquitto/certs 目录

```
cp ~/ca.* server.* /etc/mosquitto/certs
```

2. 在/etc/mosquito/mosquitto.conf 增加下列内容(使用 linux 系统 VIM 编辑器修改,如果有疑问请百度)

```
port 8883

cafile /etc/mosquitto/certs/ca.crt

certfile /etc/mosquitto/certs/server.crt

keyfile /etc/mosquitto/certs/server.key

require_certificate true

tls_version tlsv1
```

3. 重启 mosquitto

systemctl restart mosquito

4.4 配置 ChirpStack 证书

1. 将 CA 证书和 ChirpStack TLS 证书和密钥拷贝到 /etc/ChirpStack

```
cp ~/ChirpStack.* /etc/ChirpStack
cp ~/ca.crt /etc/ChirpStack
```

2. 修改 /etc/ChirpStack/ChirpStack.toml 的 network_server.gateway.backend

部分(使用 linux 系统 VIM 编辑器修改,如果有疑问请百度)。

```
# absolutely needed.
# Use "{{ .MAC }}" as an substitution for the LoRa gateway MAC.
uplink_topic_template="gateway/+/rx"
downlink_topic_template="gateway/{{ .MAC }}/tx"
stats_topic_template="gateway/+/stats"
ack_topic_template="gateway/+/ack"
config_topic_template="gateway/{{ .MAC }}/config"

# MQTT server (e.g. scheme://host:port where scheme is tcp, ssl or ws)
server="ssl://127.0.0.1:8883"

# Connect with the given username (optional)
username=""
```

```
# absolutely needed.

# Use "{{ .MAC }}" as an substitution for the LoRa gateway MAC.

uplink_topic_template="gateway/+/rx"

downlink_topic_template="gateway/{{ .MAC }}/tx"

stats_topic_template="gateway/+/stats"

ack_topic_template="gateway/+/ack"

config_topic_template="gateway/{{ .MAC }}/config"

# MQTT server (e.g. scheme://host:port where scheme is tcp, ssl or ws)

server="ssl://127.0.0.1:8883"
```

```
# but the certificate used by the server is not trusted by any CA certificate
# on the server (e.g. when self generated).
ca_cert="/etc/loraserver/ca.crt"

# TLS certificate file (optional)
tls_cert="/etc/loraserver/loraserver.crt"

# TLS key file (optional)
tls_key="/etc/loraserver/loraserver.key"
```

```
# on the server (e.g. when self generated).
ca_cert="/etc/ChirpStack/ca.crt"

# TLS certificate file (optional)
tls_cert="/etc/ChirpStack/ChirpStack.crt"

# TLS key file (optional)
tls_key="/etc/ChirpStack/ChirpStack.key"
```


3. 重启 ChirpStack

systemctl restart ChirpStack


4.5 使能&配置 MQTT Bridge

1. 配置 LoRa Packet Forwarder Protocol 为 LoRa Gateway MQTT Bridge 并保存。






2. 配置 LoRa Gateway MQTT Bridge



如上图所示打开 Enable,修改 MQTT Broker Address/Port, SSL/TLS Mode 选择 Self-signed server & client certificate, TLS Version 和 mosquitto tls_version 保持一致 (TLSv1)。

将 server 中 ~/ca.crt 中的内容拷贝到 CA Certificate 中 , ~/eui_60c5a8fffe6f74a0.crt 的内容拷贝到 TLS Certificate 中 , 将 ~/eui_60c5a8fffe6f74a0.key 的内容拷贝到 TLS Key 中。保存并应用。

3. 配置 MQTT Topic,注意应该与 ChirpStack.toml 中的保持格式一致。



注意:此处网页的配置必须要确保和 ChirpStack 配置的参数一致(网关中的{{eui}} 等效 ChirpStack 中的{{.MAC}}, 自适应当前网关的 EUI)。

```
# absolutely needed.

# Use "{{ .MAC }}" as an substitution for the LoRa gateway MAC.

uplink_topic_template="gateway/+/rx"

downlink_topic_template="gateway/{{ .MAC }}/tx"

stats_topic_template="gateway/+/stats"

ack_topic_template="gateway/+/ack"

config_topic_template="gateway/{{ .MAC }}/config"

# MQTT server (e.g. scheme://host:port where scheme is tcp, ssl or ws)

server="ssl://127.0.0.1:8883"

# Connect with the given username (optional)

username=""
```

4.6 Mosquitto Sub 订阅网关消息

```
mosquitto_sub -t "gateway/#" -p 8883 -v --cafile \sim/ca.crt --cert \sim/eui_60c5a8fffe6f74a0.crt --key eui_60c5a8fffe6f74a0.key --tls-version tlsv1
```


如果出现到类似下面的消息,说明 LoRaGatway 已经正常连接到 MQTT Broker

```
gateway/60c5a8fffe6f74a0/rx
"rxInfo": {"mac": "60c5a8fffe6f74a0", "timestamp": 2036224996, "frequency": 905300000, "channel": 7, "rfChai
spreadFactor":7,"bandwidth":125},"board":0,"antenna":0},"phyPayload":"gC5K1gGASwIFAUrhF/nr2MDyWN
XIw9L4"}
        gateway/60c5a8fffe6f74a0/tx
{"token":35594,"txInfo":{"mac":"60c5a8fffe6f74a0","immediately":false,"timestamp":2037224996,"frequen
cy":927500000,"power":20,"dataRate":{"modulation":"LoRa","spreadFactor":7,"bandwidth":500},"codeRate":
"4/5", "iPol": true, "board": 0, "antenna": 0}, "phyPayload": "YC5K1gGgOQI9VpIf"}
        gateway/60c5a8fffe6f74a0/ack {"mac":"60c5a8fffe6f74a0","token":35594}
        gateway/60c5a8fffe6f74a0/stat
{"mac":"60c5a8fffe6f74a0","time":"2019-04-02T07:18:54Z","rxPacketsReceived":5,"rxPacketsReceivedOK":
3,"txPacketsReceived":3,"txPacketsEmitted":3}
        gateway/60c5a8fffe6f74a0/rx
"rxInfo": {"mac": "60c5a8fffe6f74a0", "timestamp": 2046166763, "frequency": 904100000, "channel": 1, "rfChai
n":0,"crcStatus":1,"codeRate":"4/5","rssi":-21,"LoRaSNR":9.8,"size":17,"dataRate":{"modulation":"LoRa","s
preadFactor":7,"bandwidth":125},"board":0,"antenna":0},"phyPayload":"gC5K1gGATAID1VoTFGxWaz8="}
         gateway/60c5a8fffe6f74a0/tx
{"token":19073,"txInfo":{"mac":"60c5a8fffe6f74a0","immediately":false,"timestamp":2047166763,"frequen
\verb|cy":923900000, \verb|power":20|, \verb|dataRate":{|modulation":|LoRa||, \verb|spreadFactor":7|, \verb|bandwidth||:500||, \verb|codeRate||:1|, codeRate||:1|, codeRate|
"4/5","iPol":true,"board":0,"antenna":0},"phyPayload":"YC5K1gGgOgLJfJ+g"}
         gateway/60c5a8fffe6f74a0/ack {"mac":"60c5a8fffe6f74a0","token":19073}
```



4.7 查看 ChirpStack 上订阅的消息

打开 ChirpStack 的 Web 页面,进入网关 LIVE LoRaWAN FRAMES,如下图所示。



5 联系方式

如果您有任何疑问请访问 RAK 官方论坛获取帮助,或者您也可以通过以下邮箱联系我们。

RAK 论坛: https://forum.rakwireless.com/

邮箱: info@rakwireless.com



6修订历史

版本	描述	日期
1.0	创建文档	2019-05-29
1.1	修改 ChirpStack 部分,更新图片	2019-09-06

7 文档概要

准备	审核	发布
Penn	yutao	



关于瑞科慧联:

RAK 是一家专注于 IoT 领域以产品为驱动型的公司,凭借团队深厚的无线通讯技术领域的积累,采 用创新的商业模式高效地为全球中小型的网络运营商(Network Operator),系统集成商(System Integrator)和服务提供商(Service Provider)等提供高性能的 IoT 产品与应用方案。