```
follow below steps to disable HVDCP, to clear bit2 of 0x1362 1. in XBL: pm_driver_post_init(): +pm_comm_write_byte_mask(0, 0x1362, 0x04, 0, 0); //bit2
```

```
2. in HLOS: /drivers/power/supply/qcom/smb-lib.c static int smblib_hvdcp_enable_vote_callback(struct votable *votable,void *data,int hvdcp_enable, const char *client) {
...
--if (!hvdcp_enable)
--val = HVDCP_EN_BIT;
++val = 0;
...
}
```