\SSY REF	ASSEMBLY	DASH NO PAGE NO.
DES	ASSEMBL T	DASH NO PAGE NO.
ABA1	AC DISTRIBUTION	003
ABA3	EATHERNET HUB	003,009
ABA4A1	REAR UI INDICATORS	003,004.010
ABASA1	FRONT UI INDICATORS	003,004.010
ABA6	DC PWR SPLY NODE BO. UI DISPLAY	003,004,010
ABA7	DC PWR SPLY BROOKS, VTM & ATM	003,008
ASAS	UI COMPUTER	003,010
A8A10	EMO DISTRIBUTION	003,003-2
A8A11	UPS	003,010
ASAZ	ASSY, BOX AD JOT	003,003-2
A6A3	ASSY, LIGHT	003
A6A4	ASSY, IONIZER NAIN	003
ABAD	ASSY, IONIZER	003
ASAS	FILTER BLOWER	603
A7A4PM1	PM1 BULKHEAD	003-2,007
A7A4PM2	PW2 BULKHEAD	003-2,007
A7A4PM3	PA3 BULKHEAD	003-2.007
A7A4PM4	PM4 BULKHEAD	003-2.007
A40	ASSY, REMOTE PAR DIST BOX	003-2,007
A41	ASSY, IPX PUMP	003,005
A42	SHUTTLE PIMP	003,009
	ASSY, UPS MODULE	903
A43	ASSY, UPS MODULE	003
A8A2081	ASSY, PCB, RACK DISTRIBUTION	004.010
A5A1B1	ASSY, PCB, NOCE DUAL VALVE (PMI)	004,007,009
A5A2B1	ASSY, PCB, NOCE DUAL VALVE (PM2)	004,007,009
A5A3B1	ASSY, PCB, NODE DUAL VALVE (PM3)	004.007.00B
A5A481	ASSY, PCB. NODE DUAL VALVE (PM4)	004,007,009
ADADD I	VIM MOTHERBOARD	004
A5A2161	ASSY,POB,MODE DUAL VALVE (LL1)	004,007,009
A5A2281	ASSY, PCB, NODE DUAL VALVE (LL2)	004,007,009
ASA1B3	ASSY, PCB, LONWORKS HODE	004
A6A7	ASSY, BROOKS CONTROL ALIGNER	004,008
A9	ASSY,LOAD PORT 1	004
A10	ASSY, LOAD PORT 2	004
A5A6A1	PNEUMATIC BLOCK	005
A5A7	LL1 VAT DOOR	006
ASAB	LL2 VAT DOOR	005
A5A9A2	WATER FLOW SENSOR	005
ASA10	SENSOR, INSIDE LL1	005
A5A11	SENSOR, INSIDE LL1	
A5A12	SENSOR, INSIDE LL1	005 bgs
A5A13	SENSOR, INSIDE LL2	905
A5A14	SENSOR, OPTICAL, LL1A	005-2
A5A15	SENSOR, OPTICAL, LLZA	005-2
A5A16	SENSOR, OPTICAL, PNIA	005-2
A5A17	SENSOR, OPTICAL, PN2A	005-2
A5A18	SENSOR, OPTICAL, PN3A	005-2
ASA19	SENSOR, OPTICAL, PN4A	005-2
A5A30	SENSOR, OPTICAL, LL18	006-2
A5A31	SENSOR, OFFICAL, LLZB	005-2
A5A32	SENSOR, OPTICAL, PN18	005-3
A5A33	SENSOR, OPTICAL, PM28	005-3
A5A34	SENSOR, OPTICAL, PASE	005-3
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	materials per a theretal in 1999	000-0

SSY REF	ASSEMBLY	DASH NO, - PAGE NO.
DES	WATER DET. SENSOR	005
	WATER DET. SENSOR	005
AXAX	WATER DET. SENSOR	1 003
	PECTATOR CHARGE	205
AXAX	DECTECTOR, SMOKE	006
A5A9A4	SWITCH, He	006
A5A9A5	SWITCH, CDA	006
ASASAS	SWITCH, N2	006
SABA7 AXAX	ASSY, RESET SWITCH	006
A3A23	CONV. TM (ATM/VAC)	006
A5A24		006
A5A25	CONV. FORELINE (ATM/VAC)	
	CONV. LL1 (ATM/VAC)	006
A5A26	CONV. LL2 (ATM/VAC)	006
A5A27	CENTRAL ROBOT	004,006
A6A8 A6A10	LIGHT TOWER M/BUZZER (FRONT) MELODY BOX	008
ANAX ABA25	DECTECTOR, SMOKE	006
ABA11	LIGHT TOWER W/BUZZER (REAR)	006
A6A12	ASSY, COVER SWITCH	
	ASSY, COVER SWITCH	008
A6A17	MANUAL , ERGO	008
U6A18	MANUAL . ERGO	008
A6A19	ASSY,ATM BROOKS ROBOT	008
A6A20	ASSY, CA, AL IGNER	008
ASSIP1	ASSY, PCB, LOHWORKS, FE1	008
A1081P1	ASSY, PCB, LONWORKS, FE2 MODE, P10 1	008
AGA1B1	HODE, PIO 2	
A6A21B1 A44	LIGHT OURTAIN RECEIVER	008
A45	LIGHT CURTAIN TRANSMITTER	008
A6A24	LIGHT OURTAIN PLATE	008
ABA15	CONSOLE SWITCH MUX	919
A6A25	WID	004,009,011
		00110001011
A5A40	DC POWER	004
ABA21	AC JUNCTION BOX 2	003
A6A22	TERMINAL SERVER	009
A5A41	VALVE CONTROL NODE	007
A1 181	ASSY, PCB, LONWORKS, FE3	008
A6A23	WATER DETECTOR SENSOR	005
		-
A1.2	IMM	012
		I and the second

-012	ILM	В
-011	WAFER ID	8
-010	UI OPTION	В
-009	VTM COMMUNICATION	B
-008	ATM SIGNAL	В
-007	VTM3 SIGNAL	Α
-006	VTM2 SIGNAL	В
-005	VTM1 SIGNAL	В
-004	DC POWER	C
003	AC POWER	В
-002	REFERÊNCE	A.
-001	COVER PAGE	D
DASH	DESCRIPTION	REV