

Adjusting zoom — Tour Pro Zoom #13-22

Read from BASE_SHOW_2026.mtr, TLM_SHOW_2026_R13_FLASHY_SCENE_SPLIT.mtr and BASE_SHOW_2026.qlab5.

WHY A ZOOM CHANGE WON'T STICK Every memory stores a ZOOM value for #13-22 (2794 entries in the show file, 110 in the base), all set to snap. The Mantra is latest-takes-precedence, so the next memory QLab fires puts zoom straight back to the stored value. Turning the encoder is fine for finding the right value, but to keep it the value has to be written into the memories (step 2).

1 Find the value (focus session)	Load BASE_SHOW_2026.mtr on the desk and BASE_SHOW_2026.qlab5 in QLab. GO the fixture's test cue (table below) so it is the only light on. On the Mantra select that fixture, open its attributes and turn ZOOM (look under the beam attributes — the exact Mantra Lite button names are not confirmed here). Zoom snaps, range 0-255. Check the fixture manual for which end is narrow, or just watch the beam. Write the number in the table. Barn doors and aim are set by hand at the fixture.
2 Make it stick	A · recommended: send the numbers (e.g. “#13-18 = 120, #19-20 = 40”). They get written into every memory of both .mtr files, checksums and checks updated; then re-import the show file on the desk (Home > Tools > Import Show). B · on the desk: set the zoom and update every memory that uses that fixture, on every page. Slow and easy to miss one — run the whole show after.
3 Check	With the show file loaded, fire a few scenes from QLab that use the Zooms (LX1 wash #13-18, side #21-22, voice specials #19-20 at Q55/Q56) and confirm the beam stays where you set it.

Fixtures and where zoom lives — fill in NEW VALUE at the focus session

#	Label	Hung	Fader	DMX start	ZOOM ch 8	QLab test	Stored now: show (× entries)	Stored now: base	Note	NEW VALUE	Beam OK
13	WASH DSR	LX1	Console 13	U1 : 301	U1 : 308	T13	0 (×305)	0 (×11)			☐
14	WASH DSC	LX1	Console 14	U1 : 313	U1 : 320	T14	0 (×305)	0 (×11)			☐
15	WASH DSL	LX1	Console 15	U1 : 325	U1 : 332	T15	0 (×305)	0 (×11)			☐
16	WASH CSR	LX1	Console 16	U1 : 337	U1 : 344	T16	0 (×305)	0 (×11)			☐
17	WASH CSC	LX1	Console 17	U1 : 349	U1 : 356	T17	0 (×305)	0 (×11)			☐
18	WASH CSL	LX1	Console 18	U1 : 361	U1 : 368	T18	0 (×305)	0 (×11)			☐
19	THEODORE	LX2	Console 19	U1 : 373	U1 : 380	T19	0 (×163)	0 (×11)	voice special V3 Theodore: book says 13°		☐
20	MARINA	LX2	Console 20	U1 : 385	U1 : 392	T20	0 (×163)	0 (×11)	voice special V4 Marina: book says 13°		☐
21	SIDE SR	SR boom	Console 21	U1 : 397	U1 : 404	T21	0 (×319)	0 (×11)			☐
22	SIDE SL	SL boom	Console 22	U1 : 409	U1 : 416	T22	0 (×319)	0 (×11)			☐

Zoom 12-channel layout (from the desk file): 1 Intensity · 2 Red (home 255) · 3 Green (home 255) · 4 Blue (home 255) · 5 White · 6 Control · 7 Strobe · 8 Zoom · 9 Other · 10 Default · 11 Auto Speed · 12 Reset. Keep Control, Strobe, Other, Default, Auto speed and Reset at 0.