config_events

Command: `config_events`

Description

Enables or disables specific device events. To apply the changes, a device reboot is required. For RFD4090 devices, only the following events are supported: terminalConnection, firmwareUpdate, network, exceptions, ntp, heartbeat, power, battery, and fileDownload.

Request

Request Fields

Field	Type	Required	Description	Example
`command`	string	Yes	Command issued to configure events & alert threshold values	`config_events`
`requestId`	string	Yes	A unique identifier for the request, allowing tracking and debugging of the operation.	`abc123`
`eventConfiguration`	object	No		
`eventConfiguration.antenna`	boolean	No	set to true to enable antenna events	
`eventConfiguration.terminalConnection`	boolean	No	set to true to enable terminal connection/disconnection events	
`eventConfiguration.firmwareUpdate`	boolean	No	set to true to enable fw update events	
`eventConfiguration.gpi`	boolean	No	set to true to enable gpi events	
`eventConfiguration.network`	boolean	No	set to true to enable network events	
`eventConfiguration.exceptions`	boolean	No	set to true to enable exception events	

Field	Type	Required	Description	Example
`eventConfiguration.ntp`	boolean	No	set to true to enable battery alerts	
`eventConfiguration.userApp`	boolean	No	set to true to enable user app events	
`eventConfiguration.heartbeat`	boolean	No	set to true to enable heart beat	
`eventConfiguration.power`	boolean	No	set to true to enable power source alerts	
`eventConfiguration.battery`	boolean	No	set to true to enable battery alerts	
`eventConfiguration.temperature`	boolean	No	set to true to enable temperature alerts	
`eventConfiguration.fileDownload`	boolean	No	set to true to enable file download alerts	
`eventConfiguration.cpuUsage`	boolean	No	set to true to enable cpu usage alerts	
`eventConfiguration.flashUsage`	boolean	No	set to true to enable flash usage alerts	
`eventConfiguration.ramUsage`	boolean	No	set to true to enable ram usage alerts	
`eventConfiguration.heartbeatConfiguration`	object	No		
`eventConfiguration.heartbeatConfiguration.interval`	integer	No	heart beat interval in seconds	`100`
`eventConfiguration.heartbeatConfiguration.inventoryStatus`	boolean	No	set to true to enable inventory status as part of heartbeat message	
`eventConfiguration.heartbeatConfiguration.batteryStatus`	boolean	No	set to true to enable battery status as part of heartbeat message	

Field	Type	Required	Description	Example
`eventConfiguration.heartbeatConfiguration.userApps`	boolean	No	set to true to enable user app status as part of heartbeat message	
`eventConfiguration.cpuThreshold`	integer	No	cpu usage value(%) above which alert will be triggered	
`eventConfiguration.ramThreshold`	integer	No	ram usage value(%) above which alert will be triggered	
`eventConfiguration.flashThreshold`	integer	No	flash usage value(%) above which alert will be triggered	
`eventConfiguration.temperatureThreshold`	integer	No	temperature treshold value above which alert will be triggered	

Request Examples

Enable all events

```
{
  "command": "config_events",
  "requestId": "abc123",
  "eventConfiguration": {
    "antenna": true,
    "terminalConnection": true,
    "firmwareUpdate": true,
    "gpi": true,
    "network": true,
    "exceptions": true,
    "ntp": true,
    "userApp": true,
    "heartbeat": true,
    "power": true,
    "battery": true,
    "temperature": true,
    "fileDownload": true,
    "cpuUsage": true,
    "flashUsage": true,
    "ramUsage": true,
    "heartbeatConfiguration": {
      "interval": 100,
```

```
      "inventoryStatus": true,
      "batteryStatus": true,
      "userApps": true
    },
    "cpuThreshold": 80,
    "ramThreshold": 80,
    "flashThreshold": 80,
    "temperatureThreshold": 55
  }
}
```

Selective events

```
{
  "command": "config_events",
  "requestId": "abc123",
  "eventConfiguration": {
    "antenna": false,
    "terminalConnection": true,
    "firmwareUpdate": true,
    "gpi": false,
    "network": true,
    "exceptions": false,
    "ntp": false,
    "userApp": false,
    "heartbeat": false,
    "power": true,
    "battery": true,
    "temperature": true,
    "fileDownload": true,
    "cpuUsage": false,
    "flashUsage": false,
    "ramUsage": false
  }
}
```

Response

Response Fields

Field	Type	Required	Description	Example
`command`	string	Yes		`config_events`
`requestId`	string	Yes		`abc123`

Field	Type	Required	Description	Example
`apiVersion`	string (enum)	Yes		`V1.1`
`response`	object	Yes	Status of the command execution — check `code` to confirm success (0) or identify the error.	

Field	Type	Required	Description	Example
`response.code`	integer	Yes	Response code indicating success or failure. • **0** — Success • **1** — Command payload accepted • **2** — Invalid payload • **3** — Not able to retrieve information • **4** — Firmware update in progress • **5** — Can't reboot, inventory in progress • **6** — Region is not configured • **7** — Interface is not available • **8** — Insufficient flash size • **9** — File not found • **10** — Configuration already exists • **11** — Inventory in progress • **12** — No radio operation in progress • **13** — Firmware update failed • **14** — Battery too low for firmware update • **15** — WIFI: SSID not found • **16** — WIFI: Cannot delete active SSID • **17** — WIFI: SSID missing	`0`

Field	Type	Required	Description	Example
			• **18** — WIFI: SSID already exists • **19** — WIFI: SSID count overflow • **20** — WiFi is not supported • **21** — Certificate not found • **22** — Advanced configuration not set • **23** — Invalid enum value • **24** — Max 32 prefilters limit exceeded • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length • **28** — Tag match pattern length exceeded	
`response.description`	string	Yes	Human-readable description of the response code (e.g. "Success", "Invalid payload").	`Success`

Response Examples

example1

```
{
  "command": "config_events",
  "requestId": "abc123",
  "apiVersion": "V1.1",
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```