get_config

Command: `get_config`

Description

Retrieves the **complete device configuration** in a single response — equivalent to calling `get_version`, `get_status`, `get_current_region`, `get_wifi`, `get_eth`, `get_endpoint_config`, and `get_installed_certificate` all at once.

Response sections:

Section	Contents
`readerVersion`	Model, serial number, SKU, firmware versions (main, scanner, radio, IoTC)
`deviceStatus`	Power source, radio state, temperature, battery health, NTP sync, terminal connection
`currentRegion`	Country, regulatory standard, frequency channels, power limits, frequency hopping, LBT
`wifiConfig`	Wi-Fi interface status, connected SSID, IP address, MAC, DHCP, security type
`ethConfig`	Ethernet interface status, link speed, IP configuration
`epConfig`	Active MQTT endpoint: type, broker URL, port, protocol, credentials, topics, security
`installedCerts`	List of installed certificates with type, validity dates, and algorithms
`eventConfiguration`	Which events/alerts are enabled (heartbeat, battery, temperature, firmware, network, etc.)

Typical use cases:

- First-time setup — see how a blank scanner is configured before applying changes via `set_config`.
- Troubleshooting — get the full picture when something isn't working.
- Auditing — verify all settings across a fleet of scanners.

Request

Request Fields

Field	Type	Required	Description	Example
`command`	string (enum)	No	Must be `get_config`. Tells the scanner to return its full configuration.	`get_config`
`requestId`	string	No	A unique ID you assign to this request. The scanner echoes it back in the response so you can match requests to responses.	`abc123`

Request Examples

Generated Example

```
{
  "command": "get_config",
  "requestId": "abc123"
}
```

Response

Response Fields

Field	Type	Required	Description	Example
`command`	string	Yes	Echoes back the command name — always `get_config` for this response.	`get_config`

Field	Type	Required	Description	Example
`requestId`	string	Yes	Echoes back the requestId you sent, so you can match this response to your original request.	`abc123`
`apiVersion`	string	Yes	The API version supported by the scanner (currently V1.1).	`V1.1`
`currentConfig`	object	No	Complete device configuration snapshot — contains every configurable section of the scanner in a single object. Each sub-object corresponds to a standalone get command (e.g. readerVersion = get_version, deviceStatus = get_status).	
`currentConfig.readerVersion`	object	No	Scanner identity — model, serial number, SKU, and firmware versions for the main device, barcode scanner, RFID radio, and IoT Connector. These values only change after a firmware update.	
`currentConfig.readerVersion.firmwareVersion`	string	Yes	The firmware version of the reader.	`SAAFKS00-006-R02`

Field	Type	Required	Description	Example
`currentConfig.readerVersion.model`	string (enum)	Yes	The model of the reader, such as RFD40 or RFD90.	`RFD40`
`currentConfig.readerVersion.serialNumber`	string	Yes	The serial number of the reader.	`23053520102096`
`currentConfig.readerVersion.sku`	string	Yes	The stock keeping unit (SKU) identifier for the reader.	`RFD4031-G10B700-US`
`currentConfig.readerVersion.detailedVersions`	object	No	Detailed version information for the reader.	
`currentConfig.readerVersion.detailedVersions.scannerFirmware`	string	No	The firmware version of the scanner component.	`PAAEOC20-003-R01`
`currentConfig.readerVersion.detailedVersions.radioFirmware`	string	No	The firmware version of the radio component.	`2.0.42.0`
`currentConfig.readerVersion.detailedVersions.iotcVersion`	string (enum)	No	The version of the IoT Connector (IoTC) software.	`V1.1`
`currentConfig.deviceStatus`	object	No	Real-time device health — power source, RFID radio state, temperature, battery level and health, NTP clock sync, and paired terminal (phone/tablet) connection.	

Field	Type	Required	Description	Example
`currentConfig.deviceStatus.powerSource`	string (enum)	Yes	The source of power for the device (e.g., DC, Wall Charger, USB, or Cradle).	`CRADLE`
`currentConfig.deviceStatus.radioActivity`	string (enum)	Yes	The activity status of the device's radio (e.g., Active or Inactive).	`ACTIVE`
`currentConfig.deviceStatus.radioConnection`	string (enum)	Yes	The connection status of the device's radio (e.g., Connected or Disconnected).	`CONNECTED`
`currentConfig.deviceStatus.hostname`	string	Yes	The hostname of the device on the network.	`RFD40-212735201D0053.local`
`currentConfig.deviceStatus.systemTime`	string	Yes	The system time of the device in ISO 8601 format.	`2022-07-01T03:01:31.464Z`
`currentConfig.deviceStatus.temperature`	integer	Yes	The current temperature of the device in degrees Celsius.	`32`
`currentConfig.deviceStatus.ntp`	object	No	Details about the Network Time Protocol (NTP) synchronization.	
`currentConfig.deviceStatus.ntp.offset`	integer	No	The offset in milliseconds between the device's clock and the NTP server.	`120`
`currentConfig.deviceStatus.ntp.reach`	integer	No	The reachability score of the NTP server.	`321`

Field	Type	Required	Description	Example
`currentConfig.deviceStatus.terminalConnection`	object	No	Details about the terminal connection to the device.	
`currentConfig.deviceStatus.terminalConnection.status`	string (enum)	No	The connection status of the terminal (e.g., Connected or Disconnected).	`connected`
`currentConfig.deviceStatus.terminalConnection.type`	string (enum)	No	The type of terminal connection (e.g., Bluetooth, CIO, or USB).	
`currentConfig.deviceStatus.batteryStatus`	object	No	Information about the battery status of the device.	
`currentConfig.deviceStatus.batteryStatus.capacity`	integer	No	The battery capacity remaining in mAh.	`21`
`currentConfig.deviceStatus.batteryStatus.stateOfHealth`	string (enum)	No	The overall health of the battery (e.g., Good, Average, or Poor).	`GOOD`
`currentConfig.deviceStatus.batteryStatus.chargePercentage`	integer	No	The percentage of battery charge remaining.	`23`
`currentConfig.deviceStatus.batteryStatus.chargeStatus`	integer	No	The charging status of the device battery: 0 - Charger not connected, 1 - Charger connected and charging in progress, 2 - Charger connected and battery is 100%.	`1`

Field	Type	Required	Description	Example
`currentConfig.currentRegion`	object	No	Regulatory radio configuration — country, regulatory standard, available frequency channels, transmit power limits, frequency hopping, and Listen Before Talk settings. These are factory-set and cannot be changed.	
`currentConfig.currentRegion.frequencyHopping`	boolean	Yes	Indicates whether frequency hopping is enabled in the region.	
`currentConfig.currentRegion.channelData`	array	Yes	List of channel frequencies available in the region, represented as strings.	
`currentConfig.currentRegion.country`	string	Yes	The country for which the device is configured.	`USA`
`currentConfig.currentRegion.lbtEnabled`	boolean	Yes	Specifies if Listen Before Talk (LBT) is enabled for the region.	
`currentConfig.currentRegion.maxTxPowerSupported`	number	Yes	The maximum transmission power supported in the region, measured in dBm.	`29.2`
`currentConfig.currentRegion.minTxPowerSupported`	number	Yes	The minimum transmission power supported in the region, measured in dBm.	`10.0`

Field	Type	Required	Description	Example
`currentConfig.currentRegion.regulatoryStandard`	string	Yes	The regulatory standard governing the region's transmission rules.	`ETSI_EU_800M_900M_3_CHANNEL`
`currentConfig.ethConfig`	object	No	Detailed schema for Ethernet configuration.	
`currentConfig.ethConfig.interfaceDetails`	object	No		
`currentConfig.ethConfig.interfaceDetails.interfaceName`	string	Yes	Name of the network interface.	`eth0`
`currentConfig.ethConfig.interfaceDetails.status`	string (enum)	Yes	Status of the network interface.	`enabled`
`currentConfig.ethConfig.interfaceDetails.hostname`	string	Yes	Hostname assigned to the device.	`RFD40AB03`
`currentConfig.ethConfig.interfaceDetails.macAddress`	string	Yes	MAC address of the network interface.	`E0-D0-45-3D-38-1D`
`currentConfig.ethConfig.interfaceDetails.linkStatus`	object	No		
`currentConfig.ethConfig.interfaceDetails.linkStatus.status`	string (enum)	Yes	Current status of the network link.	`up`

Field	Type	Required	Description	Example
`currentConfig.ethConfig.interfaceDetails.linkStatus.linkSpeed`	string	Yes	Speed of the network link.	`100Mbps`
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration`	object	No		
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration.ipAddress`	string	No	IPv4 address of the network interface.	`192.168.1.81`
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration.subnetMask`	string	No	Subnet mask for the IPv4 configuration.	`255.255.255.0`
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration.gateway`	string	No	Gateway address for the IPv4 configuration.	`192.168.1.144`
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration.enableDhcp`	boolean (enum)	No	Indicates if DHCP is enabled for IPv4 configuration.	`enabled`
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration.dnsServer`	string	No	DNS server address for the IPv4 configuration.	`192.168.1.78`
`currentConfig.ethConfig.interfaceDetails.ipv4Configuration.domainName`	string	No	Domain name for the IPv4 configuration.	`test.soti.com`

Field	Type	Required	Description	Example
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration`	object	No		
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration.ipAddress`	string	No	IPv6 address of the network interface.	`fe80::1643:8376:b32:4a16`
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration.prefix`	integer	No	Prefix length for the IPv6 configuration.	`64`
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration.gateway`	string	No	Gateway address for the IPv6 configuration.	`2a02:1234:420a:100b::99`
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration.enableAuto`	boolean	No	Indicates if auto-configuration is enabled for IPv6.	`True`
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration.dnsServer`	string	No	DNS server address for the IPv6 configuration.	`2001:4860:4860::9999`
`currentConfig.ethConfig.interfaceDetails.ipv6Configuration.domainName`	string	No	Domain name for the IPv6 configuration.	`test.soti.com`
`currentConfig.ethConfig.interfaceDetails.security`	object	No		

Field	Type	Required	Description	Example
`currentConfig.ethConfig.interfaceDetails.security.securityStatus`	boolean	No	Indicates if security features are enabled.	`True`
`currentConfig.ethConfig.interfaceDetails.security.EAP802_1X`	object	No		``
`currentConfig.ethConfig.interfaceDetails.security.EAP802_1X.authentication`	string (enum)	No	Authentication method for 802.1X security.	`PEAP`
`currentConfig.ethConfig.interfaceDetails.security.EAP802_1X.innerAuthentication`	string (enum)	No	Inner authentication method for 802.1X security.	`EAP-MS-CHAPv2`
`currentConfig.ethConfig.interfaceDetails.security.EAP802_1X.certificate`	string	No	Certificate used for 802.1X authentication.	`client45`

Field	Type	Required	Description	Example
`currentConfig.wifiConfig`	object	No	Wi-Fi network configuration — interface status (enabled/disabled), connected access point (SSID, signal, security type), IP addressing (IPv4/IPv6, DHCP or static), and enterprise security credentials (WPA2/WPA3 Personal or Enterprise, certificates).	
`currentConfig.wifiConfig.interfaceDetails`	object	No		
`currentConfig.wifiConfig.interfaceDetails.interfaceName`	string	Yes	The name of the network interface (e.g., wlan0).	`wlan0`
`currentConfig.wifiConfig.interfaceDetails.status`	string (enum)	Yes	The status of the network interface, either "ENABLED" or "DISABLED".	`ENABLED`
`currentConfig.wifiConfig.interfaceDetails.hostname`	string	Yes	The hostname of the device.	`RFD40S123`
`currentConfig.wifiConfig.interfaceDetails.macAddress`	string	Yes	The MAC address of the network interface.	`E0-D0-45-3D-38-1D`
`currentConfig.wifiConfig.interfaceDetails.accessPoint`	object	No		

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.accessPoint.essid`	string	Yes	The ESSID (network name) of the access point.	`Zwireless`
`currentConfig.wifiConfig.interfaceDetails.accessPoint.status`	string (enum)	Yes	The connection status to the access point, either "CONNECTED" or "DISCONNECTED".	`CONNECTED`
`currentConfig.wifiConfig.interfaceDetails.accessPoint.securityType`	string (enum)	Yes	The security type used by the access point.	`OWEPublic`
`currentConfig.wifiConfig.interfaceDetails.accessPoint.isPreferred`	boolean	Yes	Indicates whether this access point is preferred for connection.	
`currentConfig.wifiConfig.interfaceDetails.accessPoint.autoConn`	boolean	No	This field is deprecated and kept for backward compatibility.	
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration`	object	No		
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration.ipAddress`	string	No	The IPv4 address of the device.	`192.168.1.81`

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration.subnetMask`	string	No	The subnet mask of the network.	`255.255.255.0`
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration.gateway`	string	No	The IPv4 gateway address.	`192.168.1.144`
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration.enableDhcp`	boolean	No	Indicates if DHCP is enabled for IPv4 configuration.	`enabled`
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration.dnsServer`	string	No	The IPv4 address of the DNS server.	`192.168.1.78`
`currentConfig.wifiConfig.interfaceDetails.ipv4Configuration.domainName`	string	No	The domain name of the network.	`test.soti.com`
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration`	object	No		``
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration.ipAddress`	string	No	The IPv6 address of the device.	`fe80::1643:8376:b32:4a16`
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration.prefix`	integer	No	The prefix length of the IPv6 address.	`64`

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration.gateway`	string	No	The IPv6 gateway address.	`2a02:1234:420a:100b::99`
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration.enableAuto`	boolean (enum)	No	Specifies if automatic IPv6 configuration is enabled.	`enabled`
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration.dnsServer`	string	No	The IPv6 address of the DNS server.	`2001:4860:4860::9999`
`currentConfig.wifiConfig.interfaceDetails.ipv6Configuration.domainName`	string	No	The domain name of the IPv6 network.	`test.soti.com`
`currentConfig.wifiConfig.interfaceDetails.securityDetails`	object	No		
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Personal`	object	No		
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Personal.password`	string	No	The password used for WPA2-Personal security.	`test@123`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Personal`	object	No		

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Personal.password`	string	No	The password used for WPA3-Personal security.	`test@123`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise`	object	No		
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.authentication`	string (enum)	No	The authentication method for WPA2-Enterprise.	`tls`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.innerAuthentication`	string (enum)	No	The inner authentication protocol for WPA2-Enterprise.	`mschapv2`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.identity`	string	No	The identity used for WPA2-Enterprise authentication.	`test`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.anonymousIdentity`	string	No	The anonymous identity used for WPA2-Enterprise authentication.	`test`

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.password`	string	No	The password for WPA2-Enterprise authentication.	`test@123`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.passphrase`	string	No	The passphrase for WPA2-Enterprise.	`test@321`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.certificate`	array	No	The certificates used for WPA2-Enterprise.	`ap1wpa2e`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA2Enterprise.protocol`	string (enum)	No	The protocol used for WPA2-Enterprise.	`WPA2_Enterprise_CCMP`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise`	object	No		``
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.authentication`	string (enum)	No	The authentication method for WPA3-Enterprise.	`tls`

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.innerAuthentication`	string (enum)	No	The inner authentication protocol for WPA3-Enterprise.	`mschapv2`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.identity`	string	No	The identity used for WPA3-Enterprise authentication.	`test`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.anonymousIdentity`	string	No	The anonymous identity used for WPA3-Enterprise authentication.	`test`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.password`	string	No	The password for WPA3-Enterprise authentication.	`test@123`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.passphrase`	string	No	The passphrase for WPA3-Enterprise.	`test@321`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.certificate`	array	No	The certificates used for WPA3-Enterprise.	`ap1wpa2e`

Field	Type	Required	Description	Example
`currentConfig.wifiConfig.interfaceDetails.securityDetails.WPA3Enterprise.protocol`	string (enum)	No	The protocol used for WPA3-Enterprise.	`WPA3_Enterprise_CCMP_256`
`currentConfig.wifiConfig.interfaceDetails.securityDetails.OWEPublic`	object	No		
`currentConfig.wifiConfig.interfaceDetails.securityDetails.OWEPublic.authentication`	string	No	The authentication method for OWE-Public access.	
`currentConfig.installedCerts`	object	No	Installed TLS/SSL certificates — lists every certificate on the device with its type (client, server, MQTT, Wi-Fi), issuer, subject, validity dates, and public key details. Used for secure MQTT and enterprise Wi-Fi connections.	
`currentConfig.installedCerts.certInfo`	array	No	A list of installed certificates with their details.	

Field	Type	Required	Description	Example
`currentConfig.epConfig`	object	No	MQTT endpoint configuration — broker connection details (URL, port, protocol), authentication (username/password, TLS certificates), publish/subscribe topics with QoS levels, keep-alive and reconnect settings, and event configuration (which device events are forwarded to the broker).	
`currentConfig.epConfig.configuration`	object	No		
`currentConfig.epConfig.configuration.endpointName`	string	No	The name of the endpoint, e.g., "MDM" for Mobile Device Management.	`MDM`
`currentConfig.epConfig.configuration.epType`	string (enum)	Yes	The type of endpoint, specifying its functionality (e.g., Management, Control, etc.).	`MGMT`
`currentConfig.epConfig.configuration.protocol`	string (enum)	Yes	The communication protocol used by the endpoint, such as MQTT or HTTP.	`MQTT`

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.activate`	boolean	Yes	Indicates whether the endpoint is activated (true or false).	
`currentConfig.epConfig.configuration.url`	string	Yes	The URL of the endpoint, specifying its address.	`soti.example.com`
`currentConfig.epConfig.configuration.verificationType`	string (enum)	Yes	The type of verification to be used for the endpoint connection.	`VERIFY_HOST_PEER`
`currentConfig.epConfig.configuration.port`	integer	Yes	The port number used for the connection.	`1883`
`currentConfig.epConfig.configuration.qosCommon`	integer	No	The Quality of Service (QoS) level for message delivery.	`1`
`currentConfig.epConfig.configuration.tenantId`	string	No	The tenant's unique identifier.	`ZEBRA`
`currentConfig.epConfig.configuration.mqttParams`	object	No		
`currentConfig.epConfig.configuration.mqttParams.keepAlive`	integer	No	The keep-alive interval for the MQTT connection.	`300`
`currentConfig.epConfig.configuration.mqttParams.cleanSession`	boolean	No	Indicates whether the MQTT session should be clean (true or false).	

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.mqttParams.reconnectDelayMin`	integer	No	Minimum delay before reconnecting in case of disconnection.	
`currentConfig.epConfig.configuration.mqttParams.reconnectDelayMax`	integer	No	Maximum delay before reconnecting in case of disconnection.	
`currentConfig.epConfig.configuration.mqttParams.clientId`	string	No	The client ID used for the MQTT connection.	`zebra-rfd40-01`
`currentConfig.epConfig.configuration.mqttParams.username`	string	No	The username for authenticating the MQTT connection.	
`currentConfig.epConfig.configuration.mqttParams.password`	string	No	The password for authenticating the MQTT connection.	
`currentConfig.epConfig.configuration.mqttParams.publishTopics`	array	No	A list of topics to which messages will be published.	
`currentConfig.epConfig.configuration.mqttParams.subscribeTopics`	array	No	A list of topics to which the client will subscribe.	
`currentConfig.epConfig.configuration.securityParams`	object	No	Security parameters for the endpoint connection.	

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.securityParams.format`	string (enum)	Yes	The format of the security certificate (e.g., PEM or PFX).	`PEM`
`currentConfig.epConfig.configuration.securityParams.algorithm`	string (enum)	Yes	The encryption algorithm used (e.g., RSA256).	`RSA256`
`currentConfig.epConfig.configuration.securityParams.caCertificateFile`	string	Yes	The CA certificate file for establishing trust.	`cloud-trusted-ca-certs.crt`
`currentConfig.epConfig.configuration.securityParams.clientCert`	string	Yes	The client certificate file for authentication.	`client_cert.pem`
`currentConfig.epConfig.configuration.securityParams.clientKey`	string	Yes	The client key file for authentication.	`client_key.pem`
`currentConfig.epConfig.configuration.eventConfiguration`	object	No		
`currentConfig.epConfig.configuration.eventConfiguration.antenna`	boolean	No	set to true to enable antenna events	
`currentConfig.epConfig.configuration.eventConfiguration.terminalConnection`	boolean	No	set to true to enable terminal connection/disconnection events	

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.eventConfiguration.firmwareUpdate`	boolean	No	set to true to enable fw update events	
`currentConfig.epConfig.configuration.eventConfiguration.gpi`	boolean	No	set to true to enable gpi events	
`currentConfig.epConfig.configuration.eventConfiguration.network`	boolean	No	set to true to enable network events	
`currentConfig.epConfig.configuration.eventConfiguration.exceptions`	boolean	No	set to true to enable exception events	
`currentConfig.epConfig.configuration.eventConfiguration.ntp`	boolean	No	set to true to enable battery alerts	
`currentConfig.epConfig.configuration.eventConfiguration.userApp`	boolean	No	set to true to enable user app events	
`currentConfig.epConfig.configuration.eventConfiguration.heartbeat`	boolean	No	set to true to enable heart beat	
`currentConfig.epConfig.configuration.eventConfiguration.power`	boolean	No	set to true to enable power source alerts	

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.eventConfiguration.battery`	boolean	No	set to true to enable battery alerts	
`currentConfig.epConfig.configuration.eventConfiguration.temperature`	boolean	No	set to true to enable temperature alerts	
`currentConfig.epConfig.configuration.eventConfiguration.fileDownload`	boolean	No	set to true to enable file download alerts	
`currentConfig.epConfig.configuration.eventConfiguration.cpuUsage`	boolean	No	set to true to enable cpu usage alerts	
`currentConfig.epConfig.configuration.eventConfiguration.flashUsage`	boolean	No	set to true to enable flash usage alerts	
`currentConfig.epConfig.configuration.eventConfiguration.ramUsage`	boolean	No	set to true to enable ram usage alerts	
`currentConfig.epConfig.configuration.eventConfiguration.heartbeatConfiguration`	object	No		

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.eventConfiguration.heartbeatConfiguration.interval`	integer	No	heart beat interval in seconds	`100`
`currentConfig.epConfig.configuration.eventConfiguration.heartbeatConfiguration.inventoryStatus`	boolean	No	set to true to enable inventory status as part of heartbeat message	
`currentConfig.epConfig.configuration.eventConfiguration.heartbeatConfiguration.batteryStatus`	boolean	No	set to true to enable battery status as part of heartbeat message	
`currentConfig.epConfig.configuration.eventConfiguration.heartbeatConfiguration.userApps`	boolean	No	set to true to enable user app status as part of heartbeat message	
`currentConfig.epConfig.configuration.eventConfiguration.cpuThreshold`	integer	No	cpu usage value(%) above which alert will be triggered	
`currentConfig.epConfig.configuration.eventConfiguration.ramThreshold`	integer	No	ram usage value(%) above which alert will be triggered	

Field	Type	Required	Description	Example
`currentConfig.epConfig.configuration.eventConfiguration.flashThreshold`	integer	No	flash usage value(%) above which alert will be triggered	
`currentConfig.epConfig.configuration.eventConfiguration.temperatureThreshold`	integer	No	temperature treshold value above which alert will be triggered	
`currentConfig.deviceCapabilities`	object	No	Hardware capabilities of the scanner — indicates whether Bluetooth, Wi-Fi, and barcode scanning features are supported on this particular model.	
`currentConfig.deviceCapabilities.isBluetoothSupported`	boolean	No	Indicates whether the device supports Bluetooth functionality.	
`currentConfig.deviceCapabilities.isWifiSupported`	boolean	No	Indicates whether the device supports WiFi connectivity.	
`currentConfig.deviceCapabilities.isScannerSupported`	boolean	No	Indicates whether the device supports scanner capabilities.	
`response`	object	No	Status of the command execution — check `code` to confirm success (0) or identify the error.	

Field	Type	Required	Description	Example
`response.code`	integer	Yes	Response code indicating success or failure. • **0** — Success • **1** — Command payload accepted • **2** — Invalid payload • **3** — Not able to retrieve information • **4** — Firmware update in progress • **5** — Can't reboot, inventory in progress • **6** — Region is not configured • **7** — Interface is not available • **8** — Insufficient flash size • **9** — File not found • **10** — Configuration already exists • **11** — Inventory in progress • **12** — No radio operation in progress • **13** — Firmware update failed • **14** — Battery too low for firmware update	`0`

Field	Type	Required	Description	Example
			• **15** — WIFI: SSID not found • **16** — WIFI: Cannot delete active SSID • **17** — WIFI: SSID missing • **18** — WIFI: SSID already exists • **19** — WIFI: SSID count overflow • **20** — WiFi is not supported • **21** — Certificate not found • **22** — Advanced configuration not set • **23** — Invalid enum value • **24** — Max 32 prefilters limit exceeded • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length • **28** — Tag match pattern length exceeded	

Field	Type	Required	Description	Example
`response.description`	string	Yes	Human-readable description of the response code (e.g. "Success", "Invalid payload").	`Success`

Response Examples

Complete device config


```
{
  "command": "get_config",
  "requestId": "abc123",
  "apiVersion": "V1.1",
  "currentConfig": {
    "readerVersion": {
      "firmwareVersion": "PAAFKS00-007-D03",
      "model": "RFD40",
      "serialNumber": "212735201D0053",
      "sku": "RFD4031-G10B700-US",
      "detailedVersions": {
        "scannerFirmware": "PAAEOC20-003-R01",
        "radioFirmware": "2.0.42.0",
        "iotcVersion": "V1.1"
      }
    },
    "deviceStatus": {
      "powerSource": "USB",
      "radioActivity": "INACTIVE",
      "radioConnection": "CONNECTED",
      "systemTime": "2024-02-26T17:46:06.138Z",
      "temperature": 32,
      "ntp": {
        "offset": 0,
        "reach": 0
      },
      "terminalConnection": {
        "status": "CONNECTED",
        "type": "USB"
      },
      "batteryStatus": {
        "capacity": 6400,
        "stateOfHealth": "GOOD",
        "chargePercentage": 100,
        "chargeStatus": 1
      }
    },
    "currentRegion": {
      "frequencyHopping": true,
```

```
      "channelData": [
        "91575",
        "91525",
        "90325",
        "92675",
        "92625",
        "90425",
        "92725",
        "92025",
        "91925",
        "90925",
        "91875",
        "91775",
        "90525",
        "90475",
        "92525",
        "92175",
        "91475",
        "90675",
        "91375",
        "92225",
        "91125",
        "91175",
        "90375",
        "90875",
        "90575",
        "91225",
        "90625",
        "91725",
        "91425",
        "90725",
        "91825",
        "91625",
        "91025",
        "91075",
        "90775",
        "92475",
        "90975",
        "91975",
        "91675",
        "91325",
        "92375",
        "90825",
        "92575",
        "91275",
        "92425",
        "92125",
        "92075",
        "92275",
        "90275",
        "92325"
      ],
      "country": "United States",
      "lbtEnabled": false,
```

```
      "maxTxPowerSupported": 300,
      "minTxPowerSupported": 0,
      "regulatoryStandard": "FCC"
    },
    "ethConfig": {
      "interfaceDetails": {
        "interfaceName": "eth0",
        "status": "Disabled"
      }
    },
    "wifiConfig": {
      "interfaceDetails": {
        "interfaceName": "wlan0",
        "status": "Enabled",
        "hostname": "RFD40-212735201D0053",
        "macAddress": "48:A4:93:00:0B:9F",
        "accessPoint": {
          "essid": "Samhitha_2.4G",
          "status": "Connected",
          "securityType": "Pending"
        },
        "ipv4Configuration": {
          "ipAddress": "192.168.0.52",
          "subnetMask": "255.255.255.0",
          "gateway": "192.168.0.1",
          "enableDhcp": true,
          "dnsServer": "1.0.168.192",
          "domainName": "zebra.com"
        }
      }
    },
    "installedCerts": {},
    "epConfig": {
      "configuration": {
        "epType": "SOTI",
        "protocol": "MQTT_TLS",
        "activate": true,
        "url": "17L11-GG6663-1",
        "verificationType": "VERIFY_NONE",
        "port": 8883,
        "qosCommon": 0,
        "tenantId": "zebra",
        "mqttParams": {
          "keepAlive": 65520,
          "cleanSession": false,
          "reconnectDelayMin": 5,
          "reconnectDelayMax": 512,
          "username": "username_1",
          "password": "password_1",
          "publishTopics": [
            {
              "topic": "MGMT/clients/cmnd",
              "qos": 0,
              "retain": false
```

```
            }
          ],
          "subscribeTopics": [
            {
              "topic": "MGMT/clients/resp",
              "qos": 1,
              "retain": false
            },
            {
              "topic": "MGMT/clients/event",
              "qos": 1,
              "retain": false
            },
            {
              "topic": "MGMT/clients/rfid",
              "qos": 2,
              "retain": true
            }
          ]
        },
        "securityParams": {
          "format": "PEM",
          "algorithm": "ToDo"
        },
        "eventConfiguration": {
          "terminalConnection": true,
          "firmwareUpdate": true,
          "network": true,
          "ntp": true,
          "heartbeat": true,
          "power": true,
          "battery": true,
          "temperature": true,
          "fileDownload": true,
          "heartbeatConfiguration": {
            "interval": 100,
            "inventoryStatus": true,
            "batteryStatus": true
          }
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```