get_eth

Command: `get_eth`

Description

This API used to retrieve ethernet configuration details. Security features, static IP configuration, and IPv6 support are not available in the current API version.

Request

Request Fields

Field	Type	Required	Description
`command`	string	**Yes**	Command issued to get the ethernet configuration
`requestId`	string	**Yes**	A unique identifier for the request, allowing tracking and debugging of the operation.

Request Examples

Generated Example

```
{
  "command": "get_eth",
  "requestId": "abc123"
}
```

Response

Response Fields

Field	Type	Required	Description
`command`	string	No	
`requestId`	string	No	
`apiVersion`	string (enum)	No	

Field	Type	Required	Description
`ethConfig`	object	No	Detailed schema for Ethernet configuration.
`ethConfig.interfaceDetails`	object	No	
`ethConfig.interfaceDetails.interfaceName`	string	**Yes**	Name of the network interface.
`ethConfig.interfaceDetails.status`	string (enum)	**Yes**	Status of the network interface.
`ethConfig.interfaceDetails.hostname`	string	**Yes**	Hostname assigned to the device.
`ethConfig.interfaceDetails.macAddress`	string	**Yes**	MAC address of the network interface.
`ethConfig.interfaceDetails.linkStatus`	object	No	
`ethConfig.interfaceDetails.linkStatus.status`	string (enum)	**Yes**	Current status of the network link.
`ethConfig.interfaceDetails.linkStatus.linkSpeed`	string	**Yes**	Speed of the network link.
`ethConfig.interfaceDetails.ipv4Configuration`	object	No	
`ethConfig.interfaceDetails.ipv4Configuration.ipAddress`	string	No	IPv4 address of the network interface.
`ethConfig.interfaceDetails.ipv4Configuration.subnetMask`	string	No	Subnet mask for the IPv4 configuration.
`ethConfig.interfaceDetails.ipv4Configuration.gateway`	string	No	Gateway address for the IPv4 configuration.

Field	Type	Required	Description
`ethConfig.interfaceDetails.ipv4Configuration.enableDhcp`	boolean (enum)	No	Indicates if DHCP is enabled for IPv4 configuration.
`ethConfig.interfaceDetails.ipv4Configuration.dnsServer`	string	No	DNS server address for the IPv4 configuration.
`ethConfig.interfaceDetails.ipv4Configuration.domainName`	string	No	Domain name for the IPv4 configuration.
`ethConfig.interfaceDetails.ipv6Configuration`	object	No	
`ethConfig.interfaceDetails.ipv6Configuration.ipAddress`	string	No	IPv6 address of the network interface.
`ethConfig.interfaceDetails.ipv6Configuration.prefix`	integer	No	Prefix length for the IPv6 configuration.
`ethConfig.interfaceDetails.ipv6Configuration.gateway`	string	No	Gateway address for the IPv6 configuration.
`ethConfig.interfaceDetails.ipv6Configuration.enableAuto`	boolean	No	Indicates if auto-configuration is enabled for IPv6.
`ethConfig.interfaceDetails.ipv6Configuration.dnsServer`	string	No	DNS server address for the IPv6 configuration.
`ethConfig.interfaceDetails.ipv6Configuration.domainName`	string	No	Domain name for the IPv6 configuration.
`ethConfig.interfaceDetails.security`	object	No	
`ethConfig.interfaceDetails.security.securityStatus`	boolean	No	Indicates if security features are enabled.

Field	Type	Required	Description
`ethConfig.interfaceDetails.security.EAP802_1X`	object	No	
`ethConfig.interfaceDetails.security.EAP802_1X.authentication`	string (enum)	No	Authentication method for 802.1X security.
`ethConfig.interfaceDetails.security.EAP802_1X.innerAuthentication`	string (enum)	No	Inner authentication method for 802.1X security.
`ethConfig.interfaceDetails.security.EAP802_1X.certificate`	string	No	Certificate used for 802.1X authentication.
`response`	object	No	Status of the command execution — check `code` to confirm success (0) or identify the error.

Field	Type	Required	Description
`response.code`	integer	**Yes**	Response code indicating success or failure. • **0** — Success • **1** — Command payload accepted • **2** — Invalid payload • **3** — Not able to retrieve information • **4** — Firmware update in progress • **5** — Can't reboot, inventory in progress • **6** — Region is not configured • **7** — Interface is not available • **8** — Insufficient flash size • **9** — File not found • **10** — Configuration already exists • **11** — Inventory in progress • **12** — No radio operation in progress • **13** — Firmware update failed • **14** — Battery too low for firmware update • **15** — WIFI: SSID not found • **16** — WIFI: Cannot delete active SSID • **17** — WIFI: SSID missing • **18** — WIFI: SSID already exists • **19** — WIFI: SSID count overflow

Field	Type	Required	Description
			• **20** — WiFi is not supported • **21** — Certificate not found • **22** — Advanced configuration not set • **23** — Invalid enum value • **24** — Max 32 prefilters limit exceeded • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length • **28** — Tag match pattern length exceeded
`response.description`	string	**Yes**	Human-readable description of the response code (e.g. "Success", "Invalid payload").

Response Examples

Ethernet config info

```
{
  "command": "get_eth",
  "requestId": "abc123",
  "apiVersion": "V1.1",
  "ethconfig": {
    "InterfaceDetails": {
      "interfaceName": "eth0",
      "status": "Enabled",
      "hostName": "RFD40-211545201D0020",
      "macAddress": "AC:3F:A4:00:2C:89",
      "linkStatus": {
        "status": "Connected",
        "linkSpeed": "100Mbps"
```

```
      },
      "ipv4Configuration": {
        "ipAddress": "192.168.0.101",
        "subnetMask": "255.255.255.0",
        "gateway": "192.168.0.1",
        "enableDhcp": true,
        "dnsServer": "0.0.0.0",
        "domainName": "zebra.com"
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```