config_endpoint

> Command: `config_endpoint`

Description

Using config_endpoint user can add/delete/modify the end point configuration

Request

Request Fields

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`command`	string	Yes	Command issued to configure active endpoint	`config_endpoint`
`requestId`	string	Yes	A unique identifier for the request, allowing tracking and debugging of the operation.	`abc123`
`epConfig`	object	No		
`epConfig.operation`	string (enum)	Yes	Specifies the type of operation to perform, either adding or deleting a configuration.	`add`
`epConfig.configuration`	object	Yes		
`epConfig.configuration.endpointName`	string	Yes	Identifies the name of the endpoint, which determines its purpose or function.	`mgmt`
`epConfig.configuration.epType`	string (enum)	Yes	Specifies the type of the endpoint.	`MGMT`

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`epConfig.configuration.protocol`	string (enum)	Yes	Defines the communication protocol used by the endpoint.	`MQTT`
`epConfig.configuration.activate`	boolean	Yes	Indicates whether the endpoint is active or inactive.	
`epConfig.configuration.url`	string	Yes	Specifies the URL associated with the endpoint.	`soti.example.com`
`epConfig.configuration.verificationType`	string (enum)	Yes	Specifies the type of verification used for establishing secure connections.	`VERIFY_PEER`
`epConfig.configuration.port`	integer	Yes	Specifies the port number used for communication.	`1883`
`epConfig.configuration.qosCommon`	integer	Yes	Defines the Quality of Service (QoS) level for the endpoint.	`1`
`epConfig.configuration.tenantId`	string	Yes	Identifies the tenantID associated with the configuration.	`ZEBRA`
`epConfig.configuration.mqttParams`	object	No		
`epConfig.configuration.mqttParams.keepAlive`	integer	No	Specifies the keep-alive interval in seconds for MQTT connections.	`300`
`epConfig.configuration.mqttParams.cleanSession`	boolean	No	Indicates whether to start a clean session for the MQTT client.	

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`epConfig.configuration.mqttParams.reconnectDelayMin`	integer	No	Specifies the minimum delay in seconds before reconnecting.	
`epConfig.configuration.mqttParams.reconnectDelayMax`	integer	No	Specifies the maximum delay in seconds before reconnecting.	
`epConfig.configuration.mqttParams.clientId`	string	No	Specifies the client ID used for MQTT connections.	`zebra-rfd40-01`
`epConfig.configuration.mqttParams.username`	string	No	The username for authentication in MQTT connections.	
`epConfig.configuration.mqttParams.password`	string	No	The password for authentication in MQTT connections.	
`epConfig.configuration.mqttParams.publishTopics`	array	No		
`epConfig.configuration.mqttParams.subscribeTopics`	array	No		
`epConfig.configuration.securityParams`	object	No	Defines the security parameters for the endpoint.	
`epConfig.configuration.securityParams.format`	string (enum)	Yes	Specifies the format of the security certificates. Currently, only PEM is supported.	`PEM`
`epConfig.configuration.securityParams.algorithm`	string (enum)	Yes	Specifies the algorithm used for encryption.	`RSA256`

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`epConfig.configuration.securityParams.caCertificateFile`	string	Yes	Specifies the file containing the CA certificates.	`cloud-trusted-ca-certs.crt`
`epConfig.configuration.securityParams.clientCert`	string	Yes	Specifies the file containing the client certificate.	`client_cert.pem`
`epConfig.configuration.securityParams.clientKey`	string	Yes	Specifies the file containing the client private key.	`client_key.pem`
`epConfig.configuration.eventConfiguration`	object	No		
`epConfig.configuration.eventConfiguration.antenna`	boolean	No	set to true to enable antenna events	
`epConfig.configuration.eventConfiguration.terminalConnection`	boolean	No	set to true to enable terminal connection/disconnection events	
`epConfig.configuration.eventConfiguration.firmwareUpdate`	boolean	No	set to true to enable fw update events	
`epConfig.configuration.eventConfiguration.gpi`	boolean	No	set to true to enable gpi events	
`epConfig.configuration.eventConfiguration.network`	boolean	No	set to true to enable network events	
`epConfig.configuration.eventConfiguration.exceptions`	boolean	No	set to true to enable exception events	
`epConfig.configuration.eventConfiguration.ntp`	boolean	No	set to true to enable battery alerts	

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`epConfig.configuration.eventConfiguration.userApp`	boolean	No	set to true to enable user app events	
`epConfig.configuration.eventConfiguration.heartbeat`	boolean	No	set to true to enable heart beat	
`epConfig.configuration.eventConfiguration.power`	boolean	No	set to true to enable power source alerts	
`epConfig.configuration.eventConfiguration.battery`	boolean	No	set to true to enable battery alerts	
`epConfig.configuration.eventConfiguration.temperature`	boolean	No	set to true to enable temperature alerts	
`epConfig.configuration.eventConfiguration.fileDownload`	boolean	No	set to true to enable file download alerts	
`epConfig.configuration.eventConfiguration.cpuUsage`	boolean	No	set to true to enable cpu usage alerts	
`epConfig.configuration.eventConfiguration.flashUsage`	boolean	No	set to true to enable flash usage alerts	
`epConfig.configuration.eventConfiguration.ramUsage`	boolean	No	set to true to enable ram usage alerts	
`epConfig.configuration.eventConfiguration.heartbeatConfiguration`	object	No		

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`epConfig.configuration.eventConfiguration.heartbeatConfiguration.interval`	integer	No	heart beat interval in seconds	`100`
`epConfig.configuration.eventConfiguration.heartbeatConfiguration.inventoryStatus`	boolean	No	set to true to enable inventory status as part of heartbeat message	
`epConfig.configuration.eventConfiguration.heartbeatConfiguration.batteryStatus`	boolean	No	set to true to enable battery status as part of heartbeat message	
`epConfig.configuration.eventConfiguration.heartbeatConfiguration.userApps`	boolean	No	set to true to enable user app status as part of heartbeat message	
`epConfig.configuration.eventConfiguration.cpuThreshold`	integer	No	cpu usage value(%) above which alert will be triggered	
`epConfig.configuration.eventConfiguration.ramThreshold`	integer	No	ram usage value(%) above which alert will be triggered	
`epConfig.configuration.eventConfiguration.flashThreshold`	integer	No	flash usage value(%) above which alert will be triggered	
`epConfig.configuration.eventConfiguration.temperatureThreshold`	integer	No	temperature treshold value above which alert will be triggered	

Request Examples

Add MDM endpoint

```
{
  "command": "config_endpoint",
  "requestId": "1233",
  "epConfig": {
    "operation": "add",
    "configuration": {
      "endpointName": "mgmt_tst",
      "epType": "MGMT",
      "protocol": "MQTT",
      "activate": true,
      "url": "test.example.com",
      "verificationType": "NONE",
      "port": 1883,
      "qosCommon": 1,
      "tenantId": "ZEBRA",
      "mqttParams": {
        "keepAlive": 300,
        "cleanSession": true,
        "reconnectDelayMin": 50,
        "reconnectDelayMax": 500,
        "clientId": "zebra-rfd40-01",
        "username": "username",
        "password": "pass@1234",
        "publishTopics": [
          {
            "topic": "MDM/clients/resp",
            "qos": 1,
            "retain": false
          },
          {
            "topic": "MDM/clients/event",
            "qos": 1,
            "retain": false
          },
          {
            "topic": "MDM/clients/rfid",
            "qos": 0,
            "retain": true
          }
        ],
        "subscribeTopics": [
          {
            "topic": "MDM/clients/cmnd",
            "qos": 0,
```

```
            "retain": false
          }
        ]
      }
    }
  }
}
```

Delete endpoint

```
{
  "command": "config_endpoint",
  "requestId": "1233",
  "epConfig": {
    "operation": "delete",
    "configuration": {
      "endpointName": "mgmt_tst",
      "epType": "MGMT"
    }
  }
}
```

Add data endpoint

```
{
  "command": "config_endpoint",
  "requestId": "1233",
  "epConfig": {
    "operation": "add",
    "configuration": {
      "endpointName": "dataEP",
      "epType": "DATA1",
      "protocol": "MQTT",
      "activate": true,
      "url": "17L11-GG6663-1",
      "verificationType": "NONE",
      "port": 1883,
      "qosCommon": 1,
      "tenantId": "ZEBRA",
      "mqttParams": {
        "keepAlive": 300,
        "cleanSession": true,
        "reconnectDelayMin": 50,
        "reconnectDelayMax": 500,
```

```
        "clientId": "zebra-rfd40-01",
        "username": "username",
        "password": "password"
      }
    }
  }
}
```

Add control endpoint

```
{
  "command": "config_endpoint",
  "requestId": "1233",
  "epConfig": {
    "operation": "add",
    "configuration": {
      "endpointName": "ctrlEP",
      "epType": "CTRL",
      "protocol": "MQTT",
      "activate": false,
      "url": "17L11-GG6663-1",
      "verificationType": "NONE",
      "port": 1883,
      "qosCommon": 1,
      "tenantId": "zebra",
      "mqttParams": {
        "keepAlive": 300,
        "cleanSession": true,
        "reconnectDelayMin": 50,
        "reconnectDelayMax": 500,
        "clientId": "zebra-rfd40-01",
        "username": "mqttuser",
        "password": "password",
        "publishTopics": [
          {
            "topic": "MDM/clients/resp",
            "qos": 1,
            "retain": false
          },
          {
            "topic": "MDM/clients/event",
            "qos": 1,
            "retain": false
          },
          {
```

```
            "topic": "MDM/clients/rfid",
            "qos": 0,
            "retain": true
          }
        ],
        "subscribeTopics": [
          {
            "topic": "MDM/clients/cmnd",
            "qos": 0,
            "retain": false
          }
        ]
      }
    }
  }
}
```

Response

Response Fields

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`command`	string	No		`config_endpoint`
`requestId`	string	No		`abc123`
`apiVersion`	string (enum)	No		`V1.1`
`response`	object	No	Status of the command execution — check `code` to confirm success (0) or identify the error.	

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`response.code`	integer	Yes	Response code indicating success or failure. • **0** — Success • **1** — Command payload accepted • **2** — Invalid payload • **3** — Not able to retrieve information • **4** — Firmware update in progress • **5** — Can't reboot, inventory in progress • **6** — Region is not configured • **7** — Interface is not available • **8** — Insufficient flash size • **9** — File not found • **10** — Configuration already exists • **11** — Inventory in progress • **12** — No radio operation in progress • **13** — Firmware update failed • **14** — Battery too low for firmware update • **15** — WIFI: SSID not found	`0`

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
			• **16** — WIFI: Cannot delete active SSID • **17** — WIFI: SSID missing • **18** — WIFI: SSID already exists • **19** — WIFI: SSID count overflow • **20** — WiFi is not supported • **21** — Certificate not found • **22** — Advanced configuration not set • **23** — Invalid enum value • **24** — Max 32 prefilters limit exceeded • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length • **28** — Tag match pattern length exceeded	
`response.description`	string	Yes	Human-readable description of the response code (e.g. "Success", "Invalid payload").	`Success`

Response Examples

example1

```
{
  "command": "config_endpoint",
  "requestId": "abc123",
  "apiVersion": "V1.1",
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```