get_current_region

> Command: `get_current_region`

Description

Retrieves the **regulatory radio configuration** of the scanner — which country's rules it follows, what frequencies it can use, and power limits.

Response fields:

FIELD	WHAT IT TELLS YOU
`country`	The country this scanner is configured for (e.g. United States, Germany)
`regulatoryStandard`	The radio regulation it follows (e.g. FCC for US, ETSI for Europe)
`frequencyHopping`	Whether the scanner automatically switches between frequency channels
`lbtEnabled`	Whether Listen Before Talk is enabled (required in some regions like Japan/EU)
`maxTxPowerSupported`	Maximum allowed transmit power in dBm
`minTxPowerSupported`	Minimum transmit power in dBm
`channelData`	List of all available frequency channels (in kHz) the scanner can use

Typical use cases:

- Compliance auditing — verify scanners are configured for the correct country before deployment.
- RF planning — check available channels and power limits for site planning.
- Multi-region management — confirm scanners shipped to different countries have the right region settings.

Request

Request Fields

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`command`	string (enum)	Yes	Must be `get_current_region`. Tells the scanner to return its regulatory radio configuration.	`get_current_region`
`requestId`	string	Yes	A unique ID you assign to this request. The scanner echoes it back in the response so you can match requests to responses.	`abc123`

Request Examples

Generated Example

```
{
  "command": "get_current_region",
  "requestId": "abc123"
}
```

Response

Response Fields

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`command`	string	Yes	Echoes back the command name — always `get_current_region` for this response.	`get_current_region`

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`requestId`	string	Yes	Echoes back the requestId you sent, so you can match this response to your original request.	`abc123`
`apiVersion`	string (enum)	Yes	The API version of the IoT Connector responding to this command.	`V1.1`
`currentRegion`	object	No	Regulatory radio configuration — country, regulatory standard, available frequency channels, transmit power limits, frequency hopping, and Listen Before Talk settings. These are factory-set and cannot be changed.	
`currentRegion.frequencyHopping`	boolean	Yes	Indicates whether frequency hopping is enabled in the region.	
`currentRegion.channelData`	array	Yes	List of channel frequencies available in the region, represented as strings.	
`currentRegion.country`	string	Yes	The country for which the device is configured.	`USA`
`currentRegion.lbtEnabled`	boolean	Yes	Specifies if Listen Before Talk (LBT) is enabled for the region.	

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`currentRegion.maxTxPowerSupported`	number	Yes	The maximum transmission power supported in the region, measured in dBm.	`29.2`
`currentRegion.minTxPowerSupported`	number	Yes	The minimum transmission power supported in the region, measured in dBm.	`10.0`
`currentRegion.regulatoryStandard`	string	Yes	The regulatory standard governing the region's transmission rules.	`ETSI_EU_800M_900M_3_CHANNEL`
`response`	object	Yes	Status of the command execution — check `code` to confirm success (0) or identify the error.	

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
`response.code`	integer	Yes	Response code indicating success or failure. • **0** — Success • **1** — Command payload accepted • **2** — Invalid payload • **3** — Not able to retrieve information • **4** — Firmware update in progress • **5** — Can't reboot, inventory in progress • **6** — Region is not configured • **7** — Interface is not available • **8** — Insufficient flash size • **9** — File not found • **10** — Configuration already exists • **11** — Inventory in progress • **12** — No radio operation in progress • **13** — Firmware update failed • **14** — Battery too low for firmware update • **15** — WIFI: SSID not found	`0`

FIELD	TYPE	REQUIRED	DESCRIPTION	EXAMPLE
			• **16** — WIFI: Cannot delete active SSID • **17** — WIFI: SSID missing • **18** — WIFI: SSID already exists • **19** — WIFI: SSID count overflow • **20** — WiFi is not supported • **21** — Certificate not found • **22** — Advanced configuration not set • **23** — Invalid enum value • **24** — Max 32 prefilters limit exceeded • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length • **28** — Tag match pattern length exceeded	
`response.description`	string	Yes	Human-readable description of the response code (e.g. "Success", "Invalid payload").	`Success`

Response Examples

Current region info


```
{
  "command": "get_current_region",
  "requestId": "abc123",
  "apiVersion": "V1.1",
  "currentRegion": {
    "frequencyHopping": true,
    "channelData": [
      "91575",
      "91525",
      "90325",
      "92675",
      "92625",
      "90425",
      "92725",
      "92025",
      "91925",
      "90925",
      "91875",
      "91775",
      "90525",
      "90475",
      "92525",
      "92175",
      "91475",
      "90675",
      "91375",
      "92225",
      "91125",
      "91175",
      "90375",
      "90875",
      "90575",
      "91225",
      "90625",
      "91725",
      "91425",
      "90725",
      "91825",
      "91625",
      "91025",
      "91075",
```

```
      "90775",
      "92475",
      "90975",
      "91975",
      "91675",
      "91325",
      "92375",
      "90825",
      "92575",
      "91275",
      "92425",
      "92125",
      "92075",
      "92275",
      "90275",
      "92325"
    ],
    "country": "United States",
    "lbtEnabled": false,
    "maxTxPowerSupported": 300,
    "minTxPowerSupported": 0,
    "regulatoryStandard": "FCC"
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```