# **Control Software Commands – OCT\_D (v120)**

15.09.2021

Author: Sven Dornbusch dornbusch@mpifr-bonn.mpg.de

# dbbcif(a|b|c|d|e|f|g|h)=[input[,attenuation[,filter[,target\_agc]]]]

Sets configuration for (G)CoMo-IF modules.

Parameters:

synth oen: IF input 1 (no downconversion) (1) or IF input 2 (with downconversion) (2)

selecting input 1 will disable the Synthesizer tone for the downconversion LO

attenuation: agc for automatic gain control

man for manual gain control, retaining last agc value

value between and 0 (0 dB) and 63 (31.5 dB) in stepsize of 0.5 dB

filter: no function for DBBC3, deprecated target agc: target power level for agc mode

#### samplerstats=board\_nr

Prints out and validates sampler statistics (power (gain), offset and delay)

#### core3hstats=board\_nr

Prints out power level and bit statistics of the two FIR filters.

#### time

prints out timestamps (VDIF time) of all boards. Timestamps must be identical.

## checkphase[=board\_nr]

Checks the delay phase calibration of specified ADB3L sampler board, or of all boards if board number is not specified

#### tap=board\_nr,filter\_nr,file\_name

Command to load the filter coefficients for the specified board\_nr (1 to 8) and filter\_nr (1 or 2). The file with the filter coefficients needs to be present in the config folder (like C:\DBBC CONF\OCT D 120\)

#### exit

Exit Client Program.

# reconfigure

Reloads firmware to the Core3H, than reinitializes ADB3L and Core3H from the config files and performes timesynchronization.

### cal\_offset=board\_nr

Calibrates the offset for selected ADB3L. The CoMo connected to this ADB3L should be set to manual attenuation with a power level between 5000 and 10000 to get optimal calibration.

#### cal gain=board nr

Calibrates the gain for selected ADB3L. The CoMo connected to this ADB3L should be set to age with 32000 power target to get optimal calibration.

### cal\_delay=board\_nr

Calibrates the delay for selected ADB3L. The CoMo connected to this ADB3L should be set to agc with 32000 power target to get optimal calibration.

#### core3hinit[=board\_nr]

Reinitializes selected Core3H (starting with 1) from Core3H config files or all Core3H if board parameter not specified.

#### adb3l=command

Sends specified command to adb3l. (selection of ADB3L is included in the command)

### core3h=board\_nr,command

Sends specified command to selected Core3H

## synth=board\_nr,command

Sends specified command to selected GCoMo Synthesizer (1-4)

# pps\_delay

Prints out the delay between internal and external 1PPS for all boards in ns.

# printmainconfig

Prints out the main configuration file on the console

# printadb3lconfig

Prints out the configuration file for the ADB3L boards on the console

# printcore3hconfig=board\_nr

Prints out the configuration file for the specified Core3H on the console

## version

Prints out the version of the Control Software.