BT1
Battery

U1
BrakeLight

SW5
DiffSwitchF

BRK   TAIL   GND

J1
DiffF

SW3
BreakSwitchF

SW4
BreakSwitchR

Wiring Harness

E
Engine

SW1
KillSwitch1

SW2
KillSwitch2

Emergency Kill Circuit