Function name		HLED_vInit	
Arguments	Input	* pLED_Cfg	Pointer to LED configuration to initialize the LED with a certain port and pin
	Output	none	
Return	none		
Description	This function is used to initialize the LED		

Function name		HLED_vTurnLightOn	
Arguments	Input	* pLED_Cfg	Pointer to LED configuration to turn on the LED
	Output	none	
Return	none		
Description	This function is used to turn the LED on		

Function name		HLED_vTurnLightOff	
Arguments	Input	* pLED_Cfg	Pointer to LED configuration to turn off the LED
	Output	none	
Return	none		
Description	This function is used to turn the LED off		

Function name		HLED_vToggleLight	
Arguments	Input	* pLED_Cfg	LED configuration toggle the LED
	Output	none	
Return	none		
Description	This function is used to toggle the LED		

Function name		HLED_vBlinkLED	
Arguments	Input	* pLED_Cfg	LED configuration toggle the LED
		A_u32MilliSecs	number of milli seconds to blink the LED
	Output	none	
Return	none		
Description	This function is used to blink the LED		