

Framo Machine Manual (Sample)

1. Safety Instructions

Always disconnect power before servicing the machine.

Wear appropriate PPE and follow lockout-tagout procedures.

2. Operation

Start sequence: Ensure valves are closed. Open the main inlet slowly and monitor pressure gauges.

Stop sequence: Close inlet, engage bleed valves, switch off main power.

3. Maintenance

Lubrication: Grease the bearings every 250 hours of operation.

Filter change: Replace filters every 1000 operating hours or if differential pressure exceeds recommended limits.

4. Troubleshooting

If unit does not start, check fuses, emergency stop, and control voltage.

If pressure is low, inspect pump for wear and check inlet for blockages.