Periodic Maintenance Schedule

Model: CG50 | Maintenance and Adjustment

No.	Maintenance Item	Odometer Reading (km)			Remarks
		Break-in Period 1000 km or 1 month	Initial 3000 km or 3 months	Every 3000 km or 3 months	
1	Valve clearance ※	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	
2	Spark plug ※	Clean/Adjust	Clean/Adjust	Clean/Adjust	
3	Air filter ※	Clean/Inspect	Clean/Inspect	Clean/Inspect	
4	Fuel filter ※		Replace every 8000-10000 km		
5	Crankcase oil ※	Replace every 300 km	Inspect/Replace once	Inspect/Replace once	
6	Gearbox oil ※		Replace every 1000 km		
7	Oil strainer ※	Clean/Replace	Clean/Replace	Clean/Replace	
8	Brakes ※	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust/Replace	
9	Speedometer gear ※※		Clean and lubricate every 1000 km		
10	Clutch ※	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust/Replace	
11	Aluminum / Spoke wheels ※		Adjust spokes every 300 km		
12	Wheel bearings	Inspect	Clean/Lubricate	Clean/Replace/Lubricate	
13	Steering bearings ※※	Clean/Replace/Lubricate	Clean/Lubricate	Clean/Lubricate	
14	Shock absorbers ※	Inspect	Inspect/Adjust	Inspect/Adjust	
15	Battery ※	Inspect	Charge / Top up electrolyte	Charge / Top up electrolyte	
16	Fasteners	Inspect/Tighten	Inspect/Tighten	Inspect/Tighten/Replace	

Notes:

1. Warm up the engine before draining the oil.
2. ※ : Items that use medium-weight wheel lubricant.

Periodic Maintenance Schedule

Model: CG50 | Maintenance and Adjustment

No.	Maintenance Item	Odometer Reading (km)			Remarks
		Break-in Period 1000 km or 1 month	Initial 3000 km or 3 months	Every 3000 km or 3 months	

3. ※※ : Items recommended for periodic maintenance by authorized service center personnel.

4. When riding in areas with abnormal humidity or high dust levels, the regular maintenance intervals should be appropriately shortened.

Legend: Inspect = Check condition | Inspect/Adjust = Check and adjust as needed | Clean/Adjust = Clean and adjust | Replace = Replace with new part | ※ Special attention item | ※※ Recommended for professional service

This model does not have an OBD system