Maintenance Schedule

JOY125 | Maintenance and Adjustment

No.	Maintenance Item	1000 km	4000 km	7000 km	10000 km	13000 km	16000 km	19000 km	Remarks
1	Fuel system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
2	Control cables	Inspect	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	
*3	Fuel injection system	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel
4	Fuel filter	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Replace with original parts when necessary
5	Air filter element	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Replace with original parts when necessary
6	Spark plug gap	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel
*7	Valve clearance	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjusted by professional personnel
8	Engine oil	Replace	Replace	Replace	Replace	Replace	Replace	Replace	
*9	Oil filter	Replace	Replace	Replace	Replace	Replace	Replace	Replace	
*10	Timing chain	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
*11	Idle speed	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
12	Drive belt	Inspect every 2000 km							
13	Battery	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	If not used for a long time, charge once a month
14	Brake pads	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Friction area thickness must not be less than 2 mm
*15	Brake system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Top up brake fluid when necessary
16	Brake light switch	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
17	Lighting system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
*18	Clutch	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
*19	Shock absorbers	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
20	Bolts / Nuts	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Key bolts: check tightening torque
21	Front and rear tires	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
22	Steering bearings	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel when necessary
23	Coolant	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	

Note: When riding in areas with abnormal humidity or high dust levels, the maintenance intervals should be appropriately shortened.
*Items marked with * can only be adjusted by professional personnel.*

Legend: Inspect = Check condition | Inspect/Adjust = Check and adjust as needed | Replace = Replace with new part | Adjust = Adjust to specification

JOY125 OBD Fault Code List

Diagnostic Trouble Codes (DTC) – Components, Descriptions & Monitoring Strategies

No.	Component / System	Fault Code	Fault Description	Monitoring Strategy	Auxiliary Parameters
1	Cylinder 1 Oxygen Sensor	P0131	Cylinder 1 oxygen sensor signal shorted to low voltage	Monitor oxygen signal voltage of cylinder 1. If voltage is below the limit and duration is exceeded, a fault is determined.	Cylinder 1 O2 sensor voltage, cylinder head/coolant temperature, engine running time
2	Cylinder 1 Oxygen Sensor	P0132	Cylinder 1 oxygen sensor signal shorted to high voltage	Monitor oxygen signal voltage of cylinder 1. If voltage is above the limit and duration is exceeded, a fault is determined.	Cylinder 1 O2 sensor voltage, cylinder head/coolant temperature, engine running time
3	Cylinder 1 Oxygen Sensor Heater	P0031	Cylinder 1 oxygen sensor heater circuit shorted to low voltage	Potential on the heater output circuit differs from the ECM command.	Engine running time
4	Cylinder 1 Oxygen Sensor Heater	P0032	Cylinder 1 oxygen sensor heater circuit shorted to high voltage	Potential on the heater output circuit differs from the ECM command.	Engine running time
5	Cylinder 2 Oxygen Sensor	P0137	Cylinder 2 oxygen sensor signal shorted to low voltage	Monitor oxygen signal voltage of cylinder 2. If voltage is below the limit and duration is exceeded, a fault is determined.	Cylinder 2 O2 sensor voltage, cylinder head/coolant temperature, engine running time
6	Cylinder 2 Oxygen Sensor	P0138	Cylinder 2 oxygen sensor signal shorted to high voltage	Monitor oxygen signal voltage of cylinder 2. If voltage is above the limit and duration is exceeded, a fault is determined.	Cylinder 2 O2 sensor voltage, cylinder head/coolant temperature, engine running time
7	Cylinder 2 Oxygen Sensor Heater	P0037	Cylinder 2 oxygen sensor heater circuit shorted to low voltage	Potential on the heater output circuit of cylinder 2 O2 sensor differs from the expected ECM potential.	Engine running time
8	Cylinder 2 Oxygen Sensor Heater	P0038	Cylinder 2 oxygen sensor heater circuit shorted to high voltage	Potential on the heater output circuit of cylinder 2 O2 sensor differs from the expected ECM potential.	Engine running time
9	Intake Air Pressure Sensor	P0107	Intake pressure sensor circuit low voltage / open	If the raw reading of intake pressure is below the limit, a fault is determined.	Raw reading of the intake air pressure sensor
10	Intake Air Pressure Sensor	P0108	Intake pressure sensor circuit high voltage	Compare the raw reading of intake pressure to the limit. If above the limit, a fault is determined.	Raw reading of the intake air pressure sensor
11	Intake Air Temperature Sensor	P0112	Intake air temperature sensor circuit low voltage	Compare the raw reading of intake air temperature to the limit. If below the limit, a fault is determined.	Raw reading of the intake air temperature sensor
12	Intake Air Temperature Sensor	P0113	Intake air temperature sensor circuit high voltage / open	Compare the raw reading of intake air temperature to the limit. If above the limit, a fault is determined.	Raw reading of the intake air temperature sensor
13	Coolant Temperature Sensor	P0117	Coolant temperature sensor circuit low voltage	Compare the raw reading of the coolant temperature sensor to the limit. If below the limit, a fault is determined.	Raw reading of the coolant temperature sensor
14	Coolant Temperature Sensor	P0118	Coolant temperature sensor circuit high voltage / open	Compare the raw reading of the coolant temperature sensor to the limit. If above the limit, a fault is determined.	Raw reading of the coolant temperature sensor
15	Cylinder 1 Injector	P0261	Cylinder 1 injector circuit low voltage	State of the cylinder 1 injector output circuit differs from the expected state of the ECM.	
16	Cylinder 1 Injector	P0262	Cylinder 1 injector circuit high voltage	State of the cylinder 1 injector output circuit differs from the expected state of the ECM.	

JOY125 OBD Fault Code List

Diagnostic Trouble Codes (DTC) – Components, Descriptions & Monitoring Strategies

No.	Component / System	Fault Code	Fault Description	Monitoring Strategy	Auxiliary Parameters
17	Cylinder 2 Injector	P0264	Cylinder 2 injector circuit low voltage	State of the cylinder 2 injector output circuit differs from the expected state of the ECM.	
18	Cylinder 2 Injector	P0265	Cylinder 2 injector circuit high voltage	State of the cylinder 2 injector output circuit differs from the expected state of the ECM.	
19	Cylinder 1 Ignition Coil	P2300	Cylinder 1 ignition coil circuit low voltage	Potential on the cylinder 1 ignition coil output circuit differs from the expected potential of the ECM.	
20	Cylinder 1 Ignition Coil	P2301	Cylinder 1 ignition coil circuit high voltage	Potential on the cylinder 1 ignition coil output circuit differs from the expected potential of the ECM.	
21	Cylinder 2 Ignition Coil	P2303	Cylinder 2 ignition coil circuit low voltage	Potential on the cylinder 2 ignition coil output circuit differs from the expected potential of the ECM.	
22	Cylinder 2 Ignition Coil	P2304	Cylinder 2 ignition coil circuit high voltage	Potential on the cylinder 2 ignition coil output circuit differs from the expected potential of the ECM.	
23	Crankshaft Position Sensor	P0335	Crankshaft position sensor circuit – no signal	No engine speed signal detected.	
24	Crankshaft Position Sensor	P0336	Crankshaft position sensor circuit – signal interference	Number of teeth detected differs significantly from expected (23X). Fault is determined if excessive.	
25	Throttle Position Sensor	P0122	Throttle position sensor circuit low voltage	Compare the raw reading of the throttle position sensor to the limit. If below the limit, a fault is determined.	Raw reading of the throttle position sensor
26	Throttle Position Sensor	P0123	Throttle position sensor circuit high voltage	Compare the raw reading of the throttle position sensor to the limit. If above the limit, a fault is determined.	Raw reading of the throttle position sensor
27	Vehicle Speed Sensor	P0500	Vehicle speed sensor failure	ECM receives an invalid speed signal from the speed sensor input.	Invalid speed signal identification bit from speed sensor
28	Idle Speed Control System	P0505	Idle speed abnormal	At idle, actual engine speed is lower or higher than the estimated speed by more than the limit. Fault is determined if duration is exceeded.	Engine speed, engine running time
29	System Voltage	P0562	System voltage low	Compare system voltage to the limit. If below the limit, a fault is determined.	System / battery voltage
30	System Voltage	P0563	System voltage high	Compare system voltage to the limit. If above the limit, a fault is determined.	System / battery voltage
31	Fuel Pump Relay	P0231	Fuel pump relay circuit open / low voltage	State of the fuel pump relay output circuit (open or during engine operation) differs from the expected state of the ECM.	
37	Fuel Pump Relay	P0232	Fuel pump relay circuit high voltage	State of the fuel pump relay output circuit differs from the expected state of the ECM.	

JOY125 OBD Fault Code List

Diagnostic Trouble Codes (DTC) – Components, Descriptions & Monitoring Strategies

No.	Component / System	Fault Code	Fault Description	Monitoring Strategy	Auxiliary Parameters
38	Canister Purge Solenoid	P0458	Canister purge control solenoid valve circuit low voltage	State of the canister purge control solenoid circuit differs from the expected state of the ECM.	Canister purge control solenoid duty cycle
39	Canister Purge Solenoid	P0459	Canister purge control solenoid valve circuit high voltage	State of the canister purge control solenoid circuit differs from the expected state of the ECM.	Canister purge control solenoid duty cycle
40	ECM	P0601	ECM checksum / internal error	ECM self-diagnosis detects checksum error.	
41	MIL (Malfunction Indicator Lamp)	P0650	MIL circuit malfunction	MIL circuit status differs from the ECM output state.	ECM output level signal
42	Neutral / Clutch Switch	P0850	Neutral / clutch input circuit fault	While engine is running, ECM monitors neutral switch input. If signal is missing or exceeds limit times, a fault is determined.	Neutral / clutch switch signal
43	Engine Speed Output	P1693	Engine speed output circuit low voltage	State of the engine speed output circuit differs from the desired state of the ECM.	Engine speed signal
44	Engine Speed Output	P1694	Engine speed output circuit high voltage	State of the engine speed output circuit differs from the desired state of the ECM.	Engine speed signal
45	Fuel System (BLM)	P0171	System too lean (BLM adaptation)	BLM learning value is greater than the upper limit and duration is exceeded. Fault is determined.	BLM learning values
46	Fuel System (BLM)	P0172	System too rich (BLM adaptation)	BLM learning value is less than the lower limit and duration is exceeded. Fault is determined.	BLM learning values
47	PE Mode (Power Enrichment)	P0174	PE mode system too lean	PE mode signal is below the limit and duration is exceeded. Fault is determined.	PE mode signal voltage

Notes:

1. Original document OCR quality was poor. Descriptions and strategies have been cleaned and standardized into clear technical English while preserving original meaning.

2. Order numbers follow the source document (some numbers are missing, e.g. 32–36).

3. P0458 / P0459: Original showed 'P0450' and 'P045V' – corrected to standard canister purge codes based on context.

4. BLM = Block Learn Multiplier (long-term fuel trim adaptation). PE = Power Enrichment mode.

5. This table is for reference / service documentation of the JOY125 model.