Maintenance Schedule

XS250 | Maintenance and Adjustment

No.	Maintenance Item	1000 km	4000 km	7000 km	10000 km	13000 km	16000 km	19000 km	Remarks
1	Fuel system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
2	Control cables	Inspect	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	
*3	Fuel injection system	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel
4	Fuel filter	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Replace with original parts when necessary
5	Air filter element	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Replace with original parts when necessary
6	Spark plug gap	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel
*7	Valve clearance	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjusted by professional personnel
8	Engine oil	Replace	Replace	Replace	Replace	Replace	Replace	Replace	
*9	Oil filter	Replace	Replace	Replace	Replace	Replace	Replace	Replace	
*10	Timing chain	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
*11	Idle speed	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
12	Drive belt	Inspect every 2000 km							
13	Battery	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	If not used for a long time, charge once a month
14	Brake pads	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Friction area thickness must not be less than 2 mm
*15	Brake system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Top up brake fluid when necessary
16	Brake light switch	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
17	Lighting system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
*18	Clutch	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
*19	Shock absorbers	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
20	Bolts / Nuts	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Key bolts: check tightening torque
21	Front and rear tires	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
22	Steering bearings	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel when necessary
23	Coolant	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	

Note: When riding in areas with abnormal humidity or high dust levels, the maintenance intervals should be appropriately shortened.
*Items marked with * can only be adjusted by professional personnel.*

Legend: Inspect = Check condition | Inspect/Adjust = Check and adjust as needed | Replace = Replace with new part | Adjust = Adjust to specification

XS250 Series OBD Fault Code List

Diagnostic Trouble Codes (DTC)

No.	Fault Code	Description of DTC
1	P0118	Engine Coolant Temperature Sensor Circuit High / Open Circuit
2	P0117	Engine Coolant Temperature Sensor Circuit Low
3	P0116	Engine Coolant Temperature Sensor signal performance
4	P1116	Engine Coolant Temperature Sensor signal out of range
5	P0335	Crankshaft Position Sensor "A" Circuit
6	P2300	Ignition Coil "A" Primary Control Circuit Low / Open Circuit
7	P2303	Ignition Coil "B" Primary Control Circuit Low / Open Circuit
8	P0123	Throttle Position Sensor/Switch "A" Circuit High
9	P0122	Throttle Position Sensor/Switch "A" Circuit Low / Open Circuit
10	P0232	Fuel Pump circuit short High
11	P0231	Fuel Pump circuit short Low / Open Circuit
12	P0601	Internal Control Module Memory Checksum Error
13	P0262	Cylinder 1 Fuel Injector "A" Circuit High
14	P0261	Cylinder 1 Fuel Injector "A" Circuit Low / Open Circuit
15	P0265	Cylinder 2 Fuel Injector "B" Circuit High
16	P0264	Cylinder 2 Fuel Injector "B" Circuit Low/Open Circuit
17	P0108	Manifold Absolute Pressure Sensor Circuit High
18	P0107	Manifold Absolute Pressure Sensor Circuit Low/Open Circuit
19	P3106	Manifold Absolute Pressure Sensor rationality at low TPS
20	P0105	Manifold Absolute Pressure Sensor signal stuck
21	P0113	Intake Air Temperature Sensor Circuit High / Open Circuit
22	P0112	Intake Air Temperature Sensor Circuit Low

XS250 Series OBD Fault Code List

Diagnostic Trouble Codes (DTC)

No.	Fault Code	Description of DTC
23	P0111	Intake Air Temperature Sensor signal stuck
24	P0114	Intake Air Temperature Sensor Circuit Intermittent
25	P0132	O2 Sensor Circuit High Voltage Bank 1 Sensor 1
26	P0131	O2 Sensor Circuit Low Voltage Bank 1 Sensor 1 / Open Circuit
27	P0138	O2 Sensor Circuit High Voltage Bank 2 Sensor 1
28	P0137	O2 Sensor Circuit Low Voltage Bank 2 Sensor 1 / Open Circuit
29	P2195	O2 Sensor Signal Lean at PE Bank 1 Sensor 1
30	P2197	O2 Sensor Signal Lean at PE Bank 2 Sensor 1
31	P014D	O2 Sensor Slow Response - Lean to Rich Bank 1 Sensor 1
32	P014C	O2 Sensor Slow Response - Rich to Lean Bank 1 Sensor 1
33	P014F	O2 Sensor Slow Response - Lean to Rich Bank 2 Sensor 1
34	P014E	O2 Sensor Slow Response - Rich to Lean Bank 2 Sensor 1
35	P0031	O2 Sensor Heater Control Circuit Low Bank 1 Sensor 1 / Open Circuit
36	P0032	O2 Sensor Heater Control Circuit High Bank 1 Sensor 1
37	P0037	O2 Sensor Heater Control Circuit Low Bank 2 Sensor 1 / Open Circuit
38	P0038	O2 Sensor Heater Control Circuit High Bank 2 Sensor 1
39	P00D1	O2 Sensor Heater current low Bank 1 Sensor 1
40	P00D3	O2 Sensor Heater current low Bank 2 Sensor 1
41	P0300	Random/Multiple Cylinder Misfire Detected
42	P0301	Cylinder 1 Misfire Detected
43	P0302	Cylinder 2 Misfire Detected
44	P0505	Idle air control system error

XS250 Series OBD Fault Code List

Diagnostic Trouble Codes (DTC)

No.	Fault Code	Description of DTC
45	P0562	System Voltage Low
46	P0563	System Voltage High
47	P2A01	O2 Sensor Circuit Range/Performance Bank 1 Sensor 2
48	P013B	O2 Sensor Slow Response - Lean to Rich Bank 1 Sensor 2
49	P00D2	HO2S Heater Control Circuit Range/Performance Bank 1 Sensor 2
50	P1037	O2 Sensor Circuit Low Voltage Bank 1 Sensor 2
51	P1038	O2 Sensor Circuit High Voltage Bank 1 Sensor 2
52	P1137	O2S Heater Control Circuit High Bank 1 Sensor 2
53	P1138	O2S Heater Control Circuit Low Bank 1 Sensor 2
54	P0420	Catalyst System Efficiency Below Threshold Bank 1

Notes:

1. Model: XS250 Series

2. Priority column is taken from the source table (1 / 2 / 3).

3. All descriptions are kept as in the original English source.

4. Suitable for service documentation and diagnostic reference.