# Maintenance Schedule

## XS800Series | Maintenance and Adjustment

| No. | Maintenance Item | 1000 km | 4000 km | 7000 km | 10000 km | 13000 km | 16000 km | 19000 km | Remarks |
|---|---|---|---|---|---|---|---|---|---|
| 1 | Fuel system | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Adjust when necessary |
| 2 | Control cables | Inspect | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | |
| *3 | Fuel injection system | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Adjusted by professional personnel |
| 4 | Fuel filter | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Replace with original parts when necessary |
| 5 | Air filter element | Adjust | Adjust | Adjust | Adjust | Adjust | Adjust | Adjust | Replace with original parts when necessary |
| 6 | Spark plug gap | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Adjusted by professional personnel |
| *7 | Valve clearance | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Adjusted by professional personnel |
| 8 | Engine oil | Replace | Replace | Replace | Replace | Replace | Replace | Replace | |
| *9 | Oil filter | Replace | Replace | Replace | Replace | Replace | Replace | Replace | |
| *10 | Timing chain | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Adjust when necessary |
| *11 | Idle speed | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Adjust when necessary |
| 12 | Drive belt | Inspect every 2000 km | | | | | | | |
| 13 | Battery | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | If not used for a long time, charge once a month |
| 14 | Brake pads | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Friction area thickness must not be less than 2 mm |
| *15 | Brake system | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Top up brake fluid when necessary |
| 16 | Brake light switch | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | |
| 17 | Lighting system | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | |
| *18 | Clutch | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | |
| *19 | Shock absorbers | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | |
| 20 | Bolts / Nuts | Adjust | Adjust | Adjust | Adjust | Adjust | Adjust | Adjust | Key bolts: check tightening torque |
| 21 | Front and rear tires | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | Inspect | |
| 22 | Steering bearings | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Adjusted by professional personnel when necessary |
| 23 | Coolant | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | Inspect/Adjust | |

*Note: When riding in areas with abnormal humidity or high dust levels, the maintenance intervals should be appropriately shortened.*
*Items marked with * can only be adjusted by professional personnel.*

*Legend: Inspect = Check condition | Inspect/Adjust = Check and adjust as needed | Replace = Replace with new part | Adjust = Adjust to specification*

# XS800 Series OBD Fault Code List

## Diagnostic Trouble Codes (DTC)

| No. | Fault Code | Fault Description |
|---|---|---|
| 1 | P0131 | Cylinder 1 oxygen sensor signal shorted to low voltage |
| 2 | P0132 | Cylinder 1 oxygen sensor signal shorted to high voltage |
| 3 | P0031 | Cylinder 1 oxygen sensor heater circuit shorted to low voltage |
| 4 | P0032 | Cylinder 1 oxygen sensor heater circuit shorted to high voltage |
| 5 | P0137 | Cylinder 2 oxygen sensor signal shorted to low voltage |
| 6 | P0138 | Cylinder 2 oxygen sensor signal shorted to high voltage |
| 7 | P0037 | Cylinder 2 oxygen sensor heater circuit shorted to low voltage |
| 8 | P0038 | Cylinder 2 oxygen sensor heater circuit shorted to high voltage |
| 9 | P0107 | Intake air pressure sensor circuit low voltage / open |
| 10 | P0108 | Intake air pressure sensor circuit high voltage |
| 11 | P0112 | Intake air temperature sensor circuit low voltage |
| 12 | P0113 | Intake air temperature sensor circuit high voltage or open |
| 13 | P0117 | Coolant temperature sensor circuit low voltage |
| 14 | P0118 | Coolant temperature sensor circuit high voltage or open |
| 15 | P0261 | Cylinder 1 injector circuit low voltage |
| 16 | P0262 | Cylinder 1 injector circuit high voltage |
| 17 | P0264 | Cylinder 2 injector circuit low voltage |
| 18 | P0265 | Cylinder 2 injector circuit high voltage |
| 19 | P2300 | Cylinder 1 ignition coil circuit low voltage |
| 20 | P2301 | Cylinder 1 ignition coil circuit high voltage |
| 21 | P2303 | Cylinder 2 ignition coil circuit low voltage |
| 22 | P2304 | Cylinder 2 ignition coil circuit high voltage |

# XS800 Series OBD Fault Code List

## Diagnostic Trouble Codes (DTC)

| No. | Fault Code | Fault Description |
|---|---|---|
| 23 | P0335 | Crankshaft position sensor circuit – no signal |
| 24 | P0336 | Crankshaft position sensor circuit – signal interference |
| 25 | P0122 | Throttle position sensor circuit low voltage |
| 26 | P0123 | Throttle position sensor circuit high voltage |
| 27 | P0500 | Vehicle speed sensor failure |
| 28 | P0505 | Idle speed abnormal |
| 29 | P0562 | System voltage low |
| 30 | P0563 | System voltage high |
| 31 | P0231 | Fuel pump relay circuit open / low voltage |
| 32 | P0232 | Fuel pump relay circuit high voltage |
| 33 | P0458 | Canister purge control solenoid valve circuit low voltage |
| 34 | P0459 | Canister purge control solenoid valve circuit high voltage |
| 35 | P0601 | ECM checksum error |
| 36 | P0650 | MIL circuit fault |
| 37 | P0850 | Neutral / clutch input fault |
| 38 | P1693 | Engine speed output circuit low voltage |
| 39 | P1694 | Engine speed output circuit high voltage |
| 40 | P0171 | System too lean |
| 41 | P0172 | System too rich |
| 42 | P0174 | PE mode system too lean |

**Notes:**

*1. Model: XS800 Series*

*2. Descriptions translated from Chinese source table into clear technical English.*

*3. PE = Power Enrichment mode. MIL = Malfunction Indicator Lamp.*

*4. Suitable for service documentation and diagnostic reference.*