Maintenance Schedule

XS250 | Maintenance and Adjustment

No.	Maintenance Item	1000 km	4000 km	7000 km	10000 km	13000 km	16000 km	19000 km	Remarks
1	Fuel system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
2	Control cables	Inspect	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	
*3	Fuel injection system	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel
4	Fuel filter	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Replace with original parts when necessary
5	Air filter element	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Replace with original parts when necessary
6	Spark plug gap	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel
*7	Valve clearance	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjusted by professional personnel
8	Engine oil	Replace	Replace	Replace	Replace	Replace	Replace	Replace	
*9	Oil filter	Replace	Replace	Replace	Replace	Replace	Replace	Replace	
*10	Timing chain	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
*11	Idle speed	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Adjust when necessary
12	Drive belt	Inspect every 2000 km							
13	Battery	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	If not used for a long time, charge once a month
14	Brake pads	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Friction area thickness must not be less than 2 mm
*15	Brake system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Top up brake fluid when necessary
16	Brake light switch	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
17	Lighting system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
*18	Clutch	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
*19	Shock absorbers	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
20	Bolts / Nuts	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Adjust	Key bolts: check tightening torque
21	Front and rear tires	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect	
22	Steering bearings	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Adjusted by professional personnel when necessary
23	Coolant	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	Inspect/Adjust	

Note: When riding in areas with abnormal humidity or high dust levels, the maintenance intervals should be appropriately shortened.
*Items marked with * can only be adjusted by professional personnel.*

Legend: Inspect = Check condition | Inspect/Adjust = Check and adjust as needed | Replace = Replace with new part | Adjust = Adjust to specification