FPC pin#'s	14	15	17	18		20		21	23	24
3			F8	Delete		[D	Arrow-Right	Pad 4
4	Quote	End		;		Back Spac	e	S	Arrow-Down]
5	Cntrl-R									Cntrl-L
6	,	F6	F7	F5		Caps-Lock		Pad 6	K	Pad *
7		F9	Pad 8					W	Arrow-Up	Pg-Dn
8	V	Т	G		5		4	N	Υ	Ε
9	Pad 5	F11	\	F10			9	0	L	
10	С	F4	F3		8		3	В		Space
11		Tab	Fn	`		Pad 2		-	1	
12	Χ	F1	F2		0		2	M	Н	Z
13	/	F12		Esc		Р		Α	Arrow-Left	=
16		GUI	Pad 9	Pad 7		Home		Pg-Up	Num-Lock	Pad 0
19	Alt-R									Alt-L
22	Shift-R									Shift-L
25	Pad Enter	Enter	Pad +	Pad 3		Pad .		Pad 1	Pad /	Pad -
26	1	F	R		6		7	U	J	Q



