
TP-LINK CONFIGURATION GUIDE







1. Login with default IP **192.168.0.1**




2. Go to VLAN.




3. Go to **802.1Q VLAN.**




4. Select **Enable** and click on **Apply**.




5. Click on OK.




- 6. Enter management for Switch: 97 and give VLAN name for reference eg. Management.
 - a. Click on Select for Port No. 1 and 8 and Add/Modify.




- 7. Enter customer VLAN ID e.g. 102 give VLAN Name for reference e.g. Client.
 - a. Select Untagged 2 port for customer end device and select Tagged 1 and 8 port for uplink cable.
 - b. Click on Add/Modify.




8. Verify the configuration and click on Apply.




- 9. Enter Switch management VLAN: 97
 - a. Select port 1 and 8.
 - b. Click on Apply.




- 10. Enter Customer's VLAN e.g. 102.
 - a. Select port 2.
 - b. Click on Apply.



11. Verify the configuration.




- 12. Go to Switching >> IGMP Snooping.
 - a. Disable IGMP Snooping and Apply.




13. Go to System >> System Info.

a. Enter customer name and TP LINK Sr. No. for reference in **Device Description** e.g. **ICICI_210000001** and click on **Apply**.




14. Click on Save Config.




15. Go to System >> IP Setting


- a. Enter IP, Subnet Mask and Default Gateway of VLAN 97 range.
- b. Click on Apply.




16. Change your system's IP as per Switch IP.




17. Login again with new switch IP.



- 18. Go to System >> System Tools >> System Reboot.
 - a. Select Save Config and click on Reboot.



19. Verify the configuration again.



Thank You

Prepared by

Enterprise Delivery Team