Pump manual

The operating temperature must stay below 80 degrees Celsius.
Maximum pressure is 6 bar.

Alarm codes

Alarm E12 means overheating. Stop the pump and call the service.