

Bardac Drive Download Procedure

Connect your laptop to the newly installed Bardac Drive with the Ethernet cable provided.

1. Check Bardac Drive communication and baud rates:
 - a. RDDDRRDRUUU.....ensure it is in ASC II Comm; if not use up or down key to change.
 - b. RDDDRRRU.....ensure it is in 19200; if not use up or down key to change.
2. Click RURU on drive to Save info.
3. Open Bardac Drive Icon.
4. (No Password)....click on "Accept".
5. Click on "Directory" and scroll down to "Discover on serial port".
6. Right arrow and select PL Series DC Drive.
7. Click on "OK".

*Note: To find any parameters....right click drive icon.

Importing or Exporting Parameters

8. Right click Drive icon....scroll down to "Import Device Data".
9. Select file needed (most current).
10. Click "OK".
11. Right click icon again and scroll down to "Save all parameters to EEPROM".
12. Go back and enter Armature Current and Field Current settings manually at Drive:
 - a. RRURR...ensure setpoint for Armature or adjust by using the up or down key.
 - b. LDDR.....ensure setpoint for field current or adjust by using up or down key.
13. Use LLLL to get all the way back out.
14. Use RURU to SAVE all params on drive.
15. You are now finished at the drive.....close the Bardac Icon on the by exiting.
*Do NOT save changes to PC file unless changes were made to the original settings.....Close the file and close the Bardac program.