

Calibration procedure of Line 3 Contact roll position

Date: 12/16/2025

1. Enter manual mode on Magelis Panel.
On magelis Panel: Press Page 4 "Control Mode" and then elect F10 "Mode Select" to swap to manual mode.
2. Enter into "Configured Parameters" page at Siemens OP panel. "Service" will be highlighted.
3. Press "Jog Forward" button to move contact roll all the way toward the core.
4. Turn off motor power at new Bruckner cabinet.
Go to new Bruckner cabinet which is beside Tension separation roll cabinet; turn off Q012/391M4 & Q022/391M4 breakers.
5. Adjust Jack Screws on both sides so paper slides between contact roll and core.
Clockwise is "open gap". Counterclockwise is "close gap".
6. Press "Calibrate Now" button on Siemens OP panel for Drive Side and Operator Side.
Password is "BKTDS".
7. Turn off AC drives power at new Bruckner cabinet.
Go to new Bruckner cabinet; turn off F015/391M4 & F025/391M4 breakers.
8. Ensure two AC drives go off.
9. Turn on AC drives power at new Bruckner cabinet.
Go to new Bruckner cabinet; turn on F015/391M4 & F025/391M4 breakers.
10. Turn on motor power at new Bruckner cabinet
Go to new Bruckner cabinet which is beside Tension separation roll cabinet; turn on Q012/391M4 & Q022/391M4 breakers.
11. Acknowledge faults on AC drives by pressing "P" at drive.
It will show "9" on drive display, which means ready to go.
12. Press "Calibrate Now" button again for Drive / Operator Side on Siemens OP panel.
13. Verify position readings are "408mm" on Drive Side and Operator Side.
14. Press "Exit" at Siemens OP panel.
15. Turn off breaker and on to reboot Siemens OP panel and Exit Calibration function.
Go to new Bruckner cabinet which is beside Tension separation roll cabinet; turn off and on breakers F020/390C3.

Calibration procedure of Line 3 Contact roll position

Date: 12/16/2025

Siemens OP panel

