

Entering Parameters Into Dynisco UPR 900 Controller

Press the Enter button and hold down while pressing the Up button will get you into Main Menu

Go to "Setup Wizard" push enter

Unlock code with Up key and enter 10 and push Enter

Input type- "Strain gauge"

Engineering unit- "Psi"

Decimal point position- "1234"

Scale input range

Upper limit- "5000", "3000" or "1500"

Lower limit- "0"

Linear output A type- "4-20 MA"

Linear output A usage- "Retransmit input 1"

Enter value for output 1

Lower transmit limit- "0"

Upper transmit limit- "5000", "3000", or "1500"

Output 1 usage- "Alarm 1 direct"

Output 2 usage- "Alarm 1 direct"

Alarm 1 type- "Process High"

Process High

Alarm 1 value- "4000", "2400" or "1200"

Alarm 2 type- Unused

Alarm 3 type- Unused

Set up complete push enter