

## **AB PLC 500 Upload/Download Procedure**

### **I. To make sure communication is working .**

1. Power up PC and connect 9pins D-sub communication cable from PC to AB PLC 500.
2. Open RSlinx professional program.
3. Click “communications” and select “configure drivers”.
4. Select “AB\_DF1-1 DH+Sta:0 COM1 : RUNNING” Then Click “configure” button.
5. Check “ comm port :COM1” and “device : SLC-CH0”
6. Click “ Auto-configure” to make sure the communication is successfully .
7. Click “OK” if communication is successfully.
8. Select “ RS-232 DF1 devices “ under Available Driver type and click” Add new” if AB DF1-1 DH is not in configured drives . Repeat item4.

### **II. Down loading from PC to PLC .**

1. Open “ RSLogix 500 “
2. Click on “file > Open” The software displays a window that allows you to choose a project to open.
3. Select “ download “ on Offline bar

### **III. Uploading from PLC to PC**

1. Re-open “RSLogix 500”.
2. Select “ Upload” on Offline bar
3. Click on” file > Save As “ The software displays a window that allows you to save a project.

## **AB PLC 5000 Upload/Download Procedure**

### **I. Down loading from PC to PLC .**

4. Open “ RSLogix 5000 “
5. Click on “file > Open” The software displays a window that allows you to choose a project to open.
6. Select “ download “ on communication bar

### **II. Uploading from PLC to PC**

- a. Re-open “RSLogix 5000”.
- b. Select “ Upload” on communication bar
- c. Click on” file > Save As “ The software displays a window that allows you to save a project.