CHAPTER I

Description of Token Block Instruments

- Note: (i) The term 'Station Master' wherever used in this Manual, also applies to Assistant Station Master, Cabin Assistant Station Master, and any other competent staff who may, for the time being, be in charge of Block Working.
 - (ii) For the purpose of explaining the instructions in this Manual, 'W', 'X', 'Y' and 'Z' have been taken as consecutive block stations.

1.1. Provision of token block instruments:

- a) The types of token block instruments in use on the single line sections of this railway are:
 - i) Neale's Ball token instrument.
 - ii) Neale's Tablet token instrument.
- b) The sections of the line provided with these token block instruments are notified in the Working Time Table.

1.2. Description of Neale's Ball token instrument:

(See Figure No.1 at the end of this Chapter)

a)	Token receiver cover	The token receiver cover should be
		lifted for inserting the token into
		the instrument.
b)	Token receiver handle.	This should be turned for a token to
		fall into the instrument
c)	Galvanometer	This indicates the flow of current
		from one instrument to another
d)	Telephone	This is provided in conjunction with
		the instrument for communication
		with the station at the other end of
		the block section

	Code' signals and operation of
'Oper	
Pro-	ating Handle'.
f) Operating Handle This	can be set to 'Line Closed' or
'TGT'	or 'TCF' positions. It can be
turne	d to any one of these
positi	ions, when a prolonged beat is
receiv	ved from the station at the
other	end of the block section
g) Token Exit A Tol	ken comes out through this
exit v	when the 'Operating Handle' is
turne	d to the 'TGT' position.
h) Token Windows This	indicates the availability of
token	is in the instrument.
j) Bell This i	responds to Bell Code signals
given	by the station at the other
end o	of the block section. At
statio	ons provided with more than
one in	nstrument, different bells or
gongs	s with distinct sound are
provi	ded to identify the individual
instru	ument
	is provided where the Last
in 'Train Going To' position	Signal is controlled
	anically through the block
instru	uments. The key can be
releas	sed only when the block
handl	le is in 'Train Going To'
positi	ion and is used for controlling
the La	ast Stop Signal lever. This key
can a	lso be used for controlling the
slip si	iding points.