nooelec neSDR SMArT SDR Zidag Software Driver Installation

Completed — 4.9 MB https://support.nooelec.com/hc/en-us/articles/360005298053-NESDR-Installation-Guide


This driver is required to use RTL-SDR compatible SDR software on Windows operating systems.

<u>Click here to download the latest version of Zadig, used to install the SDR driver for your NESDR</u>. The driver is required to use RTL-SDR compatible SDR software on Windows operating systems.

1. Plug your NESDR into an available USB port

0 devices found.


2. Open the 'NESDR Driver Installer', Zadig, by clicking the link above





Zadig 2.2.689

nooelec neSDR SMArT SDR **Zidag Software Driver Installation**




















QUICK System Verification using Load/Open on nooelec SAWbirdH1 LNA Input

w/ RF Gain max @ 42 dB







AirSpy SDR# Kaminski IF_avg Plugin > HLine3D **Rinearn Graphics** - RTL-SDR USB d Convert IF_Avg -> .CSV Version: ja_ap_varMX8_intLogo_11jan25_01 mcpySE_D40_25Oct24_intlogo_CSN_mxb_dBScaled.csv 001.420.405.000 8.14E-2 Offset Tuning
RTL AGC
Tuner AGC
RF Gain 36,4 dB Choose Dir 0.802 90 HLine 0.43 1,420 000 G 1,420 500 G 1,421 000 G 5.84E-2 -3.0E-2 1419.655 1420.404 1420.778 1421.1