

1. When in Trouble

Protective Function (What is Error Code ?)

<List of error code No.>

Error code		Protective function	Attribute			Detail page
Main	Sub		History	Can be cleared	Immediate stop ³	
11	0	Under voltage protection of control power supply		○		6-4
12	0	Over-voltage protection	○	○		
13	0	Main power supply under-voltage protection (between P and N)		○		6-5
	1	Main power supply under-voltage protection (AC interception detection)		○	○	
14	0	Over-current protection	○			6-6
	1	IPM error protection	○			
15	0	Over-heat protection	○		○	6-7
	1	Encoders abnormal overheat protection	○		○	
16	0	Over-load protection	○	○ ^{*1}	Switchable ²	6-8
	1	Torque saturation error protection	○	○		
18	0	Over-regeneration load protection	○		○	6-9
	1	Regeneration Tr error protection	○			
21	0	Encoder communication disconnect error protection	○			6-10
	1	Encoder communication error protection	○			
23	0	Encoder communication data error protection	○			6-11
24	0	Position deviation excess protection	○	○	○	
	1	Speed deviation excess protection	○	○	○	6-12
25	0	Hybrid deviation excess error protection	○		○	
26	0	Over-speed protection	○	○	○	6-13
	1	2nd over-speed protection	○	○		
27	0	Command pulse input frequency error protection	○	○	○	6-14
	1	Absolute clear abnormal protection	○			
28	0	Limit of pulse replay error protection	○	○	○	6-15
	2	Command pulse multiplier error protection	○	○	○	
29	0	Deviation counter overflow protection	○	○		6-16
	1	counter overflow protection 1	○			
31	2	Counter overflow error protection 2	○			6-17
	0	Safety function error protection 1	○			
33	2	Safety function error protection 2	○			6-18
	0	IF overlaps allocation error 1 protection	○			
34	1	IF overlaps allocation error 2 protection	○			6-19
	2	IF input function number error 1 protection	○			
35	3	IF input function number error 2 protection	○			6-20
	4	IF output function number error 1 protection	○			
36	5	IF output function number error 2 protection	○			6-21
	6	Counter clear allocation error	○			
37	7	Command pulse inhibition input allocation error	○			6-22
	0	Motor working range setup error protection	○	○		
38	0 to 1	EEPROM parameter error protection				6-23
39	0 to 2	EEPROM check code error protection				
40	0	Drive prohibition input protection		○		6-24

Error code		Protective function	Attribute			Detail page
Main	Sub		History	Can be cleared	Immediate stop ³	
39	0	Analog input1 excess protection	○	○	○	6-11
	1	Analog input2 excess protection	○	○	○	
40	2	Analog input3 excess protection	○	○	○	6-12
	0	Absolute system down error protection	○	○ ^{*4}		
41	0	Absolute counter over error protection	○			6-13
42	0	Absolute over-speed error protection	○	○ ^{*4}		
44	0	Absolute single turn counter error protection	○			6-14
45	0	Absolute multi-turn counter error protection	○			
47	0	Absolute status error protection	○			6-15
	0	External scale connection error protection	○			
50	1	External scale communication error protection	○			6-16
	2	External displacement sensor communication data error protection	○			
51	0	External scale status 0 error protection	○			6-17
	1	External scale status 1 error protection	○			
52	2	External scale status 2 error protection	○			6-18
	3	External scale status 3 error protection	○			
53	4	External scale status 4 error protection	○			6-19
	5	External scale status 5 error protection	○			
55	0	A-phase connection error protection	○			6-20
	1	B-phase connection error protection	○			
70	2	Z-phase connection error protection	○			6-21
	0	U-phase current detector error protection	○			
72	1	W-phase current detector error protection	○			6-22
	0	Thermal Error protection	○			
80	0	Modbus communication timeout protection	○			6-23
87	0	Compulsory alarm input protection		○	○	
92	0	Encoder data recovery abnormal protection	○			6-24
	1	External scale data recovery error protection	○			
93	3	Multi-turn data upper-limit value disagreement error protection	○			6-25
	0	Parameter setup error protection 1	○			
94	1	Block data setting error protection	○	○		6-26
	2	Parameter setup error protection 2	○			
95	3	External scale connection error protection				6-27
	8	Parameter setup error protection 6				
96	0	Block operation error protection	○	○		6-28
	2	Return to origin error protection	○	○		
97	0 to 4	Motor automatic recognition error protection				6-29
	2	Control unit error protection	○			
Other number	0					6-30
	Other error		○			

Note

History...The error will be stored in the error history.

Can be cleared...To cancel the error, use the alarm clear input (A-CLR).

If the alarm clear input is not effective, turn off power, remove the cause of the error and then turn on power again.

Immediate stop...Instantaneous controlled stop upon occurrence of an error.

(Setting of "Pr.5.10 Sequence at alarm" is also required.)

*1 : When Err16.0 "Overload Protection 1" is activated, error can be cleared about 10 seconds after the occurrence.

*2 : When Err40.0 "Absolute System Down Error protection," or Err42.0 "Absolute Overspeed Protection" occurs, the error is unable to be cleared unless Absolute Clear is performed.

*3 : Immediate stop refers to alarms which result in an immediate stop when setting is made to 4 to 7 in Pr5.10 "Sequence at alarm" are shown. For the detail of an immediate stop, see P.4-55 "Sequence at alarm."

*4 : Err 16.0 "Overload protection," can be switched to responsive/non-responsive by switching bit 11 of "Function expansion setting 2" of Pr 6.47. Set to non-responsive at time of shipment.