

PUMP P-101 MAINTENANCE MANUAL

Equipment: Centrifugal Pump P-101

Location: Plant A, Unit 3

Last Updated: January 2026

MAINTENANCE SCHEDULE:

- Daily: Check motor temperature and vibration levels
- Weekly: Inspect mechanical seals and bearings
- Monthly: Lubricate bearings with grease type SAE 30
- Quarterly: Replace mechanical seals if worn
- Annually: Full inspection of all components

COMMON FAILURES:

1. Bearing failure - caused by lack of lubrication
Solution: Lubricate every 30 days
2. Seal leakage - caused by wear or misalignment
Solution: Replace seals every 6 months
3. Cavitation - caused by low suction pressure
Solution: Check inlet valve and strainer

SAFETY PROCEDURES:

- Always isolate power before maintenance
- Use lockout tagout procedure
- Wear PPE including gloves and safety glasses
- Never operate pump without guards in place

SPECIFICATIONS:

- Flow Rate: 500 LPH
- Pressure: 10 bar
- Motor Power: 5 kW
- RPM: 1450