AirNav Radar

Welcome, **Guest**. Please login or register.
Did you miss your activation email?
Forever Login
Login with username, password and session length

Search

Home Help Search Login Register

Author | Topic: How to Install rbfeeder on Raspberry Pi OS Trixie (debian

0 Members and 1 Guest are viewing this topic.

abcd567
Hero Member

Posts: 923
CYYZ - Toronto

How to Install rbfeeder on Raspberry Pi OS Trixie (debian 13)

« **on:** October 03, 2025, 10:28:16 PM »

Raspberry Pi OS Trixie (Debian 13) was release on Oct 01, 2025. The image can be downloaded from here:

https://www.raspberrypi.com/software/operating-systems/

Tje Trixie image is included in Raspberry Pi Imager also, which can download and write the image to microSD card in one go.

Please see attached screenshots.

Please see next post for method to install rbfeeder & mlat-client on Raspberry Pi OS Trixie.

« Last Edit: October 11, 2025, 01:25:53 AM by abcd567 » Logged

abcd567
Hero Member

Re: Raspberry Pi OS Trixie (debian 13) Released

« **Reply #1 on:** October 10, 2025, 11:58:05 PM »

Posts: 923

CYYZ - Toronto

The standard method to install rbfeeder on Raspberry Pi is to run following command:

Code: [Select]

```
sudo bash -c "$(wget -O - http://apt.rb24.com/inst_rbfeeder.sh)"
```

However as the Radarbox24 feeder is NOT **(yet)** available for Trixie, the above installation script fails on Trixie.

Temporary Workaround for Installation of rbfeeder on Raspberry Pi OS Trixie (TESTED , Works OK)

NOTE: This workaround works ok on 64-bit (arm64) OS, but fails on 32-bit (armhf) OS

Following is the workaround for installing rbfeeder on RPi running OS Trixie. It is valid till such time RB24 makes their script & package avaiable for Trixie, in which case above noted installation command will succeed in installing rbfeeder on Trixie also.

(a) Install tools

Code: [Select]

```
sudo apt install dirmngr gnupg
```

(b) Set apt

Note: Following three (3) commands are very long. Scroll right to see and copy these in full

Code: [Select]

```
keyserver.ubuntu.com --recv-keys F2A8428D3C354953

rmor F2A8428D3C354953 | sudo gpg --dearmor -o /etc/apt/keyrings/rb24.gpg

d-by=/etc/apt/keyrings/rb24.gpg] https://apt.rb24.com/ bookworm main" | s
```

(c) Update apt and install rbfeeder:

Code: [Select]

```
sudo apt update

sudo apt install rbfeeder
```

(d) After installation is completed, signup as follows:

Code: [Select]

```
sudo systemctl restart rbfeeder
```

After a few seconds, RBFeeder will connect to the AirNav servers and you can view your sharing-key with this command:

Code: [Select]

```
sudo rbfeeder --showkey
```

If you already have a sharing-key from a previous installation, you can set the same key using this command:

Code: [Select]

```
sudo rbfeeder --setkey ‹your sharing key›
```

(e) Activate decoder dump1090-rb

If you are not able to install a decoder such as dump1090-fa or readsb etc, no problem, the rbfeeder installation as above, includes installation of its builtin decoder **dump1090-rb**. You can check it's existance by following command

Code: [Select]

```
ls -l /usr/bin/dump1090-rb
```

By default this decoder is inactive. However you can activate it by following method:

Open file "rbfeeder.ini" for editing by following command:

Code: [Select]

```
sudo nano /etc/rbfeeder.ini
```

In the file opened, at top you will see this line:

network_mode=**true**

Change true to false, so the line becoms like below:

network_mode=**false**

Save the file (Ctrl+O)

Reboot RPi

Code: [Select]

```
sudo reboot
```

After reboot, check sttatus

Code: [Select]

```
sudo systemctl status rbfeeder
```

(f) Install mlat-client

The installation of mlat-client from RB24 repository by command sudo apt install mlat-client fails with following error message:
mlat-client:arm64 Depends python3 (< 3.12) but this is not installable (Trixie apt provides python 3.13)

Solution: Build & install mlat-client using source code

Install build tools & dependencies:

Code: [Select]

```
sudo apt install git build-essential debhelper dh-python python3-dev py

sudo apt install python3-pyasyncore
```

Build & install mlat-client:

Code: [Select]

```
git clone https://github.com/mutability/mlat-client

cd mlat-client

sudo dpkg-buildpackage -b --no-sign

cd ../

sudo dpkg -i mlat-client_0.2.13_*.deb

sudo apt-mark hold mlat-client

sudo systemctl restart rbfeeder
```

VERY IMPORTANT:
The trixie uses python3.13, in which module "asyncore" has been replaced by module "asyncio".

During **runtime**, the current version (0.2.13) of mlat-client

requires the module "asyncore". As this module is missing, rbfeeder gives following error during runtime:

Code: [Select]

```
from mlat.client.net import ReconnectingConnection
File "/usr/lib/python3/dist-packages/mlat/client/net.py", line 25, in <
   import asyncore
ModuleNotFoundError: No module named 'asyncore'
```

SOLUTION:

To make python3.13 backward-compatible to software which are still using "asyncore" (such as mlat-client), debian developers have provided a package **"python3-pyasyncore"**. This package provides the missing module "asyncore". **This package must be installed** on user's RPi . For this reason, I have already included it under installation of dependencies in above method.

Code: [Select]

```
sudo apt install python3-pyasyncore
```

« Last Edit: November 07, 2025, 05:14:12 PM by abcd567 » Logged

abcd567

Hero Member

Posts: 923

CYYZ - Toronto

Re: How to Install rbfeeder on Raspberry Pi OS Trixie (debian 13)

« **Reply #2 on:** October 14, 2025, 03:53:51 PM »

ADDITIONAL SETTINGS (OPTIONAL)

If setting is "network_mode=false", it makes rbfeeder to start and use dump1090-rb. All settings of dump1090-rb are hard-coded in rbfeeder.

By default dump1090-rb is run with automatic gain control, which is very good. This is done by rbfeedr by passing folowing arguments to dump1090-rb:

--adaptive-range
--adaptive-burst

This setting for most purposes is very good. However if user wants to manually set a fixed gain, then this can ne done by adding following 3 lines under [client] section of file /etc/rbfeeder.ini

dump_gain=28
dump_adaptive_range=false
dump_adaptive_burst=false

Note: replace 28 in line "dump_gain=28" by gain value you want to set.

Save file and restart rbfeeder.

Please see screenshot attached.

« Last Edit: October 14, 2025, 03:58:25 PM by abcd567 » Logged

Pages: [1]

PRINT

« previous next »

AirNav Systems Forum » AirNav Radar » AirNav Radar Discussion (Moderator: Runway 31) »
How to Install rbfeeder on Raspberry Pi OS Trixie (debian 13)

Jump to: => AirNav Radar Discussion go

SMF 2 | SMF © 2017, Simple Machines
XHTML RSS WAP2

AirNav Systems

Contact Us ▶

Social Media

About Us Blog
FAQ Store

Copyright @ 2020 AirNav Systems LLC, Naples, FL, USA | All Rights Reserved