

```

void setup() {
  pinMode(LED_BUILTIN, OUTPUT);
  Serial.begin(9600);
  Serial.println("Type ON to turn LED on, OFF to turn it off.");
}

void loop() {
  if (Serial.available() > 0) {
    String command = Serial.readStringUntil('\n');
    command.trim();

    if (command.equalsIgnoreCase("ON")) {
      digitalWrite(LED_BUILTIN, HIGH);
      Serial.println("LED is ON");
    }
    else if (command.equalsIgnoreCase("OFF")) {
      digitalWrite(LED_BUILTIN, LOW);
      Serial.println("LED is OFF");
    }
    else {
      Serial.println("Unknown command. Use ON or OFF.");
    }
  }
}

```

```

#include <Servo.h>    // Inkluder standard Servo-bibliotek

```

```

Servo myServo;      // Opprett et servo-objekt
int angle = 90;      // Startposisjon

```

```

void setup() {
  myServo.attach(9); // Koble servo til pin 9
  myServo.write(angle);
  Serial.begin(9600);
  Serial.println("Skriv en vinkel (0-180):");
}

```

```

void loop() {
  if (Serial.available() > 0) {
    int value = Serial.parseInt(); // Leser et tall fra Serial
    if (value >= 0 && value <= 180) {
      myServo.write(value);
      Serial.print("Servo flyttet til: ");
      Serial.println(value);
    } else {

```

```

        Serial.println("Ugyldig verdi. Skriv 0-180.");
    }
}
}

#include <Servo.h>    // Standard Servo-bibliotek

Servo myServo;
int angle = 90;      // Startposisjon

const int servoPin = 9;
const int ledPin = 13; // LED koblet til pin 13 (innebygd LED på mange Arduinoer)

void setup() {
    myServo.attach(servoPin);
    myServo.write(angle);
    pinMode(ledPin, OUTPUT);

    Serial.begin(9600);
    Serial.println("Skriv en vinkel (0-180) eller kommando (LEFT, RIGHT, CENTER):");
}

void loop() {
    if (Serial.available() > 0) {
        String input = Serial.readStringUntil('\n');
        input.trim(); // Fjern mellomrom og linjeskift

        bool valid = false;
        int target = angle; // Behold gjeldende vinkel om ikke endret

        // Sjekk om input er et tall
        if (input.toInt() != 0 || input == "0") {
            int value = input.toInt();
            if (value >= 0 && value <= 180) {
                target = value;
                valid = true;
            }
        }

        // Sjekk kommandoer
        if (input.equalsIgnoreCase("LEFT")) {
            target = 0;
            valid = true;
        } else if (input.equalsIgnoreCase("RIGHT")) {
            target = 180;
            valid = true;
        } else if (input.equalsIgnoreCase("CENTER")) {

```

```

    target = 90;
    valid = true;
}

if (valid) {
    digitalWrite(ledPin, HIGH);    // Slå på LED (servo beveger seg)
    myServo.write(target);
    delay(500);                    // Gi servo tid til å bevege seg
    digitalWrite(ledPin, LOW);     // Slå av LED
    angle = target;                // Oppdater gjeldende posisjon
    Serial.print("Servo flyttet til: ");
    Serial.println(target);
} else {
    Serial.println("Ugyldig kommando/verdi. Bruk 0-180 eller LEFT/RIGHT/CENTER.");
}
}
}

```