

T15 - 417 Intro to Robotics Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail

Lab Number 01 CoppeliaSim EDU – Introduction to the Software

Introduction:

The robotics simulator CoppeliaSim, with integrated development environment, is based on a distributed control architecture: each object/model can be individually controlled via an embedded script, a plugin, ROS / ROS2 nodes, remote API clients, or a custom solution. This makes CoppeliaSim very versatile and ideal for multi-robot applications. Controllers can be written in C/C++, Python, Java, Lua, MATLAB or Octave. Following are just a few of CoppeliaSim's applications:

- Simulation of factory automation systems
- Remote monitoring
- Hardware control
- Fast prototyping and verification
- Safety monitoring
- Fast algorithm development
- Robotics related education
- Product presentation

Lab Prepared by:

Dr. Tayyab Zafar LE Hamza Sohail

Software Used:

CoppeliaSim EDU v4.7

Objectives of the Lab:

Objectives of the Lab are:

- Downloading of CoppeliaSim EDU Software
- To explore capabilities of CoppeliaSim EDU Software


Downloading:

CoppeliaSim EDU is an open-source software. It can be downloaded from the website www.coppeliarobotics.com




Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail




Upon opening CoppeliaSim EDU software we this window as follows:





Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail




New Scene – add a new scene in which you can simulate

Open Scene – Open already existing scene

Close Scene – Close the scene already selected

Save Scene – Save the current scene

Quit – Exit the CoppeliaSim



You can add shapes (cuboids etc), Joints (revolute, prismatic or spherical), Sensors or Script to




Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail

the scene.

Adding a Cuboid:




Tools are shown below:




Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail



1- Simulation Settings

In simulation settings dynamics should be enabled. At simulation end shows if you want to re initialize the scene from its initial state before it was simulated. This is helpful if you want to add new objects to want to check position and orientation of objects during simulation.



2- Scene Object properties

Once you select an object and click on scene object properties then a window will



Lah Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail

appear in which you can change properties as per requirement.

Select Cuboid

Click on the "Scene Object Properties" cene Object Properties Shape Object Shape Object General properties Visual properties ✓ Selectable Invisible during selection Colors Select base of model instead Ignored by depth pass Color Ignored by model bounding box Ignored for view-fitting Cannot be deleted during simul. Cannot be deleted Apply to selection Hidden during simulation Not moveable Extension string Other properties Apply to selection Shading angle [deg] 30.00 Visibility Show edges Backface culling Camera visibility layers To set an object as Invert faces either collidable. Apply to selection Apply to selection measurable or Texture / geometry properties Model definition Object special properties detectable. Such as Quick textures (selection) Texture Object is model ✓ Collidable ✓ Measurable Clear textures (selection) Geometry Force sensor can Model properties **✓** Detectable only sense Apply to selection Dynamic properties Other collidable object

3- Shape Edit Mode


Dynamic properties dialog

This option enables you to extract one shape from an already existing object.

Collection self-collision indicator

0

4- Model Browser




Model browser shows objects, equipment or robots that can be placed inside the scene. In this browser go to people and drag one to the scene.



Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail



5- Scene Hierarchy

Scene Hierarchy shows parent and child objects.

Add a cuboid Add a revolute joint Add another cuboid




Figure 1 shows independent objects on the scene such that revolute joint is not a child and cuboid[0] is not responsible for revolute joint. In figure 2 Revolute joint is a child of Cuboid parent. And cuboid2 is a child of Revolute joint such that revolute joint is connected to Cuboid parent and cuboid2 is connected with revolute joint. Here Revolute joint is responsible for child cuboid to move.



National University of Sciences & Technology

Course: MTS - 417 Intro to Robotics

Lab Manual


Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail

DUMMY Objects:


Dummy Objects does nothing in the scene but provide assisting in coding as reference to an object.

Translating and Rotating an Object/Frame

Translating means moving Objects/Frames from one place to another upon X, Y or Z axis while rotating means rotation of axis around X, Y or Z axis.



Object can be translated and rotated either by parent frame or world frame. In model browser, got to others \rightarrow Drag reference frame to scene.



Attach it to the cuboid. Drag the reference frame in scene hierarchy to cuboid.




National University of Sciences & Technology


Course: MTS - 417 Intro to Robotics

Lab Manual


Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail



Select the reference frame and click on the translational settings.



To attach it to the reference frame, select parent frame 0, 0,0 such that it will translate to cuboid since it is a child object of cuboid. Also select rotation and make its parent frame 0,0,0.




Now select the cube and change its orientation (Alpha +90) relative world frame.



Lab Manual

Prepared By: Dr. Tayyab Zafar & LE Hamza Sohail



Now you can see world frame axis are different than the cuboid parent frame axis.