









Buttons

SD/MMC Card

K GPI014/HS2_CLK R40 10R/R0402
RM3D 4.2 4.1 GPI02/HS2_DATA0
RM3A 1.2 1.1
RM3C 3.2 3.1
R1206_(4X0603)_488_2.2k

NA/R0402 R49 D_Com

MICRO_SD1

CD/DAT3/CS







