```
Reference Language (//www.arduino.cc/en/Reference/HomePage) | Libraries
(//www.arduino.cc/en/Reference/Libraries) | Comparison
(//www.arduino.cc/en/Reference/Comparison) | Changes (//www.arduino.cc/en/Reference/Changes)
```

## setup()

The setup() function is called when a sketch starts. Use it to initialize variables, pin modes, start using libraries, etc. The setup function will only run once, after each powerup or reset of the Arduino board.

## Example

```
int buttonPin = 3;
void setup()
  Serial.begin(9600);
  pinMode(buttonPin, INPUT);
void loop()
  // ...
```

Reference Home (//www.arduino.cc/en/Reference/HomePage)

Corrections, suggestions, and new documentation should be posted to the Forum (http://arduino.cc/forum/index.php/board,23.0.html).

The text of the Arduino reference is licensed under a Creative Commons Attribution-ShareAlike 3.0 License (http://creativecommons.org/licenses/by-sa/3.0/). Code samples in the reference are released into the public domain.

## **NEWSLETTER**

Enter your email to sign up

**SUBSCRIBE** 

Terms Of Service (//www.arduino.cc/en/Main/TermsOfService)

Privacy Policy (//www.arduino.cc/en/Main/PrivacyPolicy)

Contact Us (//www.arduino.cc/en/Main/ContactUs)

About Us (//www.arduino.cc/en/Main/AboutUs)

Distributors (//store.arduino.cc/distributors)

Careers (//careers.arduino.cc)

Security (//www.arduino.cc/en/Main/Security)

© 2020 Arduino (//www.arduino.cc/en/Main/CopyrightNotice)

(https://w/tpos/