RC Lar, Code Flowchart.

check tilt sensor Configure PSZ Controller decitopside down FWD/BKWD Receive PSZ Data Send PSZ CMD Switch motor headights hunk/beep