

HomeFix AI — Washing Machine User Manual

Sample knowledge document for the HomeFix AI RAG prototype.

1. Product Overview

This sample manual describes a front-loading washing machine and provides operating, maintenance, and troubleshooting information.

2. Basic Operation

Load clothes evenly, add the recommended detergent, close the door securely, select a suitable wash program, and press Start/Pause. Do not overload the drum.

3. Error Code E5

If error code E5 appears, stop the machine and check whether the water supply tap is fully open. Inspect the inlet hose for kinks and make sure the inlet filter is not blocked. Restart the machine after restoring water flow. If E5 continues to appear, contact an authorized service technician.

4. Drainage Problems

If water does not drain, check the drain hose for blockage or excessive bending. Clean the drain pump filter according to the maintenance instructions. Disconnect electrical power before opening the filter.

5. Door Will Not Open

The door may remain locked while water is inside the drum or while the machine is operating. Wait until the cycle ends. If the door remains locked, switch off the appliance and follow the emergency-release procedure in the service instructions.

6. Maintenance

Clean the detergent drawer regularly. Inspect hoses for cracks or leaks. Clean the pump filter periodically. Keep the door slightly open after a wash cycle to allow the drum to dry.

7. Safety

Do not operate the appliance with a damaged power cord. Do not attempt electrical repairs yourself. Disconnect the appliance from power before cleaning internal filters.

Document status: Sample / Demo content. This document is intended for testing document retrieval, source citation, and troubleshooting workflows.