

Forge-Sense: User Manual & Operational Guide

1. Introduction & Navigation Overview

Welcome to the Forge-Sense Industrial Safety Platform user manual. This guide explains how to navigate and utilize the system features without executing automated model changes or risking code execution errors.

2. Getting Started (Login Window)

- Upon launching the application, the Login Window appears.
- Enter your valid registered username and credentials to access the main operational interface.
- Once authenticated, the main dashboard loads with your operator profile active in the top navbar.

3. Operational Controls & Camera Modes

The Control Panel provides the following navigation tools:

- Upload Video: Selects a local video file (*.mp4, *.avi, *.mov, *.mkv) to load and analyze.
- Upload Sensor Link: Ingests RTSP, HTTP, or direct camera stream links for real-time tracking.
- Camera Modes: The application supports two distinct view modes via the dropdown selector:
 1. Perspective View: Standard perspective rendering of the factory floor.
 2. Top-Down View: Orthographic or top-down schematic mapping of spatial zones.

4. Safety Monitoring & Compliance

- Inject Environmental Hazard: Simulates gas or temperature spikes for testing threat response.
- Define Zone Type: Categorizes areas (e.g., SAFE, CAUTION, DANGER, RESTRICTED, HOT_WORK).
- Ask Compliance: Queries integrated regulatory standards (Factories Act, OISD, DGMS).
- Help Button: Opens this official manual PDF directly from the assets directory.